

# MOUNTING AND OPERATING INSTRUCTIONS



## EB 8384-5 EN

Translation of original instructions



Old design



New design



## Series 3730

### Type 3730-5 Electropneumatic Positioner

With FOUNDATION™ fieldbus communication · FF Device Rev. 3

Firmware version 1.65



Edition January 2022

## Note on these mounting and operating instructions

These mounting and operating instructions assist you in mounting and operating the device safely. The instructions are binding for handling SAMSON devices. The images shown in these instructions are for illustration purposes only. The actual product may vary.

- For the safe and proper use of these instructions, read them carefully and keep them for later reference.
- If you have any questions about these instructions, contact SAMSON's After-sales Service ([aftersalesservice@samsongroup.com](mailto:aftersalesservice@samsongroup.com)).



Documents relating to the device, such as the mounting and operating instructions, are available on our website at [www.samsongroup.com](http://www.samsongroup.com) > **Service & Support > Downloads > Documentation.**

## Definition of signal words

### **DANGER**

Hazardous situations which, if not avoided, will result in death or serious injury

### **NOTICE**

Property damage message or malfunction

### **WARNING**

Hazardous situations which, if not avoided, could result in death or serious injury

### **Note**

Additional information

### **Tip**

Recommended action

<b>1</b>	<b>Safety instructions and measures .....</b>	<b>7</b>
1.1	Notes on possible severe personal injury .....	11
1.2	Notes on possible personal injury .....	11
1.3	Notes on possible property damage .....	12
<b>2</b>	<b>Markings on the device .....</b>	<b>13</b>
2.1	Nameplate .....	13
2.2	Article code .....	14
2.3	Firmware versions .....	15
<b>3</b>	<b>Design and principle of operation .....</b>	<b>19</b>
3.1	Mounting versions .....	20
3.2	Additional equipment .....	20
3.3	Communication .....	21
3.4	Configuration using the TROVIS-VIEW software .....	21
3.5	Device overview and operating controls .....	22
3.6	Accessories .....	23
3.6.1	Travel tables .....	28
3.7	Technical data .....	29
3.8	Dimensions in mm .....	35
3.8.1	Fixing levels according to VDI/VDE 3845 (September 2010) .....	39
<b>4</b>	<b>Measures for preparation .....</b>	<b>41</b>
4.1	Unpacking .....	41
4.2	Transporting .....	41
4.3	Storage .....	41
<b>5</b>	<b>Mounting and start-up .....</b>	<b>43</b>
5.1	Mounting position .....	43
5.2	Lever and pin position .....	43
5.3	Direct attachment .....	46
5.3.1	Type 3277-5 Actuator .....	46
5.3.2	Type 3277 Actuator .....	48
5.4	Attachment according to IEC 60534-6 .....	50
5.5	Attachment according to VDI/VDE 3847-1 .....	52
5.6	Attachment according to VDI/VDE 3847-2 .....	56
5.6.1	Version for single-acting actuator .....	58
5.6.2	Version for double-acting actuator .....	60
5.7	Attachment to Type 3510 Micro-flow Valve .....	64
5.8	Attachment to rotary actuators .....	64
5.8.1	Heavy-duty version .....	66

## Contents

5.9	Reversing amplifier for double-acting actuators .....	70
5.9.1	Reversing amplifier (1079-1118 or 1079-1119) .....	70
5.10	Attachment of external position sensor .....	72
5.10.1	Mounting the position sensor with direct attachment.....	73
5.10.2	Mounting the position sensor with attachment according to IEC 60534-6 .....	75
5.10.3	Mounting the position sensor to Type 3510 Micro-flow Valve.....	76
5.10.4	Mounting on rotary actuators.....	77
5.11	Mounting the leakage sensor .....	78
5.12	Retrofitting an inductive limit contact.....	79
5.13	Attaching positioners with stainless steel housings.....	80
5.14	Air purging function for single-acting actuators .....	80
5.15	Pneumatic connections.....	83
5.15.1	Connecting the supply air .....	83
5.15.2	Signal pressure gauges .....	84
5.15.3	Supply pressure .....	84
5.15.4	Signal pressure (output) .....	85
5.16	Electrical connections .....	85
5.16.1	Establishing communication .....	87
<b>6</b>	<b>Operation .....</b>	<b>91</b>
<b>7</b>	<b>Operating the positioner.....</b>	<b>95</b>
7.1	Determining the fail-safe position .....	96
7.2	Adjusting the volume restriction Q .....	96
7.3	Adapting the display direction .....	97
7.4	Limiting the signal pressure .....	97
7.5	Checking the operating range of the positioner .....	98
7.6	Initializing the positioner .....	99
7.6.1	MAX – Initialization based on maximum range .....	102
7.6.2	NOM – Initialization based on nominal range .....	103
7.6.3	MAN – Initialization based on a manually selected range .....	105
7.6.4	SUB – Substitute calibration .....	106
7.7	Zero calibration .....	111
7.8	Adjusting the inductive limit contact.....	112
7.9	Reset to default settings.....	114
7.10	Enabling and selecting parameters.....	114
7.11	Operating modes.....	116
7.11.1	Automatic and manual modes .....	116
7.11.2	Fail-safe position (SAFE) .....	117

<b>8</b>	<b>Servicing.....</b>	<b>119</b>
8.1	Firmware update.....	119
8.2	Preparation for return shipment.....	120
<b>9</b>	<b>Malfunctions .....</b>	<b>121</b>
9.1	Confirming error messages .....	122
9.2	Emergency action .....	122
<b>10</b>	<b>Decommissioning and removal .....</b>	<b>123</b>
10.1	Decommissioning .....	123
10.2	Removing the positioner .....	123
10.3	Disposal .....	123
<b>11</b>	<b>Annex.....</b>	<b>125</b>
11.1	After-sales service .....	125
11.3	Certificates .....	125
11.4	Code list.....	126
11.5	Error codes.....	133
11.6	Decimal values of the modes in the FOUNDATION™ fieldbus blocks (Code 48) .....	139
11.7	Decimal values of the states in the FOUNDATION™ fieldbus blocks (Code 48) .....	139
11.8	Selecting the characteristic.....	141

---

**i** Note

- Configuration and operation over FOUNDATION™ fieldbus are described in the Configuration Manual ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.
  - The functions of the **EXPERTplus** Valve Diagnostics are described in the Operating Instructions ► EB 8389. EB 8389 is included on the enclosed CD-ROM and is available on our website.
-

# **1 Safety instructions and measures**

## **Intended use**

SAMSON's Type 3730-5 Positioner is mounted on pneumatic control valves and is used to assign the valve position to the control signal. The device is designed to operate under exactly defined conditions (e.g. operating pressure, temperature). Therefore, operators must ensure that the positioner is only used in applications where the operating conditions correspond to the technical data. In case operators intend to use the positioner in other applications or conditions than specified, contact SAMSON.

SAMSON does not assume any liability for damage resulting from the failure to use the device for its intended purpose or for damage caused by external forces or any other external factors.

→ Refer to the technical data for limits and fields of application as well as possible uses.

## **Reasonably foreseeable misuse**

The Type 3730-5 Positioner is **not** suitable for the following applications:

– Use outside the limits defined during sizing and by the technical data

Furthermore, the following activities do not comply with the intended use:

– Use of non-original spare parts

– Performing maintenance activities not specified by SAMSON

## **Qualifications of operating personnel**

The positioner is to be mounted, started up or operated only by trained and experienced personnel familiar with the product. According to these mounting and operating instructions, trained personnel refers to individuals who are able to judge the work they are assigned to and recognize possible hazards due to their specialized training, their knowledge and experience as well as their knowledge of the applicable standards.

Explosion-protected versions of this device must be operated only by personnel who has undergone special training or instructions or who is authorized to work on explosion-protected devices in hazardous areas.

## **Safety instructions and measures**

### **Personal protective equipment**

No personal protective equipment is required for the direct handling of the positioner. Work on the control valve may be necessary when mounting or removing the device.

- Observe the requirements for personal protective equipment specified in the valve documentation.
- Check with the plant operator for details on further protective equipment.

### **Rewriting and other modifications**

Rewriting, conversions or other modifications of the product are not authorized by SAMSON. They are performed at the user's own risk and may lead to safety hazards, for example. Furthermore, the product may no longer meet the requirements for its intended use.

### **Safety features**

Upon failure of the air supply or electric signal, the positioner vents the actuator, causing the valve to move to the fail-safe position determined by the actuator.

### **Warning against residual hazards**

The positioner has direct influence on the control valve. Any hazards that could be caused in the valve by the process medium, the signal pressure or by moving parts are to be prevented by taking appropriate precautions. They must observe all hazard statements, warning and caution notes in these mounting and operating instructions, especially for installation, start-up and service work.

If inadmissible motions or forces are produced in the pneumatic actuator as a result of the supply pressure, it must be restricted using a suitable supply pressure reducing station.

### **Explosion protection**

#### **– Explosive dust atmospheres of zone 21 or zone 22**

The following applies to type of protection Ex i in combustible dust atmospheres:

If intrinsic safety is impaired by the influence of dust, an enclosure complying with Clause 6.1.3 of EN 60079-11 with at least in degree of protection IP 5X must be used. The requirements according to Clause 6.1.3 apply to the cable glands accordingly. The degree of ingress protection is verified by a test according to IEC 60529 and EN 60079-0 (e.g. performed by VDE).

For use in the presence of combustible dust in compliance with type of protection Ex tb IIIC (protection by enclosure), observe Clause 5.6.3 of EN 60079-14.

### **– Servicing explosion-protected devices**

If a part of the device on which the explosion protection is based needs to be serviced, the device must not be put back into operation until a qualified inspector has assessed it according to explosion protection requirements, has issued an inspection certificate, or given the device a mark of conformity. Inspection by a qualified inspector is not required if the manufacturer performed a routine test on the device before putting it back into operation. Document the passing of the routine test by attaching a mark of conformity to the device.

Replace explosion-protected components only with original, routine-tested components by the manufacturer.

Devices that have already been used outside hazardous areas and are intended for future use inside hazardous areas must comply with the safety requirements placed on serviced devices. Before being operated inside hazardous areas, test the devices according to the specifications for servicing explosion-protected devices.

EN 60079-17 applies to servicing explosion-protected devices.

### **– Maintenance, calibration and work on equipment**

Observe the maximum permissible values specified in the certificates for intrinsically safe circuits to ensure that components relevant to explosion protection are not damaged.

## **Responsibilities of the operator**

The operator is responsible for proper operation and compliance with the safety regulations. Operators are obliged to provide these mounting and operating instructions to the operating personnel and to instruct them in proper operation. Furthermore, the operator must ensure that operating personnel or third persons are not exposed to any danger.

## **Responsibilities of operating personnel**

Operating personnel must read and understand these mounting and operating instructions as well as the specified hazard statements, warning and caution notes. Furthermore, the operating personnel must be familiar with the applicable health, safety and accident prevention regulations and comply with them.

## **Safety instructions and measures**

### **Referenced standards, directives and regulations**

Devices with a CE marking fulfill the following requirements of the Directives:

- Type 3730-5: 2011/65/EU, 2014/30/EU
- Type 3730-51, -55, -58: 2011/65/EU, 2014/30/EU, 2014/34/EU

Devices with an EAC marking fulfill the requirements of the following Regulations:

- Type 3730-5: TR CU 020/2011

Devices with a UKCA marking fulfill the requirements of the following regulations:

- Type 3730-5: SI 2016 No. 1091, SI 2012 No. 3032
- Type 3730-51/-55: SI 2016 No. 1091, SI 2016 No. 1107, SI 2012 No. 3032
- Type 3730-58: SI 2016 No. 1091, SI 2016 No. 1107, SI 2012 No. 3032

See Annex for declarations of conformity and EAC certificates.

### **Referenced documentation**

The following documents apply in addition to these mounting and operating instructions:

- Operating instructions for valve diagnostics: ► EB 8389
- The mounting and operating instructions of the components on which the positioner is mounted (valve, actuator, valve accessories etc.).

## **1.1 Notes on possible severe personal injury**

### **⚠ DANGER**

#### **Risk of fatal injury due to the formation of an explosive atmosphere.**

Incorrect installation, operation or maintenance of the positioner in potentially explosive atmospheres may lead to ignition of the atmosphere and cause death.

- ➔ The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1).
- ➔ Installation, operation or maintenance of the positioner must only be performed by personnel who has undergone special training or instructions or who is authorized to work on explosion-protected devices in hazardous areas.

## **1.2 Notes on possible personal injury**

### **⚠ WARNING**

#### **Risk of personal injury due to moving parts on the valve.**

During initialization of the positioner and during operation, the actuator stem moves through its entire travel range. Injury to hands or fingers is possible if they are inserted into the valve.

- ➔ During initialization, do not insert hands or fingers into the valve yoke and do not touch any moving valve parts.

### 1.3 Notes on possible property damage

#### NOTICE

##### **Risk of damage to the positioner due to incorrect mounting position.**

- Do not mount the positioner with the back of the device facing upward.
- Do not seal or restrict the vent opening when the device is installed on site.

##### **Risk of malfunction due to incorrect sequence during start-up.**

The positioner can only work properly if the mounting and start-up are performed in the prescribed sequence.

- Perform mounting and start-up as described in section 5.

##### **An incorrect electric signal will damage the positioner.**

The positioner is powered over the bus line.

- Only use a current source and never a voltage source.

##### **Incorrect assignment of the terminals will damage the positioner and will lead to malfunction.**

For the positioner to function properly, the prescribed terminal assignment must be observed.

- Connect the electrical wiring to the positioner according to the prescribed terminal assignment.

##### **Malfunction due to initialization not yet completed.**

The initialization causes the positioner to be adapted to the mounting situation. After initialization is completed, the positioner is ready to use.

- Initialize the positioner on the first start-up.
- Re-initialize positioner after changing the mounting position.

##### **Risk of positioner damage due to incorrect grounding of the electric welding equipment.**


- Do not ground electric welding equipment near to the positioner.

## 2 Markings on the device

### 2.1 Nameplate


The nameplates shown were up to date at the time of publication of this document. The nameplates on the device may differ from the ones shown.

#### Explosion-protected version



- 1 FOUNDATION™ fieldbus: Communication Profile Class
- 2 FOUNDATION™ fieldbus: Physical Layer Class
- 3 Supply pressure
- 4 Type of protection for explosion-protected devices

#### Version without explosion protection



- 5 Features:  Yes /  No
  - Binary input 5 to 30 V DC
  - Binary input, floating contact
  - Leakage detection
  - Limit switch, inductive
  - Solenoid valve
- 6 Firmware version (see section 2.3)
- 7 Year of manufacture
- 8 Configuration ID
- 9 Serial number
- 10 Model number
- 11 Conformity
- 12 RoHS marking
- 13 Data Matrix code

## Markings on the device

### 2.2 Article code

Positioner		Type 3730-5	x	x	x	0	x	x	x	0	x	0	x	x
With LCD and autotune, FOUNDATION™ fieldbus														
<b>Explosion protection</b>														
Without		0											000	
<b>ATEX</b>	II 2G Ex ia IIC T6 Gb; II 2D Ex ia III T80°C Db	1											000	
<b>ATEX</b>	II 2D Ex tb IIIC T80°C Db	5											000	
<b>ATEX</b>	II 3G Ex nA IIC T6 Gc, II 3D Ex tc IIIC T80°C Dc	8											000	
<b>IECEx</b>	Ex ia IIC T6...T4 Gb; Ex ia IIC T80°C Db	1											012	
<b>IECEx</b>	Ex nA IIC T6...T4 Gc; Ex tc IIIC T80°C Dc	8											013	
<b>CCC Ex</b>	Ex ia IIC T4...T6 Gb; Ex ia IIIC T80 °C Db	1											009	
<b>CCC Ex</b>	Ex ec IIC T6 Gc	8											010	
<b>CCoE</b>	Ex ia IIC T6...T4 Gb	1												
<b>CSA</b>	Ex ia IIC T6; Class I,II, Div.1, Groups A-G; Ex nA II T6; Ex nL IIC T6; Class I, II, Div.2, Groups A-G; Class II, Div.1, Groups E-G; Class III	3											000	
<b>EAC</b>	1Ex ia IIC T6/T5/T4 Gb X, Ex tb IIIC T80 °C Db X	1											014	
<b>FM</b>	Class I, Zone 0 AEx ia IIC; Class I, II, III, Div.1, Groups A, B, C, D, E, F, G; Class I, Div.2, Groups A, B, C, D; Class II, Div.2, Groups F, G												000	
<b>INMETRO</b>	Ex ia IIC T4...T6 Gb; Ex ia IIIC T80 °C Db	1											031	
	Ex ec IIC T4...T6 Gc; Ex tc IIIC T80 °C Dc	8												
<b>KCS</b>	Ex ia IIC T6/T5/T4	1											029	
<b>TR CMU</b>	II 2G Ex ia IIC T6...T4 Gb; II 2D Ex ia IIIC T80 °C Db	1											043	
	II 2D Ex tb IIIC T80 °C Db	5												
	II 3G Ex ic nA IIC T6 Gc; II 3D Ex tc IIIC T80 °C Dc IP66	8												
<b>UKEX</b>	II 2G Ex ia IIC T4/T6 Gb; II 2D Ex ia IIIC T80°C Db	1											051	
	II 2D Ex tb IIIC T80°C Db	5												
	II 3G Ex ec IIC T* Gc; II 3D Ex tc IIIC T80°C Dc	8												
<b>Additional equipment</b>														
Inductive limit switch	Without	0												
	SJ2-SN (NC contact)	1												
Solenoid valve	Without	0												
	With, 24 V DC	4												
External position sensor	Without		0											
	With	0	1	0									0	
Leakage sensor	Without			0										
	With			1										
Binary input	Without				0									
	Floating contact				0	1								
<b>Diagnostics</b>														
EXPERTplus												4		

Positioner	Type 3730-5	x	x	x	0	x	x	x	0	x	0	0	x	x
<b>Housing material</b>														
Aluminum (standard)										0				
Stainless steel 1.4408				0						1				
<b>Special applications</b>														
Without												0		
Device compatible with paint												1		
Exhaust air port with 1/4-18 NPT thread, back of positioner sealed	0	0	0	0								2		
Attachment according to VDI/VDE 3847 including interface												6		
Attachment according to VDI/VDE 3847 prepared for interface												7		
<b>Special version</b>														
Without												0	0	0

## 2.3 Firmware versions

Firmware revisions (Control R)
<b>R 1.44 to 1.46</b> Internal revisions
<b>R 1.52</b> <ul style="list-style-type: none"> <li><b>Diagnostics:</b> all EXPERTplus diagnostic functions are available without having to activate them in the positioner (► EB 8389 on EXPERTplus Valve Diagnostics).</li> <li>Additional function blocks: 2x DO (Discrete Output), 1x IS (Input Selector), 1x MAI (Multiple Analog Input), 1x MAO (Multiple Analog Output). See Configuration Manual ► KH 8384-5</li> <li>New functions: new functions are implemented in the DO Function Block (Discrete Output). See Configuration Manual ► KH 8384-5</li> <li><b>Action on fault detection:</b> If the AO Transducer Block is in O/S mode and the condensed state changes to "Maintenance alarm", the following actions can be started:           <ul style="list-style-type: none"> <li>– Hold last value</li> <li>– Move valve to fail-safe position</li> <li>– Move to a predefined fault state value</li> </ul>           Configuration Manual ► KH 8384-5         </li> </ul>
<b>R 1.54 to 1.56</b> <b>Code 48 extended:</b> The following subitems have been added to Code 48 (► EB 8389): <ul style="list-style-type: none"> <li>• h0: Activation/deactivation reference test</li> <li>• h1: Reference test completed (YES/No)</li> <li>• h3: Automatic reset of diagnosis after this time</li> <li>• h4: Remaining time until diagnosis reset</li> </ul>
<b>R 1.54 to 1.56</b> Internal revisions
<b>R 1.57</b> <b>Data logging:</b> Data logging has been extended to document errors in internal device communication.

## Markings on the device

Firmware revisions (Control R)
<b>R 1.58</b> Improved memory function: the test results of newly performed partial stroke tests (PST) are saved in several cycles.
<b>R 1.62</b> The positioner moves more quickly to closed-loop operation due to an improved start-up routine.
<b>R 1.64</b> Improved memory function: the test results of newly performed partial stroke tests (PST) are saved in several cycles.
<b>R 1.65</b> Internal revisions

Firmware revisions (Communication K)
Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.
<b>K 1.21</b> <ul style="list-style-type: none"><li>• "<b>Device not initialized" diagnostic alarm:</b> the diagnostic alarm "Device not initialized" is generated when the positioner is not initialized and the condensed state is set to "Maintenance alarm".</li><li>• <b>Leakage sensor at binary input 2:</b> The connection of a leakage sensor at binary input 2 (by selecting LEAKAGE SENSOR in CONFIG_BINARY_INPUT2 parameter of the AO Transducer Block) causes:<ul style="list-style-type: none"><li>– Information specified in XD_ERROR_EXT parameter in the AO Transducer Block and the generation of a diagnostic alarm which is logged</li><li>– The state of the binary input is reported in BINARY_INPUT2 parameter in the AO Transducer Block</li></ul>The connection of a leakage sensor at binary input 2 (by selecting LEAKAGE SENSOR in CONFIG_BINARY_INPUT2 parameter of the AO Transducer Block) causes:<ul style="list-style-type: none"><li>– Information specified in XD_ERROR_EXT parameter in the AO Transducer Block and the generation of a diagnostic alarm which is logged</li><li>– The state of the binary input is reported in BINARY_INPUT2 parameter in the AO Transducer Block</li></ul></li><li>• <b>Display of the operating range FINAL_VALUE_RANGE:</b> the correction of the operating range FINAL_VALUE_RANGE over on-site operation of the positioner (Code 8/9) is also transferred over fieldbus in firmware version K 1.21 and higher.</li><li>• <b>De-energized internal solenoid valve:</b> a masking allows to set whether a de-energized internal solenoid valve generates an AO block error, resulting in a block alarm.</li><li>• <b>SOLENOID_SELECT parameter:</b> the SOLENOID_SELECT parameter in firmware K 1.21 and higher allows to set whether a "Maintenance now" block error of the AO Transducer Block results in an output error in the AO Block.</li><li>• <b>TOT_VALVE_TRAV_LIM parameter:</b> new range: 1000 to 990 000 000</li></ul>

### Firmware revisions (Communication K)

Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.

#### K 1.22

- **Operating range FINAL\_VALUE\_RANGE:** the operating range FINAL\_VALUE\_RANGE of the AO Transducer Block is compared on entering it with TRANSM\_PIN\_POS.
- If the TRANSM\_PIN\_POS parameter is changed, the positioner checks whether the setting and unit match the current operating range FINAL\_VALUE\_RANGE. If this is not the case, the FINAL\_VALUE\_RANGE parameter is set to 0 to 100 %.
- **VALVE\_TYPE parameter:** the parameter of the AO Transducer Block is set depending on the selected PIN\_POS. The last setting is kept when VALVE\_TYPE is set to OFF.
- **FINAL\_VALUE parameter:** the output value is scaled with FINAL\_VALUE\_RANGE in firmware K 1.22 and higher and not as previously with XD\_SCALE.
- **Display of O/S mode in AO Transducer Block:** if the AO Transducer Block is set to O/S mode, this is indicated in the positioner display by MAN/AUTO.

#### K 1.23

Internal revisions

#### K 1.24

- **BUS\_ADDRESS parameter:** the bus address has the default setting of 248.
- **Device type:** in the delivered state, the device is configured as a basic device.

#### K 1.25

Internal revisions

#### K 2.01

- **Additional function blocks:** 2x DO (Discrete Output), 1x IS (Input Selector), 1x MAI (Multiple Analog Input), 1x MAO (Multiple Analog Output).
- **New functions:** the following new functions are implemented in the DO Function Block (Discrete Output):
  - Discrete analysis of on/off valves
  - Start partial stroke test (PST)
  - Start and reset the data logger
  - Resetting the diagnosis
  - Stop diagnosis
  - Move to the fail-safe position
  - Lock on-site operation
- **Action on fault detection:** If the AO Transducer Block is in O/S mode and the condensed state changes to "Maintenance alarm", the following actions can be started:
  - Hold last value
  - Move valve to fail-safe position
  - Move to a predefined fault state value

#### K 2.02

**Partial stroke test (PST):** configuration of the partial stroke test (PST) over the FF parameters is no longer possible. Configuration over the TROVIS-VIEW software is still possible.

## Markings on the device

### Firmware revisions (Communication K)

Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.

#### K 2.03

**Partial stroke test (PST):** configuration of the partial stroke test (PST) over the FF parameters is no longer possible. Configuration over the TROVIS-VIEW software is still possible. The partial stroke test can be started over the binary input BI2.

#### K 2.04

Internal revisions

#### K 2.05

Internal revisions

#### K 2.06

**Process control system:** new firmware compatible with Honeywell Experion® control system.

Communication: improved communication of valve positions smaller than -0.9 %.

#### K 2.07

**Testing device functioning:** monitoring of internal device communication has been added to the cyclic testing of the device functions.

#### K 2.08

**Internal communication interface redesigned:** the permissible clock frequency of communication calls between the internal device controllers has been optimized.

#### K 3.01

- Certified according to ITK 6.2.0
- Diagnostics specification according to FF-912
- Function block added: AI (Analog Input)
- Function blocks removed: MAI (Multiple Analog Input), MAO (Multiple Analog Output), IS (Input Selector)

#### K 3.05

Internal communication interface redesigned: the permissible clock frequency of communication calls between the internal device controllers has been optimized.

#### K 3.06

Fail-safe position reliably maintained even when the positioner is not connected to the process control system.

### 3 Design and principle of operation

→ Refer to Fig. 1


The positioner is mounted on pneumatic control valves and is used to assign the valve position (controlled variable  $x$ ) to the control signal (set point  $w$ ). The positioner compares the control signal of a control system to the travel or rotational angle of the control valve and issues a signal pressure (output variable  $y$ ) for the pneumatic actuator.

The positioner mainly consists of an electric travel sensor system, an analog i/p convert-

er with a downstream air capacity booster and the electronics with the microcontroller.

When a system deviation occurs, the actuator is either vented or filled with air. If necessary, the signal pressure change can be slowed down by a volume restriction. The signal pressure supplied to the actuator can be limited by software or on site to 1.4, 2.4 or 3.7 bar.

The fixed flow regulator ensures a constant air flow to the atmosphere, which is used to flush the inside of the positioner housing and to optimize the air capacity booster. The i/p converter is supplied with a constant upstream pressure by the pressure regulator to



compensate for any fluctuations in the supply pressure.

The positioner communicates and is powered using IEC 61158-2 transmission technology conforming to FOUNDATION™ fieldbus specification.

As a standard feature, the positioner comes with a binary input used to signalize process information over the FOUNDATION™ fieldbus network.

The extended EXPERTplus diagnostics are integrated into the positioner. They provide information on the positioner and generate diagnostic and status messages, which allow faults to be pinpointed quickly.

### 3.1 Mounting versions

The positioner is suitable for the following types of attachment using the corresponding accessories (see section 3.6):

- **Direct attachment to SAMSON Type 3277 Actuator**  
→ See section 5.3.
- **Attachment to actuators according to IEC 60534-6:**  
→ See section 5.4.
- **Attachment according to VDI/VDE 3847-1/-2:**  
→ See section 5.5 and section 5.6.
- **Attachment to Type 3510 Micro-flow Valve**  
→ See section 5.7.

- **Attachment to rotary actuators according to VDI/VDE 3845:**

→ See section 5.8.

## 3.2 Additional equipment

### Solenoid valve

If the operating voltage for the solenoid valve (12) fails, the supply pressure for the i/p converter is vented to the atmosphere. The positioner can no longer operate and the control valve moves to the fail-safe position determined by the actuator, regardless of the set point.

#### NOTICE

*The manual set point is also reset to 0 % after the solenoid valve is activated.  
A different manual set point must be entered again (Code 1).*

### Inductive limit contact

In this version, the rotary shaft of the positioner carries an adjustable tag which actuates the built-in proximity switch.

### External position sensor

In this version, only the sensor is mounted to the control valve. The positioner is located separately from the valve. The connection of x and y signals to the valve is established by cable and piping for air (only without inductive limit contact).

### Leakage sensor

By upgrading the positioner with a leakage sensor, it is possible to detect seat leakage when the valve is in the closed position.

### Binary input BI1 (14)

As a standard feature, the positioner comes with a binary input used to signalize process information over the FOUNDATION™ fieldbus network.

### Binary input BI2 (15)

This binary input BI2 is optional. It is an active input which is powered by the positioner to connect a floating contact. The switching state of the floating contact can be indicated over the FOUNDATION™ fieldbus network.

#### i Note

*The binary inputs are configured in the DI Function Blocks. Refer to Configuration Manual ► KH 8384-5.*

## 3.3 Communication

The positioner is controlled completely by digital signal transmission according to FOUNDATION™ fieldbus specification.

Data are transmitted over the bus using digital, bit-synchronous Manchester coding at a Baud rate of 31.25 kbit/s over twisted-pair wires according to IEC 61158-2.

#### i Note

*If complex functions are started in the positioner, which require a long calculation time or lead to a large quantity of data being saved in the volatile memory of the positioner, the alert 'busy' is issued over the DD. This alert is **not an error message** and can be simply confirmed.*

**Configuration and operation of the positioner over FOUNDATION™ fieldbus are described in the Configuration Manual**

► KH 8384-5.

## 3.4 Configuration using the TROVIS-VIEW software

The positioner can be configured with SAMSON's TROVIS-VIEW Software.

The positioner has for this purpose a **serial interface** to allow the RS-232 or USB port of a computer to be connected to it using an adapter cable.

The TROVIS-VIEW software enables the user to easily configure the positioner as well as view process parameters online.

### Note

TROVIS-VIEW provides a uniform user interface that allows users to configure and parameterize various SAMSON devices using device-specific database modules. The device module 3730-5 can be downloaded free of charge from our website at

► [www.samsongroup.com](http://www.samsongroup.com) > SERVICE & SUPPORT > Downloads > TROVIS-VIEW. Further information on TROVIS-VIEW (e.g. system requirements) is available on our website and in the Data Sheet ► T 6661.

---

### 3.5 Device overview and operating controls

→ See section 6.

## 3.6 Accessories

**Table 1:** General accessories

Designation		Order no.
Reversing amplifier for double-acting actuators		Type 3710
	Black plastic (6 to 12 mm clamping range)	8808-1011
	Blue plastic (6 to 12 mm clamping range)	8808-1012
Cable gland M20x1.5	Nickel-plated brass (6 to 12 mm clamping range)	1890-4875
	Nickel-plated brass (10 to 14 mm clamping range)	1922-8395
	Stainless steel 1.4305 (8 to 14.5 mm clamping range)	8808-0160
Adapter M20x1.5 to 1/2 NPT	Powder-coated aluminum	0310-2149
	Stainless steel	1400-7114
Lever	S	0510-0522
	M	0510-0510
	L	0510-0511
	XL	0510-0512
	XXL	0510-0525
Retrofit kit for inductive limit contact 1 x SJ2-SN		1402-1770
Isolated USB interface adapter (SSP interface to USB port) including TROVIS-VIEW CD-ROM		1400-9740
Serial interface adapter (SAMSON SSP interface to RS-232 port on a computer)		1400-7700
TROVIS-VIEW 6661 (download: ► <a href="http://www.samsongroup.com">www.samsongroup.com</a> > SERVICE & SUPPORT > Downloads > TROVIS-VIEW)		

**Table 2:** Direct attachment to Type 3277-5 (see section 5.3.1)

Designation		Order no.
Mounting parts	Standard version for actuators 120 cm <sup>2</sup> or smaller	1400-7452
	Version compatible with paint for actuators 120 cm <sup>2</sup> or smaller	1402-0940
Accessories for actuator	Old switchover plate for Type 3277-5xxxxxx.00 Actuator (old)	1400-6819
	New switchover plate for Type 3277-5xxxxxx.01 Actuator (new) <sup>1)</sup>	1400-6822
	New connecting plate for Type 3277-5xxxxxx.01 Actuator (new) <sup>1)</sup> , G 1/8 and 1/8 NPT	1400-6823
	Old connecting plate for Type 3277-5xxxxxx.00 Actuator (old): G 1/8	1400-6820
	Old connecting plate for Type 3277-5xxxxxx.00 (old): 1/8 NPT	1400-6821
Accessories for positioner	Connecting plate (6)	G 1/4 1/4 NPT
	Pressure gauge bracket (7)	G 1/4 1/4 NPT
	Pressure gauge mounting kit (8) up to max. 6 bar (output/supply)	Stainless steel/brass Stainless steel/stainless steel
		1402-0938 1402-0939

<sup>1)</sup> Only new switchover and connecting plates can be used with new actuators (Index 01). Old and new plates are not interchangeable.

## Design and principle of operation

**Table 3:** Direct attachment to Type 3277 (see section 5.3.2)

Mounting parts/accessories	Order no.
Standard version for actuators 175, 240, 350, 355, 700, 750 cm <sup>2</sup>	1400-7453
Version compatible with paint for actuators 175, 240, 350, 355, 700, 750 cm <sup>2</sup>	1402-0941
Connection block with seals and screw	G 1/4 1/4 NPT
Pressure gauge mounting kit up to max. 6 bar (output/supply)	Stainless steel/brass Stainless steel/stainless steel
Piping with screw fittings <sup>1)</sup>	Order no.
Actuator (175 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (175 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (240 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (240 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (350 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (350 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (355 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (355 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (700 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (700 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (750 cm <sup>2</sup> ), steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT
Actuator (750 cm <sup>2</sup> ), stainless steel	G 1/4/G 3/8 1/4 NPT/3/8 NPT

<sup>1)</sup> For "actuator stem retracts" fail-safe action  
with air purging of the top diaphragm chamber

**Table 4:** Attachment to NAMUR rib or attachment to rod-type yokes<sup>1)</sup> according to IEC 60534-6 (section 5.4)

Travel in mm	Lever	For actuator	Order no.
7.5	S	Type 3271-5 with 60/120 cm <sup>2</sup> on Type 3510 Micro-flow Valve	1402-0478
5 to 50	M <sup>2)</sup>	Actuators from other manufacturers and Type 3271 with 120 to 750 cm <sup>2</sup> effective areas	1400-7454
14 to 100	L	Actuators from other manufacturers and Type 3271 with 1000 and 1400-60 cm <sup>2</sup>	1400-7455
30 or 60	L	Type 3271, 1400-120 and 2800 cm <sup>2</sup> versions with 30/60 mm travel <sup>3)</sup>	1400-7466
		Mounting brackets for Emerson and Masoneilan linear actuators (in addition, a mounting kit according to IEC 60534-6 is required depending on the travel). See rows above.	1400-6771
		Valtek Type 25/50	1400-9554
40 to 200	XL	Actuators from other manufacturers and Type 3271 with 1400-120 and 2800 cm <sup>2</sup> and with 120 mm travel	1400-7456
Accessories			Order no.
Connecting plate			G 1/4 1400-7461
			1/4 NPT 1400-7462
Pressure gauge bracket			G 1/4 1400-7458
			1/4 NPT 1400-7459
Pressure gauge mounting kit up to max. 6 bar (output/supply)			Stainless steel/brass 1402-0938
			Stainless steel/stainless steel 1402-0939

1) 20 to 35 mm rod diameter

2) M lever is mounted on basic device (included in the scope of delivery)

3) In conjunction with Type 3273 Side-mounted Handwheel with 120 mm rated travel, additionally one bracket (0300-1162) and two countersunk screws (8330-0919) are required.

**Table 5:** Attachment according to VDI/VDE 3847-1 (see section 5.5)

Mounting parts	Order no.
VDI/VDE 3847 interface adapter	1402-0257
Connecting plate, including connection for air purging of actuator spring chamber	Aluminum ISO 228/1-G 1/4 1/4-18 NPT
	Stainless steel ISO 228/1-G 1/4 1/4-18 NPT
Mounting kit for attachment to SAMSON Type 3277 Actuator with 175 to 750 cm <sup>2</sup>	1402-0868
Mounting kit for attachment to SAMSON Type 3271 Actuator or third-party actuators	1402-0869
Travel pick-off for valve travel up to 100 mm	1402-0177
Travel pick-off for 100 to 200 mm valve travel (SAMSON Type 3271 Actuator only)	1402-0178

## Design and principle of operation

**Table 6:** Attachment according to VDI/VDE 3847-2 (see section 5.6)

Designation		Order no.
Mounting parts	Mounting block for PFEIFFER Type 31a (edition 2020+) Rotary Actuators with dummy plate for solenoid valve interface	1402-1645
	Dummy plate for solenoid valve interface (sold individually)	1402-1290
	Adapter bracket for Type 3730 (VDI/VDE 3847)	1402-0257
	Adapter bracket for Type 3730 and Type 3710 (DAP/PST)	1402-1590
Accessories for actuator	Shaft adapter AA1	1402-1617
	Shaft adapter AA2	1402-1616
	Shaft adapter AA4	1402-1888

**Table 7:** Attachment to rotary actuators (see section 5.8)

Mounting parts/accessories	Order no.
Attachment according to VDI/VDE 3845 (September 2010), actuator surface corresponds to fixing level 1	
Size AA1 to AA4, version with CrNiMo steel bracket	1400-7448
Size AA1 to AA4, heavy-duty version	1400-9244
Size AA5, heavy-duty version (e.g. Air Torque 10 000)	1400-9542
Bracket surface corresponds to fixing level 2, heavy-duty version	1400-9526
Attachment for rotary actuators with max. 180° opening angle, fixing level 2	1400-8815 and 1400-9837
Attachment to SAMSON Type 3278 with 160/320 cm <sup>2</sup> , CrNiMo steel bracket	1400-7614
Attachment to SAMSON Type 3278 with 160 cm <sup>2</sup> and to VETEC Type S160, Type R and Type M, heavy-duty version	1400-9245
Attachment to SAMSON Type 3278 with 320 cm <sup>2</sup> and to VETEC Type S320, heavy-duty version	1400-5891 and 1400-9526
Attachment to Camflex II	1400-9120
Accessories	
Connecting plate	G 1/4 1/4 NPT
Pressure gauge bracket	G 1/4 1/4 NPT
Pressure gauge mounting kit up to max. 6 bar (output/supply)	Stainless steel/brass Stainless steel/stainless steel
	1400-7461 1400-7462 1400-7458 1400-7459 1402-0938 1402-0939

**Table 8:** Attachment of external position sensor (see section 5.10)

Mounting parts/accessories		Order no.
Template for mounting position sensor on older mounting parts		1060-0784
Direct attachment	Mounting parts for actuator with 120 cm <sup>2</sup>	1400-7472
	Connecting plate (9, old) with Type 3277-5xxxxxx.00 Actuator	G 1/8 1/8 NPT
	Connecting plate (new) with Type 3277-5xxxxxx.01 Actuator (new) <sup>1)</sup>	1400-6823
	Mounting parts for actuators with 175, 240, 350, 355 and 750 cm <sup>2</sup>	1400-7471
NAMUR attachment	Mounting parts for attachment to NAMUR rib using L or XL lever	1400-7468
Attachment to Type 3510 Micro-flow Valve	Mounting parts for Type 3271 Actuator with 60 cm <sup>2</sup>	1400-7469
Attachment to rotary actuators	VDI/VDE 3845 (September 2010), see section 3.8.1 for details.  Actuator surface corresponds to fixing level 1	
	Size AA1 to AA4 with follower clamp and coupling wheel, version with CrNiMo steel bracket	1400-7473
	Size AA1 to AA4, heavy-duty version	1400-9384
	Size AA5, heavy-duty version (e.g. Air Torque 10 000)	1400-9992
	Bracket surface corresponds to fixing level 2, heavy-duty version	1400-9974
	SAMSON Type 3278 with 160 cm <sup>2</sup> and VETEC Type S160 and Type R, heavy-duty version	1400-9385
	SAMSON Type 3278 with 320 cm <sup>2</sup> and VETEC Type S320, heavy-duty version	1400-5891 and 1400-9974
Accessories for positioner	Connecting plate (6)	G 1/4 1/4 NPT
	Pressure gauge bracket (7)	G 1/4 1/4 NPT
	Pressure gauge mounting kit up to max. 6 bar (output/supply)	Stainless steel/brass Stainless steel/stainless steel
	Bracket to mount the positioner on a wall ( <b>Note:</b> The other fastening parts are to be provided at the site of installation as wall foundations vary from site to site).	1402-0938 1402-0939 0309-0184

<sup>1)</sup> Only new connecting plates can be used with new actuators (Index 01). Old and new plates are not interchangeable.

### 3.6.1 Travel tables

**i Note**

The M lever is included in the scope of delivery.

S, L, XL levers for attachment according to IEC 60534-6 (NAMUR) are available as accessories (see Table 4 on page 25). The XXL lever is available on request.

**Table 9:** Direct attachment to Type 3277-5 and Type 3277 Actuator

Actuator size [cm <sup>2</sup> ]	Rated travel [mm]	Adjustment range at positioner <sup>1)</sup> Travel [mm]	Required lever	Assigned pin position
120	7.5	5.0 to 25.0	M	25
120/175/240/350	15	7.0 to 35.0	M	35
355/700/750	30	10.0 to 50.0	M	50

<sup>1)</sup> The min./max. adjustment range is based on the NOM (nominal range) initialization mode

**Table 10:** Attachment according to IEC 60534-6 (NAMUR)

SAMSON valves with Type 3271 Actuator		Adjustment range at positioner Other control valves <sup>1)</sup>		Required lever	Assigned pin position
Actuator size [cm <sup>2</sup> ]	Rated travel [mm]	Min. travel [mm]	Max. travel [mm]		
60 and 120 with Type 3510 Valve	7.5	3.6	18.0	S	17
120	7.5	5.0	25.0	M	25
120/175/240/350	15	7.0	35.0	M	35
355/700/750	7.5	7.0	35.0	M	35
355/700/750	15 and 30	10.0	50.0	M	50
1000/1400/2800	30	14.0	70.0	L	70
	60	20.0	100.0	L	100
1400/2800	120	40.0	200.0	XL	200
See manufacturer's specifications	200	See manufacturer's specifications			300

<sup>1)</sup> The min./max. adjustment range is based on the NOM (nominal range) initialization mode

**Table 11:** Attachment to rotary actuators

Opening angle	Required lever	Assigned pin position
24 to 100°	M	90°

## 3.7 Technical data

**Table 12: Type 3730-5 Electropneumatic Positioner**

Type 3730-5 Positioner: the technical data for the explosion-protected devices may be restricted by the limits specified in the test certificates.	
Rated travel, adjustable	Direct attachment to Type 3277 Actuator: 3.6 to 30 mm Attachment according to IEC 60534-6 (NAMUR): 3.6 to 300 mm Attachment according to VDI/VDE 3847: 3.6 to 300 mm Attachment to rotary actuators (VDI/VDE 3845): 24 to 100° opening angle
Travel range, adjustable	Adjustable within the initialized travel/angle of rotation; travel can be restricted to 1/5 at the maximum
Bus connection	Fieldbus interface according to IEC 61158-2, bus-powered Physical Layer Class 113 (without explosion protection) and 111 (explosion-protected version) Field device according to FM 3610 entity, FISCO and FNICO
Fieldbus	Data transmission conforming to FOUNDATION™ fieldbus specification Communication Profile Class: 31 PS, 32 L Interoperability tested according to Interoperability Test Kit (ITK) 6.2.0
Communication	Execution times AO FB: 30 ms      DI FB: 20 ms      PID FB: 40 ms
Local	SAMSON SSP interface and serial interface adapter Software requirements: TROVIS-VIEW with database module 3730-5
Permissible operating voltage	9 to 32 V DC · Powered by bus line Observe the limits in the test certificate for explosion-protected versions.
Maximum operating current	15 mA
Additional current in case of error	0 mA
Supply air	1.4 to 7 bar (20 to 105 psi)
Air quality acc. to ISO 8573-1	Max. particle size and density: Class 4 · Oil content: Class 3 Moisture and water: Class 3 · Pressure dew point: Class 3 or at least 10 K below the lowest ambient temperature to be expected
Signal pressure (output)	0 bar up to the supply pressure · Can be limited to 1.4/2.4/3.7 bar ±0.2 bar by software
Characteristic	Linear/Equal percentage/Reverse equal percentage User-defined (over operating software and communication) Butterfly valve, rotary plug valve or segmented ball valve: Linear/equal percentage Deviation from characteristic ≤ 1 %
Hysteresis	≤0.3 %
Sensitivity	≤0.1 %
Direction of action	Reversible
Air consumption	Independent of supply air < 110 l <sub>n</sub> /h

## Design and principle of operation

Type 3730-5 Positioner: the technical data for the explosion-protected devices may be restricted by the limits specified in the test certificates.		
Air output capacity	Supply	At $\Delta p = 6$ bar: $8.5 \text{ m}_n^3/\text{h}$ · At $\Delta p = 1.4$ bar: $3.0 \text{ m}_n^3/\text{h} \cdot K_{V\max(20^\circ\text{C})} = 0.09$
	Exhaust	At $\Delta p = 6$ bar: $14.0 \text{ m}_n^3/\text{h}$ · At $\Delta p = 1.4$ bar: $4.5 \text{ m}_n^3/\text{h} \cdot K_{V\max(20^\circ\text{C})} = 0.15$
Permissible ambient temperature		-20 to +80 °C -45 to +80 °C -55 to +80 °C All versions With metal cable gland Special version for low temperatures with metal cable gland (Type 3730-5xxxxxxxxx0x02x0xx) The temperature limits for the explosion-protected devices may be further restricted by the limits specified in the test certificates.
<b>Influences</b>		
	Temperature	$\leq 0.15\% / 10 \text{ K}$
Influences	Supply air	None
	Effect of vibration	$\leq 0.25\%$ up to 2000 Hz and 4 g according to IEC 770
EMC	Complying with EN 61000-6-2, EN 61000-6-3, EN 61326-1 and NAMUR Recommendation NE 21	
Explosion protection	Refer to Table 14	
Electrical connections	One M20x1.5 cable gland for 6 to 12 mm clamping range · Second M20x1.5 threaded connection additionally exists · Screw terminals for 0.2 to 2.5 mm <sup>2</sup> wire cross-sections	
Degree of protection	IP 66/NEMA 4X	
Use in safety-instrumented systems (SIL)	Observing the requirements of IEC 61508, the systematic capability of the pilot valve for emergency venting as a component in safety-instrumented systems is given.	
Emergency venting at 0 V or over the optional solenoid valve	Use is possible on observing the requirements of IEC 61511 and the required hardware fault tolerance in safety-instrumented systems up to SIL 2 (single device/HFT = 0) and SIL 3 (redundant configuration/HFT = 1).	
<b>Binary input BI1</b>		
Input	0 to 30 V DC · Reverse polarity protection · Static destruction limit 40 V Current consumption 3.5 mA at 24 V, galvanic isolation	
Signal	Signal '1' at $U_e > 5 \text{ V}$ · Signal '0' at $U_e < 3 \text{ V}$	
<b>Materials</b>		
Housing	Die-cast aluminum EN AC-AlSi12(Fe) (EN AC-44300) acc. to DIN EN 1706 chromated and powder paint coated · Special version: stainless steel 1.4408	
External parts	Stainless steel 1.4404/316L	
Cable gland	M20x1.5, black polyamide	
Weight	Approx. 1.0 kg · Special version in stainless steel: 2.2 kg	
Conformity	 ·  ·	

**Table 13:** Optional additional functions

<b>Binary input BI2</b> for floating contact	
Switching input	R < 100 Ω · Contact load 100 mA · Static destruction limit 20 V/5.8 mA Galvanic isolation
<b>Solenoid valve</b> · Approval acc. to IEC 61508/SIL	
Input	24 V DC · Reverse polarity protection · Static destruction limit 40 V Current consumption $I = \frac{U - 5.7 \text{ V}}{3840 \Omega}$ (corresponding to 4.8 mA at 24 V/114 mW)
Signal '0' (no response)	<12 V (emergency venting at 0 V)
Signal '1' (response)	> 19 V
Service life	>5 × 10 <sup>6</sup> switching cycles
K <sub>v</sub> coefficient	0.15
<b>Inductive limit switch by Pepperl+Fuchs</b>	For connection to switching amplifier acc. to EN 60947-5-6
SJ2-SN proximity switch	Measuring plate not detected: ≥3 mA · Measuring plate detected: ≤1 mA
<b>External position sensor</b>	
Travel	Same as positioner
Cable	10 m · Flexible and durable · With M12x1 connector · Flame-retardant acc. to VDE 0472 · Resistant to oils, lubricants and coolants as well as other aggressive media
Permissible ambient temperature	-60 to +105 °C with a fixed connection between positioner and position sensor · The limits in the test certificate additionally apply for explosion-protected versions.
Immunity to vibration	Up to 10 g in the range of 10 to 2000 Hz
Degree of protection	IP 67
<b>Leakage sensor</b> · Suitable for operation in hazardous areas	
Temperature range	-40 to +130 °C
Tightening torque	20 ±5 Nm

## Design and principle of operation

**Table 14: Summary of explosion protection approvals**


		Certification			Type of protection	
Type 3730	-51		EU type examination certificate	Number	PTB 04 ATEX 2109	
				Date	2017-05-11	
	-55		EU type examination certificate	Number	PTB 04 ATEX 2109	
				Date	2017-05-11	
	-58		Statement of conformity	Number	PTB 05 ATEX 2010 X	
				Date	2017-06-22	
	-51	IECEx		Number	IECEEx PTB 06.0054	
				Date	2006-11-02	
	-55	IECEx		Number	IECEEx PTB 06.0054	
				Date	2006-11-02	
	-58	IECEx		Number	IECEEx PTB 06.0054	
				Date	2006-11-02	
	-5	CCoE		Number	A P HQ MH 104 7593	
				Date	2023-05-25	
				Valid until	2027-12-21	
	-51	CCC Ex		Number	2020322307002425	
				Date	2023-03-28	
				Valid until	2025-09-17	
	-58	CCC Ex		Number	2020322307002425	
				Date	2023-03-28	
				Valid until	2025-09-17	
	-53	CSA		Number	1675804	
				Date	2017-05-23	
	-51	EAC		Number	RU C-DE.HA65.B.00510/20	
				Date	2020-03-18	
				Valid until	2025-03-18	
	-53	FM		Number	3023605	
				Date	2006-03-15	

		Certification			Type of protection
Type 3730	-51	INMETRO	Number	IEx 22.0025X	Ex ia IIC T4...T6 Gb Ex ia IIIC T80 °C Db
			Date	2022-11-22	
			Valid until	2028-11-21	
	-58	INMETRO	Number	IEx 22.0025X	Ex ec IIC T4...T6 Gc Ex tc IIIC T80 °C Dc
			Date	2022-11-22	
			Valid until	2028-11-21	
	-51	KCS-Korea	Number	11-KB4BO-0225	Ex ia IIC T6/T5/T4
			Date	2011-11-10	
			Valid until	2024-11-10	
	-51	TR CMU	Number	ZETC/35/2021	II 2G Ex ia IIC T6...T4 Gb II 2D Ex ia IIIC T80 °C Db
			Date	2021-07-26	
			Valid until	2024-07-25	
	-55	TR CMU	Number	ZETC/35/2021	II 2D Ex tb IIIC T80 °C Db
			Date	2021-07-26	
			Valid until	2024-07-25	
	-58	TR CMU	Number	ZETC/35/2021	II 3G Ex ic nA IIC T6 Gc II 3D Ex tc IIIC T80 °C Dc IP66
			Date	2021-07-26	
			Valid until	2024-07-25	
	-55	UKEX	Number	FM21UKEX0202X	II 2G Ex ia IIC T4/T6 Gb II 2D Ex ia IIIC T80°C Db
			Date	2022-10-20	
	-51	UKEX	Number	FM21UKEX0202X	II 2D Ex tb IIIC T80°C Db
			Date	2022-10-20	
	-58	UKEX	Number	FM21UKEX0203X	II 3G Ex ec IIC T* Gc II 3D Ex tc IIIC T80°C Dc
			Date	2023-01-24	




### 3.8 Dimensions in mm

#### Attachment according to IEC 60534-6




#### Direct attachment




## Design and principle of operation


**Attachment according to VDI/  
VDE 3847-1 onto Type 3277  
Actuator**




**Attachment according to VDI/  
VDE 3847-1 to a NAMUR rib**



**Attachment according to VDI/VDE 3847-2  
with single-acting actuator**




**Attachment according to VDI/VDE 3847-2  
with double-acting actuator**




## Design and principle of operation

### Attachment to rotary actuators according to VDI/VDE 3845

#### Heavy-duty version



#### Light version




- <sup>1)</sup> Reversing amplifiers  
– Type 3710 (see drawing of heavy-duty version for dimensions)  
– 1079-1118/1079-1119, no longer available  
(see drawing of light version for dimensions)

**Lever**

Lever	x	y	z
S	17 mm	25 mm	33 mm
M	25 mm	50 mm	66 mm
L	70 mm	100 mm	116 mm
XL	100 mm	200 mm	216 mm
XXL	200 mm	300 mm	316 mm

### 3.8.1 Fixing levels according to VDI/VDE 3845 (September 2010)





## 4 Measures for preparation

After receiving the shipment, proceed as follows:

1. Check the scope of delivery. Compare the shipment received with the delivery note.
2. Check the shipment for transportation damage. Report any transportation damage.

### 4.1 Unpacking

#### ! NOTICE

*Risk of positioner damage due to foreign particles entering it.*

*Do not remove the packaging and protective film/protective caps until immediately before mounting and start-up.*

1. Remove the packaging from the positioner.
2. Dispose of the packaging in accordance with the valid regulations.

### 4.2 Transporting

- Protect the positioner against external influences (e.g. impact).
- Protect the positioner against moisture and dirt.
- Observe transport temperature depending on the permissible ambient temperature (see technical data in section 3.7).

### 4.3 Storage

#### ! NOTICE

*Risk of positioner damage due to improper storage.*

- Observe storage instructions.
- Contact SAMSON in case of different storage conditions or long storage periods.

#### Storage instructions

- Protect the positioner against external influences (e.g. impact, shocks, vibration).
- Do not damage the corrosion protection (coating).
- Protect the positioner against moisture and dirt. In damp spaces, prevent condensation. If necessary, use a drying agent or heating.
- Observe storage temperature depending on the permissible ambient temperature (see technical data in section 3.7).
- Store positioner with closed cover.
- Seal the pneumatic and electrical connections.



## 5 Mounting and start-up

### ! NOTICE

*Risk of malfunction due to incorrect mounting parts/accessories.*

*Only use the mounting parts and accessories listed in these mounting and operating instructions to mount and install the positioner. Pay attention to the type of attachment.*

### ! NOTICE

*Risk of malfunction due to incorrect sequence of mounting, installation and start-up. Observe the prescribed sequence.*

→ Sequence:

**1. Remove the protective caps from the pneumatic connections.**

**2. Mount the positioner on the valve.**

→ Section 5.3 onward

**3. Perform pneumatic installation.**

→ Section 5.15 onward

**4. Perform electrical installation.**

→ Section 5.16 onward

**5. Perform settings.**

→ Section 7 onward

## 5.1 Mounting position

### ! NOTICE

*Risk of damage to the positioner due to incorrect mounting position.*

– Do not mount the positioner with the back of the device facing upward.

– Do not seal or restrict the vent opening when the device is installed on site.

→ Observe mounting position (see Fig. 3).

→ Do not seal or restrict the vent opening (see Fig. 2) when the device is installed on site.

## 5.2 Lever and pin position

The positioner is adapted to the actuator and to the rated travel by the lever on the back of the positioner and the pin inserted into the lever.

The travel tables on page 28 show the maximum adjustment range at the positioner. The travel that can be implemented at the valve is additionally restricted by the selected fail-safe position and the required compression of the actuator springs.

The positioner is equipped with the M lever (pin position 35) as standard (see Fig. 4).

### i Note

*The M lever is included in the scope of delivery.*

*S, L, XL levers are available as accessories.*

*The XXL lever is available on request.*


If a pin position other than position 35 with the standard M lever is required or an L or XL lever size is required, proceed as follows (see Fig. 5):

1. Fasten the follower pin (2) in the assigned lever hole (pin position as speci-


## **Mounting and start-up**

fied in the travel tables on page 28).  
Only use the longer follower pin included  
in the mounting kit.


2. Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1).




**Fig. 2:** Vent opening  
(back of the positioner)



**Fig. 3:** Permissible mounting positions



**Fig. 4:** M lever with pin position 35



**Fig. 5:** Mounting the lever and follower pin

### 5.3 Direct attachment

#### 5.3.1 Type 3277-5 Actuator

- Required mounting parts and accessories: Table 2 on page 23.
- Observe travel tables on page 28.

#### Actuator with 120 cm<sup>2</sup> (see Fig. 6)

Depending on the type of positioner attachment, the signal pressure is routed either left or right of the yoke through a hole to the actuator diaphragm. Depending on the fail-safe action of the actuator "actuator stem extends" or "actuator stem retracts" (valve closes or opens upon supply air failure), the switchover plate (9) must first be attached to the actuator yoke. Align the switchover plate with the corresponding symbol for left or right attachment according to the marking (view looking onto the switchover plate).

1. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly.
2. Remove screw plug (4) on the back of the positioner and seal the signal pressure output (38) on the connecting plate (6) or on the pressure gauge bracket (7) with the stopper (5) included in the accessories.
3. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.
4. Mount cover plate (10) with narrow side of the cut-out (Fig. 6, on the left) pointing towards the signal pressure connection.


Make sure that the gasket (14) points towards the actuator yoke.

5. **15 mm travel:** Keep the follower pin (2) on the M lever (1) on the back of the positioner in the pin position 35 (delivered state).  
**7.5 mm travel:** Remove the follower pin (2) from the pin position 35, reposition it in the hole for pin position 25 and screw tight.
6. Insert molded seal (15) into the groove of the positioner housing and insert the seal (10.1) on the back of the housing.
7. Place positioner on the cover plate (10) in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton. The lever (1) must rest on the follower clamp with spring force. Fasten the positioner on the cover plate (10) using the two fastening screws.

#### **i Note**

The following applies to all types of attachment except for direct attachment to Type 3277-5: the signal pressure output at the back must be sealed by the screw plug (4, order no. 0180-1436) and the associated O-ring (order no. 0520-0412) (delivered state, parts included in the scope of delivery).

8. Mount cover (11) on the other side. Make sure that the vent plug is located at the bottom when the control valve is in-



stalled to allow any condensed water that collects to drain off.

### 5.3.2 Type 3277 Actuator

- Required mounting parts and accessories: Table 3 on page 24.
- Observe travel tables on page 28.

#### Actuators with 175 to 750 cm<sup>2</sup> effective areas (see Fig. 7)

Mount the positioner on the yoke. The signal pressure is routed to the actuator over the connection block (12), for actuators with fail-safe action "actuator stem extends" internally through a hole in the valve yoke and for "actuator stem retracts" through an external pipe.

1. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.
2. Mount cover plate (10) with narrow side of the cut-out (Fig. 7, on the left) pointing towards the signal pressure connection. Make sure that the gasket (14) points towards the actuator yoke.
3. For actuators with 355, 700 or 750 cm<sup>2</sup>, remove the follower pin (2) on the M lever (1) on the back of the positioner from pin position **35**, reposition it in the hole for pin position **50** and screw tight. For actuators 175, 240 and 350 cm<sup>2</sup> with 15 mm travel, keep the follower pin (2) in pin position **35**.
4. Insert molded seal (15) into the groove of the positioner housing.

5. Place positioner on the cover plate in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton. The lever (1) must rest on the follower clamp with spring force. Fasten the positioner on the cover plate (10) using the two fastening screws.
6. Make sure that the tip of the gasket (16) projecting from the side of the connection block is positioned to match the actuator symbol for the actuator's fail-safe action "actuator stem extends" or "actuator stem retracts". If this is not the case, unscrew the three fastening screws and lift off the cover. Turn the gasket (16) by 180° and re-insert it.  
The old connection block version (Fig. 7, bottom) requires the switch plate (13) to be turned to align the actuator symbol with the arrow marking.
7. Place the connection block (12) with the associated seals against the positioner and the actuator yoke and fasten using the screw (12.1). For actuators with fail-safe action "actuator stem retracts", additionally remove the stopper (12.2) and mount the external signal pressure pipe.
8. Mount cover (11) on the other side. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.




Fig. 7: Direct attachment – Signal pressure connection for Type 3277 Actuator with 175 to 750 cm<sup>2</sup>

### 5.4 Attachment according to IEC 60534-6

- Required mounting parts and accessories: Table 4 on page 25.
- Observe travel tables on page 28.
- Refer to Fig. 8

The positioner is attached to the control valve using a NAMUR bracket (10).

1. Screw the two bolts (14) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (14.1) for fastening.

#### Actuator sizes 2800 cm<sup>2</sup> and 1400 cm<sup>2</sup> with 120 mm travel:

- For a travel of 60 mm or smaller, screw the longer follower plate (3.1) directly to the stem connector (9).
  - For a travel exceeding 60 mm, mount the bracket (16) first and then the follower plate (3) to the bracket together with the bolts (14) and screws (14.1).
2. Mount NAMUR bracket (10) to the control valve as follows:
    - For **attachment to the NAMUR rib**, use an M8 screw (11) and toothed lock washer directly in the yoke hole.
    - For attachment to **valves with rod-type yokes**, use two U-bolts (15) around the yoke. Align the NAMUR bracket (10) according to the embossed scale so that the follower plate (3) is shifted by half the angle range to the NAMUR bracket (the slot of the follower plate is centrally

aligned with the NAMUR bracket at mid valve travel).

3. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly.
4. Select required lever size (1) M, L or XL and pin position according to the actuator size and valve travel listed in the travel table on page 28.

Should a pin position other than position 35 with the standard **M** lever be required or an **L** or **XL** lever size be required, proceed as follows:

- Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel table). Only use the longer follower pin (2) included in the mounting kit.
  - Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1). Move lever once all the way as far as it will go in both directions.
5. Place positioner on the NAMUR bracket in such a manner that the follower pin (2) rests in the slot of the follower plate (3, 3.1). Adjust the lever (1) correspondingly.  
Screw the positioner to the NAMUR bracket using its two fastening screws.




Fig. 8: Attachment according to IEC 60534-6 (NAMUR)

### 5.5 Attachment according to VDI/VDE 3847-1

The Type 3730-5xxx0xxxx0x0060xx and Type 3730-5xxxxxxxx0xx0700 Positioners with air purging of the actuator's spring chamber can be attached according to VDI/VDE 3847.

Type 3730-5xxx0xxxx0x0000xx Positioner without air purging of the actuator's spring chamber can be attached according to VDI/VDE 3847.

This type of attachment allows the positioner to be replaced quickly while the process is running by blocking the air in the actuator.

The signal pressure can be blocked in the actuator by unscrewing the red retaining screw (20) and turning the air blocker (19) on the bottom of the adapter block.

#### Attachment to Type 3277 Actuator (see Fig. 9)

→ Required mounting parts and accessories: Table 5 on page 25.

Mount the positioner on the yoke. The signal pressure is routed to the actuator over the connecting plate (12), for actuators with fail-safe action "actuator stem extends" internally through a bore in the valve yoke and for "actuator stem retracts" through external piping.

Only the Y1 port is required for positioner attachment. The Y2 port can be used for air purging of the spring chamber.

1. Place follower clamp (3) on the actuator stem, align it and screw tight so that the

mounting screw is located in the groove of the actuator stem.

2. Place the adapter bracket (6) on the positioner and mount using the screws (6.1). Make sure that the seals are correctly seated. For positioners **with air purging**, remove the stopper (5) before mounting the positioner. For positioners **without air purging**, replace the screw plug (4) with a vent plug.
3. For actuators with 355, 700 or 750 cm<sup>2</sup>, remove the follower pin (2) on the M lever (1) on the back of the positioner from pin position 35, reposition it in the hole for pin position 50 and screw tight. For actuators 175, 240 and 350 cm<sup>2</sup> with 15 mm travel, keep the follower pin (2) in pin position 35.
4. Insert the molded seal (6.2) in the groove of the adapter bracket (6).
5. Insert the molded seal (17.1) into the turnboard (17) and mount the turnboard to the adapter block (13) using the screws (17.2).
6. Mount the blank plate (18) to the turnboard (17) using the screws (18.1). Make sure that the seals are correctly seated.

#### **i Note**

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted (► AB 11).





Fig. 9: Attachment according to VDI/VDE 3847-1 onto Type 3277 Actuator

## Mounting and start-up

7. Insert the screws (13.1) through the middle holes of the adapter block (13).
8. Place the connecting plate (12) together with the seal (12.1) onto the screws (13.1) corresponding to the fail-safe action "actuator stem extends" or "actuator stem retracts". The fail-safe action that applies is determined by aligning the groove of the adapter block (13) with the groove of the connecting plate (12) (Fig. 10).



**Fig. 10: Fail-safe action**

Place positioner on the adapter block (13) in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton.

The lever (1) must rest on the follower clamp with spring force.

Fasten the positioner to the adapter block (13) using the two fastening screws (6.3). Make sure the molded seal (6.2) is properly seated.

12. Mount cover (11) on the other side to the yoke. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.

9. Mount the adapter block (13) together with the connecting plate (12) to the actuator using the screws (13.1).

10. Insert the vent plug (11.1) into the **Exh.** connection.

11. For fail-safe action "actuator stem extends", seal the Y1 port with a blanking plug.

For fail-safe action "actuator stem retracts", connect the Y1 port to the signal pressure connection of the actuator.

### Attachment to NAMUR rib (see Fig. 11)

- Required mounting parts and accessories: Table 5 on page 25.
- Observe travel tables on page 28.

**1. Series 240 Valves, actuator size up to 1400-60 cm<sup>2</sup>:** Screw the two bolts (14) to the bracket of the stem connector or directly to the stem connector (depending on the version), place the follower plate (3) on top and use the screws (14.1) to fasten it.

#### Type 3251 Valve, 350 to 2800 cm<sup>2</sup>:

Screw the longer follower plate (3.1) to the bracket of the stem connector or directly to the stem connector (depending on the version).

#### Type 3254 Valve, 1400-120 to 2800

cm<sup>2</sup>: Screw the two bolts (14) to the bracket (16). Fasten the bracket (16) onto the stem connector, place the follower plate (3) on top and use the screws (14.1) to fasten it.

Mount the positioner on the NAMUR rib as shown in Fig. 11.

**2. For attachment to the NAMUR rib,** fasten the NAMUR connection block (10) directly into the existing yoke bore using the screw and toothed lock washer (11). Align the marking on the NAMUR valve connection (on the side marked '1') to 50 % travel.

For attachment to **valves with rod-type yokes** using the formed plate (15), which is placed around the yoke: screw the four studs into the NAMUR connection block (10). Place the NAMUR connection block

on the rod and position the formed plate (15) on the opposite side. Use the nuts and toothed lock washers to fasten the formed plate onto the studs. Align the marking on the NAMUR valve connection (on the side marked '1') to 50 % travel.

3. Place the adapter bracket (6) on the positioner and mount using the screws (6.1). Make sure that the seals are correctly seated. For positioners **with air purging**, remove the stopper (5) before mounting the positioner. For positioners **without air purging**, replace the screw plug (4) with a vent plug.
4. Select required lever size (1) **M, L or XL** and pin position according to the actuator size and valve travel listed in the travel table on page 28.

Should a pin position other than position 35 with the standard M lever be required or an L or XL lever size be required, proceed as follows:

- Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel table). Only use the longer follower pin (2) included in the mounting kit.
- Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1). Move lever once all the way as far as it will go in both directions.
- 5. Insert the molded seal (6.2) in the groove of the adapter bracket.

6. Insert the molded seal (17.1) into the turnboard (17) and mount the turnboard to the adapter block (13) using the screws (17.2).
7. Mount the blank plate (18) to the turnboard using the screws (18.1). Make sure that the seals are correctly seated.

### Note

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted (► AB 11).

8. Fasten the adapter block (13) to the NAMUR connection block using the screws (13.1).
9. Insert the vent plug into the Exh. connection.
10. Place the positioner on the adapter block (13) in such a manner that the follower pin (2) rests on the top of the follower plate (3, 3.1). Adjust the lever (1) correspondingly.  
Fasten the positioner to the adapter block (13) using the two fastening screws (6.3). Make sure the molded seal (6.2) is properly seated.
11. For single-acting actuators without air purging, connect the Y1 port of the adapter block to the signal pressure con-

nection of the actuator. Seal the Y2 port with a blanking plug.

For **double-acting actuators and actuators with air purging**, connect the Y2 port of the adapter block to the signal pressure connection of the second actuator chamber or spring chamber of the actuator.


## 5.6 Attachment according to VDI/VDE 3847-2

Attachment according to VDI/VDE 3847-2 for PFEIFFER SRP (single-acting) and DAP (double-acting) rotary actuators in sizes 60 to 1200 with NAMUR interface and air purging of the actuator's spring chamber allows the direct attachment of the positioner without additional piping.

Additionally, the positioner can be replaced quickly while the process is running by blocking the air in single-acting actuators.

### Procedure to block the actuator in place (see Fig. 12):

1. Unscrew the red retaining screw (1).
2. Turn the air blocker (2) on the bottom of the adapter block according to the inscription.



### 5.6.1 Version for single-acting actuator

#### Mounting onto a PFEIFFER Type 31a (edition 2020+) SRP Rotary Actuator

→ Refer to Fig. 14.

1. Fasten the adapter block (1) to the actuator's NAMUR interface using the four fastening screws (2).
- Make sure that the seals are correctly seated.
2. Mount the follower wheel (3) onto the actuator shaft. Use the matching shaft adapter (see Table 6 on page 26).
3. Place the adapter bracket (4) onto the adapter block (1) and fasten it using the fastening screws (5).
- Make sure that the seals are correctly seated.
4. Insert and fasten the follower pin in the 90° position on the positioner's lever (see Fig. 13). Only use the longer follower pin included in the mounting kit.
5. Align the positioner on the adapter bracket (1) in such a way that the follower pin engages into the actuator's follower wheel (3).
6. Fasten the positioner onto the adapter bracket (4) using the fastening screws (6).
- Make sure that the seals are correctly seated.




Fig. 12: Adapter block for attachment according to VDI/VDE 3847-2




Fig. 13: Follower pin in 90° position




Fig. 14: Mounting on a single-acting actuator

### 5.6.2 Version for double-acting actuator

A reversing amplifier must be additionally mounted for applications with double-acting (DAP) actuators or applications with single-acting (SAP) actuators that include partial stroke testing.

In this case, a special adapter bracket (4) is required for mounting.

→ Refer to Fig. 16.

1. Fasten the adapter block (1) to the actuator's NAMUR interface using the four fastening screws (2).
- Make sure that the seals are correctly seated.
2. Mount the follower wheel (3) onto the actuator shaft. Use the matching adapter (see Table 6 on page 26).
3. Place the adapter bracket (4) onto the adapter block (1) and fasten it using the fastening screws (5).
- Make sure that the seals are correctly seated.
4. Insert and fasten the follower pin into the 90° position on the positioner's lever (see Fig. 13 on page 58).
5. Align the positioner on the adapter bracket (1) in such a way that the follower pin engages into the actuator's follower wheel (3).
6. Fasten the positioner onto the adapter bracket (4) using the fastening screws (6).
7. Mount the Type 3710 Reversing Amplifier (7) together with the two guide bush-

ings (8) and terminal plate (9) onto the adapter bracket using the associated fastening screws (10).

- Make sure that the seals are correctly seated.
8. Remove the vent plug at the adapter block and seal the opening with the G 1/4 screw plug.
  9. Mount the turnboard marked '**Doppel**' for double-acting actuators or the turnboard marked '**PST**' for single-acting actuators with partial stroke testing. See Fig. 15.
  - Make sure that the seals are correctly seated.





Fig. 15: Mounting the turnboard



**Fig. 16:** Mounting on a double-acting actuator or single-acting actuator with partial stroke testing

## Mounting and start-up

### Intermediate plate for AA4 interface

→ Refer to Fig. 17.


An intermediate plate (11) must be mounted between the adapter block and adapter bracket for PFEIFFER SRP and DAP rotary actuators in sizes 900 and 1200 with AA4 interface. This plate is included in the accessories for the shaft adapter AA4 (see Table 6 on page 26).

### Mounting a solenoid valve

→ Refer to Fig. 18.

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted. Further information can be found in the document ► AB 11 (Accessories for Solenoid Valves).

Version for single-acting actuator:



11 Intermediate plate

Version for double-acting actuator:





Fig. 17: Intermediate plate for actuators in sizes 900 and 1200 for AA4 interface



**Fig. 18:** Mounting a solenoid valve

### 5.7 Attachment to Type 3510 Micro-flow Valve

- Refer to Fig. 19
  - Required mounting parts and accessories: Table 4 on page 25.
  - Observe travel tables on page 28.
- The positioner is attached to the valve yoke using a bracket.
1. Fasten the bracket (9.1) to the stem connector.
  2. Screw the two bolts (9.2) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (9.3) for fastening.
  3. Mount the travel indication scale (accessories) to the outer side of the yoke using the hex screws (12.1), ensuring that the scale is aligned with the stem connector.
  4. Fasten the hex bar (11) onto the outer side of yoke by screwing the M8 screws (11.1) directly into the holes on the yoke.
  5. Fasten the bracket (10) to the hex bar using the hex screw (10.1), washer and tooth lock washer.
  6. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals are seated properly.
  7. Unscrew the standard M lever (1) including follower pin (2) from the positioner shaft.
  8. Take the S lever (1) and screw the follower pin (2) in the hole for pin position 17.

9. Place the S lever on the positioner shaft and screw tight using the disk spring (1.2) and nut (1.1).  
Move lever once all the way as far as it will go in both directions.
10. Place positioner on the bracket (10) in such a manner that the follower pin slides into the groove of the follower pin (3). Adjust the lever (1) correspondingly. Screw the positioner to the bracket (10) using both its screws.

### 5.8 Attachment to rotary actuators

- Refer to Fig. 21
- Required mounting parts and accessories: Table 7 on page 26.
- Observe travel tables on page 28.

The positioner is mounted to the rotary actuator using two pairs of brackets.

Prior to attaching the positioner to the SAMSON Type 3278 Rotary Actuator, mount the associated adapter (5) to the free end of the rotary actuator shaft.

#### **i Note**

*On attaching the positioner as described below, it is imperative that the actuator's direction of rotation is observed.*

1. Place follower clamp (3) on the slotted actuator shaft or adapter (5).




Fig. 19: Attachment to Type 3510 Micro-flow Valve

## Mounting and start-up

2. Place coupling wheel (4) with flat side facing the actuator on the follower clamp (3). Refer to Fig. 22 to align slot so that it matches the direction of rotation when the valve is in its closed position.
3. Fasten the coupling wheel (4) and follower clamp (3) tightly onto the actuator shaft using screw (4.1) and disk spring (4.2).
4. Fasten the bottom pair of brackets (10.1) with the bends pointing either facing to the inside or to the outside (depending on the actuator size) onto the actuator housing. Position the top pair of brackets (10) and fasten.
5. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals are seated properly. Double-acting springless rotary actuators require the use of a reversing amplifier on the connection side of the positioner housing (see section 5.9).
6. Unscrew the standard follower pin (2) from the positioner's M lever (1). Use the metal follower pin ( $\varnothing$  5 mm) included in the mounting kit and screw tight into the hole for pin position  $90^\circ$ .
7. Place positioner on the top bracket (10) and fasten tight. Taking the actuator's direction of rotation into account, adjust lever (1) so that it engages in the slot of the coupling wheel (4) with its follower pin (Fig. 22). It must be guaranteed that the lever (1) is parallel to the long side of the positioner when the actuator is at half its angle of rotation.
8. Stick the scale plate (4.3) on the coupling wheel so that the arrow tip indicates the closed position and it can be easily read when the valve is installed.




Fig. 20: Mounting the coupling wheel on Type 3278


### 5.8.1 Heavy-duty version

- ➔ Refer to Fig. 23
- ➔ Required mounting parts and accessories: Table 7 on page 26.

Both mounting kits contain all the necessary mounting parts. The parts for the actuator size used must be selected from the mounting kit.

Prepare actuator and mount possibly required adapter supplied by the actuator manufacturer.

1. Mount the housing (10) onto the rotary actuator. In case of VDI/VDE attachment,




## Mounting and start-up

place spacers (11) underneath, if necessary.

2. For **SAMSON Type 3278 and VETEC S160 Rotary Actuators**, fasten the adapter (5) onto the free end of the shaft and for **VETEC R Actuator**, place on the adapter (5.1). For **Type 3278, VETEC S160 and VETEC R Actuators**, place on the adapter (3). or **VDI/VDE version**, only use the adapter when it is required due to the actuator size.
3. Stick adhesive label (4.3) onto the coupling in such a manner that the yellow part of the sticker is visible in the window of the housing when the valve is OPEN. Adhesive labels with explanatory symbols are enclosed and can be stuck on the enclosure, if required.

4. Fasten coupling wheel (4) on the slotted actuator shaft or adapter (3) using screw (4.1) and disk spring (4.2).
5. Unscrew the standard follower pin (2) from the positioner's M lever (1). Attach the follower pin ( $\varnothing 5$  mm) included in the mounting kit to pin position  $90^\circ$ .
6. Mount connecting plate (6) for required  $G \frac{1}{4}$  connecting thread or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly. Double-acting springless rotary actuators require the use of a reversing amplifier on the connection side of the positioner housing (see section 5.9).
7. For actuators with a volume of less than  $300 \text{ cm}^3$ , screw the screw restriction (order no. 1400-6964) into the signal pressure output of the positioner (or the output of the pressure gauge bracket or connecting plate).
8. Place positioner on housing (10) and screw it tight. Taking the actuator's direction of rotation into account, adjust lever (1) so that it engages in the correct slot with its follower pin (Fig. 22).



**Fig. 22:** Direction of rotation




Fig. 23: Attachment to rotary actuators (heavy-duty version)

### 5.9 Reversing amplifier for double-acting actuators

For the use with double-acting actuators, the positioner must be fitted with a reversing amplifier:

- SAMSON Type 3710 Reversing Amplifier,  
▶ EB 8392
- If a different reversing amplifier (item no. 1079-1118 or 1079-1119) is used, mount it as described in section 5.9.1.

#### The following applies to all reversing amplifiers:

The signal pressure of the positioner is supplied at the output 1 of the reversing amplifier. An opposing pressure, which equals the required supply pressure (Z) when added to the pressure at output 1, is applied at output 2.

The following relationship applies:

**output 1 + output 2 = Supply pressure (Z).**

Connect output 1 to the signal pressure connection on the actuator that causes the valve to open when the pressure rises.

Connect output 2 to the signal pressure connection on the actuator that causes the valve to close when the pressure rises.

- Set slide switch on positioner to AIR TO OPEN.

#### i Note

How the outputs are marked depends on the reversing amplifier used:

– **Type 3710:** Output 1/2 =  $Y_1/Y_2$

– **1079-1118 and 1079-1119:**

Output 1/2 =  $A_1/A_2$

### 5.9.1 Reversing amplifier (1079-1118 or 1079-1119)

→ Refer to Fig. 24

1. Mount the connecting plate (6) from the accessories in Table 6 to the positioner. Make sure that both O-rings (6.1) are seated correctly.
2. Thread the special nuts (1.3) from the accessories of the reversing amplifier into the boreholes of the connecting plate.
3. Insert the gasket (1.2) into the recess of the reversing amplifier and slide both the hollowed special screws (1.1) into the connecting boreholes **A<sub>1</sub>** and **Z**.
4. Place the reversing amplifier onto the connecting plate (6) and screw tight using both the special screws (1.1).
5. Use a screwdriver (8 mm wide) to screw the enclosed filters (1.6) into the connection boreholes **A<sub>1</sub>** and **Z**.

#### ! NOTICE


Air can escape uncontrolled from the signal pressure connection.

Do not unscrew the sealing plug (1.5) out of the reversing amplifier.

#### i Note

The rubber seal (1.4) is not required and can be removed when the sealing plug is used.

6. After initialization, set Code 16 (Pressure limit) to No.



### Pressure gauge attachment

The mounting sequence shown in Fig. 24 remains unchanged. Screw a pressure gauge bracket onto the connections **A<sub>1</sub>** and **Z**.

Pressure gauge bracket	G 1/4	1400-7106
	1/4 NPT	1400-7107

Pressure gauges for supply air **Z** and output **A<sub>1</sub>** as listed in Table 8 to Table 9.

### 5.10 Attachment of external position sensor



**Fig. 25:** Positioner unit with sensor mounted on a micro-flow valve

- Required mounting parts and accessories: Table 8 on page 27.

In the positioner version with an external position sensor, the sensor located in a separate housing is attached over a plate or bracket to the control valve. The travel pick-off corresponds to that of a standard device. The positioner can be mounted as required to a wall or a pipe.

**For the pneumatic connection** either a connecting plate (6) or a pressure gauge bracket (7) must be fixed to the housing, depending on the accessory chosen. Make sure the seals (6.1) are correctly inserted (see Fig. 9, bottom right).

**For the electrical connection** a 10 meter connecting lead with M12x1 connectors is included in the scope of delivery.

**i Note**

- In addition, the instructions in sections 5.15 and 5.16 apply for the pneumatic and electrical connection.
- Since 2009, the back of the position sensor (20) is fitted with two pins acting as mechanical stops for the lever (1). If this position sensor is mounted using old mounting parts, two corresponding Ø 8 mm holes must be drilled into the mounting plate/bracket (21). A template is available for this purpose. See Table 8.

### 5.10.1 Mounting the position sensor with direct attachment

#### Type 3277-5 Actuator with 120 cm<sup>2</sup> (Fig. 6)

The signal pressure from the positioner is routed over the signal pressure connection of the connecting plate (9, Fig. 26 left) to the actuator diaphragm chamber. To proceed, first screw the connecting plate (9) included in the accessories onto the actuator yoke.

- Turn the connecting plate (9) so that the correct symbol for the fail-safe action "actuator stem extends" or "actuator stem retracts" is aligned with the marking (Fig. 27, below).
- Make absolutely sure that the gasket for the connecting plate (9) is correctly inserted.
- The connecting plate has threaded holes with NPT and G threads. Seal the threaded connection that is not used with the rubber seal and square plug.

#### Type 3277 Actuator with 175 to 750 cm<sup>2</sup>:

The signal pressure is routed to the connection at the side of the actuator yoke for the version with fail-safe action "actuator stem extends". For the fail-safe action "actuator stem retracts" the connection on the top diaphragm case is used. The connection at the side of the yoke must be fitted with a venting plug (accessories).

#### Mounting the position sensor

1. Place the lever (1) on the sensor in mid-position and hold it in place. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
2. Screw the position sensor (20) onto the mounting plate (21).
3. Depending on the actuator size and rated valve travel, determine which lever and position of the follower pin (2) is to be used from the travel table on page 28. The positioner is delivered with the M lever in pin position 35 on the sensor. If necessary, remove the follower pin (2) from its pin position and move it to the hole for the recommended pin position and screw tight.
4. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in **mid-position** and **hold it in place**. Screw on the nut (1.1).
5. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.

## Mounting and start-up

6. Place the mounting plate together with the sensor onto the actuator yoke so that the follower pin (2) rests on the top of the follower clamp (3). It must rest on it with spring force. Fasten the mounting plate (21) onto the actuator yoke using both fixing screws.
7. Mount cover (11) on the other side. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.




Fig. 26: Mounting for Type 3277-5 Actuator (left) and Type 3277 Actuator (right)

## 5.10.2 Mounting the position sensor with attachment according to IEC 60534-6

→ Required mounting parts and accessories: Table 8 on page 27.


→ Refer to Fig. 27

1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
2. Screw the position sensor (20) onto the bracket (21).

The standard attached M lever with the follower pin (2) at position 35 is designed for

120 to 350 cm<sup>2</sup> actuators with 15 mm rated travel. For other actuator sizes or travels, select the lever and pin position from the travel table on page 28. L and XL levers are included in the mounting kit.

3. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in **mid-position** and **hold it in place**. Screw on the nut (1.1).
4. Screw the two bolts (14) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (14.1) for fastening.
5. Place the bracket with the sensor at the NAMUR rib in such a manner that the follower pin (2) rests in the slot of the follower plate (3), then screw the bracket using its fixing screws onto the valve.



### 5.10.3 Mounting the position sensor to Type 3510 Micro-flow Valve

- Required mounting parts and accessories: Table 8 on page 27.
  - Refer to Fig. 28
1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unscrew the nut (1.1) and remove the standard attached **M** lever (1) together with the disk spring (1.2) from the sensor shaft.

2. Screw the position sensor (20) onto the bracket (21).
3. Select the **S** lever (1) from the accessories and screw the follower pin (2) into the hole for pin position **17**. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in mid-position and hold it in place. Screw on the nut (1.1).
4. Place follower clamp (3) on the valve stem connector, align at a right angle and screw tight.
5. Position the bracket (21) with the position sensor on the valve yoke and screw tight, making sure the follower pin (2) slides into the groove of the follower clamp (3).




Fig. 28: Mounting on a micro-flow valve

## 5.10.4 Mounting on rotary actuators

→ Required mounting parts and accessories: Table 8 on page 27.

→ Refer to Fig. 29


1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
2. Screw the position sensor (20) onto the mounting plate (21).

3. Replace the follower pin (2) normally attached to the lever (1) with the metal follower pin ( $\varnothing$  5 mm) from the accessories and screw it into the hole for pin position 90°.

4. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in **mid-position** and **hold it in place**. Screw on the nut (1.1).

Follow the instructions describing attachment to the standard positioner in section 5.8.

Instead of the positioner, attach the position sensor (20) with its mounting plate (21).



**Fig. 29:** Mounting on rotary actuators

### 5.11 Mounting the leakage sensor

→ Refer to Fig. 30

Normally, the control valve is delivered with positioner and leakage sensor already mounted.

If the leakage sensor is mounted after the valve has been installed or it is mounted onto another control valve, proceed as described in the following.

#### ! NOTICE

*Risk of malfunction due to incorrect fastening.*  
Fasten the leakage sensor using a torque of  
 $20 \pm 5 \text{ Nm}$ .

The M8 threaded connection on the NAMUR rib should preferably be used to mount the sensor (Fig. 30).

#### 💡 Tip

*If the positioner was mounted directly onto the actuator (integral attachment), the NAMUR interfaces on either side of the valve yoke can be used to mount the leakage sensor.*

The start-up of the leakage sensor is described in detail in the Operating Instructions for EXPERTplus Valve Diagnostics.




Fig. 30: Mounting the leakage sensor

## 5.12 Retrofitting an inductive limit contact

### Required retrofit kit:

Limit contact Order no. 1402-1770


#### **i Note**

The same requirements apply to retrofitting a unit as to servicing the positioner. For explosion-protected positioners, the requirements in Servicing explosion-protected devices need to be kept. Check the "Limit switch, inductive" box on the nameplate after installing the limit contact.

1. Take off the rotary pushbutton (3) and cap (1), unthread the five fastening screws (2) and lift off the plastic cover (9) together with the display, taking care not to damage the ribbon cable (between PCB and display).
2. Use a knife to cut an opening at the marked location (4).
3. Push the connector (11) with cable through the opening and secure the proximity switch (7) on the cover with a dot of glue.
4. If necessary, remove the jumper at the socket X9 and push the cable connector (11) on the socket.
5. Guide the cable in such a manner that the plastic cover can be placed back onto the positioner. Insert the fixing screws (2) and screw tight. Attach the clamping plate (8) onto the proximity switch.
6. Attach the rotary switch (5). Make sure the flattened side of the positioner shaft is

turned so that the rotary switch (5) can be attached with the metal tag next to the proximity switch.

7. On start-up of the positioner, set the option inductive alarm under Code 38 from No to YES.



1	Cap	6	Metal tag
2	Screw	7	Proximity switch
3	Rotary pushbutton	8	Clamping plate
4	Marking	9	Plastic cover
5	Rotary switch	11	Connector

Fig. 31: Retrofitting an inductive limit contact

### 5.13 Attaching positioners with stainless steel housings

Positioners with stainless steel housings require mounting parts that are completely made of stainless steel or free of aluminum.

#### **i Note**

*The pneumatic connecting plate and pressure gauge bracket are available in stainless steel (order numbers listed below). The Type 3710 Pneumatic Reversing Amplifier is also available in stainless steel.*

Connecting plate (stainless steel)	G 1/4 1/4 NPT	1400-7476 1400-7477
Pressure gauge bracket (stainless steel)	G 1/4 1/4 NPT	1402-0265 1400-7108

Table 7 to Table 9 apply for attaching positioners with stainless steel housings with the following restrictions:

#### **Direct attachment**

All mounting kits from Table 2 and Table 3 can be used. The connection block is not required. The stainless steel version of the pneumatic connecting plate routes the air internally to the actuator.

#### **Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes)**

All mounting kits from Table 4 can be used. Connecting plate in stainless steel.

#### **Attachment to rotary actuators**

All mounting kits from Table 7 can be used except for the heavy-duty version. Connecting plate in stainless steel.

### 5.14 Air purging function for single-acting actuators

The instrument air leaving the positioner is diverted to the actuator spring chamber to provide corrosion protection inside the actuator. Observe the following:

#### **Direct attachment to Type 3277-5 (stem extends FA/stem retracts FE)**

The air purging function is automatically provided.

#### **Direct attachment to Type 3277, 175 to 750 cm<sup>2</sup>**

**FA:** Remove the stopper (12.2, Fig. 7) at the black connection block and make a pneumatic connection to the spring chamber on the vented side.

#### **! NOTICE**

*Mounting possibly incorrect when old powder-paint-coated aluminum connection blocks are used.*

*Mount old powder-paint-coated aluminum connection blocks as described in sections on Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes) and Attachment to rotary actuators.*

**FE:** The air purging function is automatically provided.

### Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes) and to rotary actuators

The positioner requires an additional port for the exhaust air that can be connected over piping. An adapter available as an accessory is used for this purpose:

Threaded bushing (M20x1.5)	G 1/4 1/4 NPT	0310-2619 0310-2550
-------------------------------	------------------	------------------------

#### **i Note**

*The adapter uses one of the M20x1.5 connections in the housing which means **only one** cable gland can be installed.*

Should other valve accessories be used which vent the actuator (e.g. solenoid valve, volume booster, quick exhaust valve), this exhaust air must also be included in the purging function. The connection over the adapter at the positioner must be protected with a check valve (e.g. check valve G 1/4, order no. 8502-0597) mounted in the piping. Otherwise the pressure in the positioner housing would rise above the ambient pressure and damage the positioner when the exhausting components respond suddenly.



## 5.15 Pneumatic connections

### ⚠ WARNING

*Risk of injury by possible movement of exposed parts (positioner, actuator or valve) after connecting the signal pressure.  
Do not touch or block exposed moving parts.*

### ❗ NOTICE

*Incorrect connection of the supply air will damage the positioner and will lead to malfunction.*

*Screw the screw fittings into the connecting plate, pressure gauge mounting block or connection block from the accessories.*

The pneumatic ports are located on the back of the positioner (see Fig. 32).

### ❗ NOTICE

*Risk of malfunction due to failure to comply with required air quality.*

*Only use supply air that is dry and free of oil and dust.*

*Read the maintenance instructions for upstream pressure reducing stations.*

*Blow through all air pipes and hoses thoroughly before connecting them.*




Fig. 32: Pneumatic connections

### 5.15.1 Connecting the supply air

### ❗ NOTICE

*Risk of malfunction due to incorrect sequence of mounting, installation and start-up.*

*Keep the following sequence.*

1. Remove the protective caps from the pneumatic connections.
2. Mount the positioner on the valve.
3. Connect the supply air.
4. Connect the electrical power.
5. Perform settings.

The pneumatic connections in the connecting plate, pressure gauge mounting block and connection block are optionally designed as a bore with 1/4 NPT or G 1/4 thread. Customary fittings for metal or copper tubing or plastic hoses can be used.

### Signal pressure connection

The signal pressure connection depends on how the positioner is mounted onto the actuator:

- **Type 3277 Actuator**

The signal pressure connection is fixed.

- **Attachment according to IEC 60534-6 (NAMUR)**

For "actuator stem retracts" fail-safe action: connect the signal pressure to the connection on top of the actuator.

For "actuator stem extends" fail-safe action: connect the signal pressure to the connection on the bottom of the actuator.

- **Rotary actuators**

For rotary actuators, the manufacturer's specifications for connection apply.

## 5.15.2 Signal pressure gauges



To monitor the supply air and signal pressure, we recommend mounting pressure gauges (see accessories in section 3.6).

### Mounting the pressure gauges:

→ See section 5.4 and Fig. 8

### 5.15.3 Supply pressure

The required supply air pressure depends on the bench range and the actuator's direction of action (fail-safe action).

The bench range is written on the nameplate either as the bench range or signal pressure range depending on the actuator. The direction of action is marked FA or FE or by a symbol.

#### Actuator stem extends FA (AIR TO OPEN)

Fail-close (for globe and angle valves):

→ Required supply pressure = Upper bench range value + 0.2 bar, at least 1.4 bar.

#### Actuator stem retracts FE (AIR TO CLOSE)

Fail-open (for globe and angle valves):

For tight-closing valves, the maximum signal pressure  $p_{st_{max}}$  is roughly estimated as follows:

$$p_{st_{max}} = F + \frac{d^2 \cdot \pi \cdot \Delta p}{4 \cdot A} \text{ [bar]}$$

d = Seat diameter [cm]

$\Delta p$  = Differential pressure across the valve [bar]

A = Actuator area [ $\text{cm}^2$ ]

F = Upper bench range value of the actuator [bar]

If there are no specifications, calculate as follows:

→ Required supply pressure = Upper bench range value + 1 bar

## 5.15.4 Signal pressure (output)

The signal pressure at the output (38) of the positioner can be restricted to 1.4 bar, 2.4 bar or 3.7 bar in Code 16.

The limitation is not activated [No] by default.

## 5.16 Electrical connections

For electrical installation, observe the relevant electrotechnical regulations and the accident prevention regulations that apply in the country of use. In Germany, these are the VDE regulations and the accident prevention regulations of the employers' liability insurance.

### ⚠ DANGER

**Risk of fatal injury due to the formation of an explosive atmosphere.**

The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1) Explosive Atmospheres – Electrical Installations Design, Selection and Erection.

### ⚠ WARNING

*Incorrect electrical connection will render the explosion protection unsafe.*

- Adhere to the terminal assignment.
- Do not undo the enameled screws in or on the housing.
- Do not exceed the maximum permissible values specified in the EC type examination certificates when interconnecting intrinsically safe electrical equipment ( $U_i$  or  $U_0$ ,  $I_i$  or  $I_0$ ,  $P_i$  or  $P_0$ ,  $C_i$  or  $C_0$  and  $L_i$  or  $L_0$ ).

### Selecting cables and wires

Observe clause 12 of EN 60079-14: 2008 (VDE 0165, Part 1) for installation of the intrinsically safe circuits.

Clause 12.2.2.7 applies when running multi-core cables and wires with more than one intrinsically safe circuit.

The radial thickness of the insulation of a conductor for common insulating materials (e.g. polyethylene) must not be smaller than 0.2 mm. The diameter of an individual wire in a fine-stranded conductor must not be smaller than 0.1 mm. Protect the conductor ends against splicing, e.g. by using wire-end ferrules. When two separate cables or wires are used for connection, an additional cable gland can be installed. Seal cable entries left unused with plugs. Fit equipment used in ambient temperatures **below –20 °C** with metal cable entries.

### Equipment for use in zone 2/zone 22

In equipment operated according to type of protection Ex nA II (non-sparking equipment)

## Mounting and start-up

according to EN 60079-15: 2003, circuits may be connected, interrupted or switched while energized only during installation, maintenance or repair.

Equipment connected to energy-limited circuits with type of protection Ex nL (energy-limited equipment) according to EN 60079-15: 2003 may be switched under normal operating conditions.

**The maximum permissible values specified in the statement of conformity and its addenda apply when interconnecting the equipment with energy-limited circuits in type of protection Ex nL IIC.**

### Cable entry

Cable entry with M20x1.5 cable gland. See section on Accessories for clamping range. There is a second M20x1.5 threaded hole in the housing that can be used for additional connection, when required.

The screw terminals are designed for wire cross-sections of 0.2 to 2.5 mm<sup>2</sup>. Tighten the screws by 0.5 to 0.6 Nm.


### i Note

*The power supply for the positioner can be supplied either over the connection to the fieldbus segment or over a DC voltage source (9 to 32 V) connected to the bus terminals in the positioner.*

***Observe the relevant regulations for installation in hazardous areas.***

### Accessories

Cable glands M20x1.5	Order no.
Black plastic (6 to 12 mm clamping range)	8808-1011
Blue plastic (6 to 12 mm clamping range)	8808-1012
Nickel-plated brass (6 to 12 mm clamping range)	1890-4875



Nickel-plated brass (10 to 14 mm clamping range)	1922-8395
Stainless steel 1.4305 (8 to 14.5 mm clamping range)	8808-0160
<b>EMC cable gland M20x1.5:</b>	
Nickel-plated brass (7 to 12 mm clamping range)	8808-0143
<b>Adapter M20x1.5 to 1/2 NPT</b>	
Powder-coated aluminum	0310-2149
Stainless steel	1400-7114

### Bus line

Route the two-wire bus line to the screw terminals marked "IEC 1158-2", whereby no polarity needs to be observed.

To connect the limit contact, binary inputs and forced venting, an additional cable gland that needs to be fitted in place of the existing blanking plug is necessary.

#### ! NOTICE

Degree of protection may be impaired.  
Do not use the positioner with open cable glands.  
Seal cable glands left unused with blanking plugs.

### Limit contact

The operation of the limit contact requires a switching amplifier to be connected in the output circuit. Its function is to control the limit values of the control circuit according to EN 60947-5-6, thus ensuring operational reliability of the positioner.

Observe the relevant regulations for installation in hazardous areas.

### Binary input BI1

An active contact can be operated at binary input 1. The positioner can report the switching state over the bus protocol.

### Binary input BI2

A passive, floating contact can be operated at binary input 2. The positioner can report the switching state over the bus protocol.

### Solenoid valve

For positioners fitted with the optional solenoid valve for the forced venting function, a voltage of 24 V DC must be connected to the relevant terminals +81 and -82.

If there is no voltage connected for the solenoid valve at terminals +81 and -82 or when the voltage signal is interrupted, the positioner vents the actuator.

#### ! NOTICE

The actuator does not respond to the set point when the voltage is too low.  
Observe the switching thresholds specified in the technical data.

## 5.16.1 Establishing communication

The communication structure between the controller, logic solvers (PLC) or automation system or between a computer or work station and the positioner(s) is implemented to conform with IEC 61158-2.

### **i Note**

The action of the positioner upon failure of the FOUNDATION™ fieldbus communication can be determined over the bus parameters or over the SAMSON TROVIS-VIEW software:

- The valve remains in its last position.
- The valve moves to the fail-safe position.
- The valve moves to a defined fault state value.


**Bus parameters:** ► KH 8384-5

- FEATURES\_SEL (RES) > FAULTSTATE
- XD\_FSTATE\_OPT (AO TRD): Action on fault detection
- XD\_FSTATE\_VAL (AO FB): Fail-safe value

**TROVIS-VIEW:**

The parameters can be found in the folder [Settings > Positioner (AO, TRD) > Fail-safe action].

The action selected only takes effect if the positioner is powered. Should a power failure occur at the same time, the actuator is vented and the valve moves to the fail-safe position.



**Fig. 34:** Connection acc. to FOUNDATION™ fieldbus, for safe areas (top) and for hazardous areas (bottom)



## 6 Operation

### Rotary pushbutton

The rotary pushbutton is located underneath the front protective cover. The positioner is operated on site using the rotary pushbutton:

Turn : Select codes and values

Press : confirm setting.

### AIR TO OPEN/AIR TO CLOSE slide switch

- AIR TO OPEN applies to a valve opening as the signal pressure increases.
- AIR TO CLOSE applies to a valve closing as the signal pressure increases.

The signal pressure is the pneumatic pressure at the output of the positioner applied to the actuator.

### Volume restriction Q

The volume restriction serves to adapt the air output capacity to the size of the actuator. Depending on the air passage at the actuator, two fixed settings are available.

- For actuators smaller than 240 cm<sup>2</sup> and with a signal pressure connection at the side (Type 3271-5), set restriction to MIN SIDE.
- For a connection at the back (Type 3277-5), set restriction to MIN BACK.
- For actuators 240 cm<sup>2</sup> and larger, set to MAX SIDE for a side connection and to MAX BACK for a connection at the back.





Fig. 35: Operating controls

## Operation



<b>AUto</b>	Automatic
<b>Class</b>	Clockwise
<b>CCL</b>	Counterclockwise
<b>Err</b>	Error
<b>ESC</b>	Stop
<b>LOW</b>	w too low
<b>MAN</b>	Manual setting
<b>MAX</b>	Maximum range
<b>No</b>	Not available/not active
<b>NOM</b>	Rated travel
<b>RES</b>	Reset
<b>RUN</b>	Start
<b>SAFE</b>	Fail-safe position
<b>Sub</b>	Substitute calibration
<b>TunE</b>	Initialization in progress
<b>YES</b>	Available/active
<b>ZP</b>	Zero calibration
<b>tESTinG</b>	Test function active
↗↗	Increasing/increasing
↖↖	Increasing/decreasing

⌚ **blinking: positioner not initialized**  
⌚⌚ **blinking: Valve in mechanical fail-safe position  
(see SET\_FAIL\_SAFE\_POS parameter in the  
AO Transducer Block (AO TRD))**  
▶ **KH 8384-5**

⌚⌚ **⌚⌚ together: AO Transducer Block is in the  
MAN mode** ▶ **KH 8384-5**  
⌚⌚ **⌚⌚ both blinking: The positioner is manual  
mode while the mechanical fail-safe position  
(SET\_FAIL\_SAFE\_POS) has been de-  
manded over the fieldbus. After exiting the  
manual position, the valve moves to the  
fail-safe position.**  
⌚⌚ **blinking: emergency mode (see error code 62)**

**Fig. 36: Display**

## Readings

Icons assigned to certain codes, parameters and functions are indicated on the display.

### Operating modes:

-  **(manual mode)**

The positioner follows the manual set point (Code 1) instead of the set point of the process control system.

 blinks: The positioner is not initialized. Operation only possible over manual set point (Code 1).

-  **(automatic mode)**

The positioner is in closed-loop operation and follows the set point of the process control system.

-  **S SAFE**

The positioner vents the output. The valve moves to the mechanical fail-safe position.

### Bar graph:

In manual  and automatic  modes, the bars indicate the set point deviation that depends on the sign (+/-) and the value. One bar element appears per 1 % set point deviation.

If the positioner has not been initialized, ( blinks on the display), the bar graph indicates the lever position in degrees in relation to the mid-axis. One bar element corresponds to approximately a 5° angle of rotation. The fifth bar element blinks (reading > 30°) if the permissible angle of rotation has

been exceeded. Lever and pin position must be checked.

### Status messages

-  Maintenance alarm
-  Maintenance demanded/Maintenance required

These icons indicate that an error has occurred.

A classified status can be assigned to each error. Classifications include "No message", "Maintenance required", "Maintenance demanded" and "Maintenance alarm" (see ► EB 8389 on EXPERTplus valve diagnostics).

### Enable configuration

This indicates that the codes marked with an asterisk (\*) in the code list are enabled for configuration (see section 11.8).



## 7 Operating the positioner

### ! NOTICE

*Risk of malfunction due to incorrect sequence of mounting, installation and start-up.  
Keep the following sequence.*

1. Remove the protective caps from the pneumatic connections.
2. Mount the positioner on the valve.
3. Connect the supply air.
4. Connect the electrical power.
5. Perform settings.

**Reading after connecting the electrical power supply:**



After *tEStinG* runs across the display, the **!** fault alarm icon appears and the **!** hand icon blinks on the display when the **positioner has not been initialized**. The reading indicates the lever position in degrees in relation to the mid-axis.

Code 0 is displayed when a **positioner has been initialized**. The positioner is in the last active operating mode.

The positioner performs a test in the start-up phase while following its automation task at the same time.

### ! WARNING

*Risk of injury due to the actuator stem extending or retracting.  
Do not touch or block the actuator stem.*

During the start-up phase, operation on site is unrestricted, yet write access is limited.

### 7.1 Determining the fail-safe position

Define the fail-safe position of the valve (0 %) taking the valve type and the actuator's direction of action into account. Position the AIR TO OPEN/AIR TO CLOSE slide switch accordingly:

- **AIR TO OPEN** setting

Signal pressure opens the valve, e.g. for a fail-close valve

The AIR TO OPEN setting always applies to double-acting actuators.

- **AIR TO CLOSE** setting


Signal pressure closes the valve, e.g. for a fail-open valve

**For checking purposes:** after successfully completing initialization, the positioner display must read 0 % when the valve is closed and 100 % when the valve is open. If this is not the case, change the slide switch position and re-initialize the positioner.

**i Note**

*The switch position is prompted prior to an initialization. After an initialization has been completed, changing the switch position does not have any effect on the operation of the positioner.*

### 7.2 Adjusting the volume restriction Q



Q

Signal pressure	Transit time <1 s	≥1 s
Connection at the side	MIN SIDE	MAX SIDE
Connection at the back	MIN BACK	MAX BACK

\* Intermediate settings are not permitted.

Fig. 37: Volume restriction Q

The volume restriction Q serves to adapt the air output capacity to the size of the actuator:

- Actuators with a **transit time < 1 s**, e.g. linear actuators with an effective area smaller than 240 cm<sup>2</sup>, require a restricted air flow rate (MIN).
- Actuators with a **transit time ≥ 1 s** do not require the air flow rate to be restricted (MAX).

The position of volume restriction Q also depends on how the signal pressure is routed at the actuator in **SAMSON actuators**:

**'SIDE' inscription**

- For actuators with a signal pressure connection at the side, e.g. Type 3271-5
- For actuators from other manufacturers

**'BACK' inscription**

- For actuators with a signal pressure connection at the back, e.g. Type 3277-5

**! NOTICE**

*Malfunction due to changed start-up settings.*

*Initialize an initialized positioner again after the position of the volume restriction has been changed.*

## 7.3 Adapting the display direction

The display contents can be turned by 180° to adapt the display reading to the actuator's mounting situation. If the displayed data appear upside down, proceed as follows:

1. Turn  until Code 2 appears.
2. Press , the code number 2 blinks.
3. Turn  and select the desired reading direction.
4. Press  to confirm.



Reading direction for right attachment of pneumatic connections



Reading direction for left attachment of pneumatic connections

## 7.4 Limiting the signal pressure

If the maximum actuator force may cause damage to the valve, the signal pressure must be limited.

→ Do not activate pressure limitation for double-acting actuators (AIR TO OPEN (AtO) fail-safe position). Default setting is 'No'.


Enable configuration at the positioner before limiting the signal pressure.

## Operating the positioner

### Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: .



Enable configuration  
Default: No

### Limit the signal pressure:

1. Turn  until Code 16 appears.
2. Press , the code number 16 blinks.
3. Turn  until the required pressure limit (1.4/2.4/3.7 bar) appears.
4. Press  to confirm.



Pressure limit  
Default: No

## 7.5 Checking the operating range of the positioner

To check the mechanical attachment and the proper functioning, the valve should be moved through the operating range of the positioner in the  manual mode with the manual set point.

### Select manual mode ():

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until MAN appears.
4. Press  . The positioner changes to the manual mode (.



Operating mode  
Default: MAN

**Check the operating range:**

5. Turn  until Code 1 appears.
6. Press , the code number 1 and  icon blink.
7. Turn  until the pressure in the positioner builds up and the control valve moves to its final positions so that the travel/angle can be checked.

The angle of rotation of the lever on the back of the positioner is indicated.

A horizontal lever (mid position) is equal to 0°.



Manual set point w  
(current angle of  
rotation is indicated)

**To ensure the positioner is working properly**, the outer bar elements must not blink while the valve is moving through the operating range.

Exit Code 1 by pressing the rotary pushbutton ().

**The permissible range has been exceeded** when the displayed angle is more than 30° and the outer right or left bar element blinks. The positioner goes to the fail-safe position (SAFE). After canceling the fail-safe position (SAFE) (see section 7.11.2) it is absolutely essential that you check the lever and pin position as described in section 5.

**⚠ WARNING**

*Risk of injury due to the actuator stem extending or retracting.*

*Before exchanging the lever or changing the pin position, disconnect the supply air and electrical auxiliary power.*

## 7.6 Initializing the positioner

**⚠ WARNING**

*Risk of injury by exposed moving parts on the positioner, actuator or valve.*

*Do not touch or block exposed moving parts.*

### NOTICE

*The process is disturbed by the movement of the actuator or valve.*

*Do not perform the initialization while the process is running. First isolate the plant by closing the shut-off valves.*

→ Check the max. permissible signal pressure of the valve before starting initialization.

During initialization, the positioner issues an output signal pressure up to the maximum supply pressure supplied. If necessary, limit the signal pressure by connecting an upstream pressure reducing valve.

### Note

*Reset positioner to its default settings (see section 7.9) before mounting it on a different actuator or changing its mounting position.*

During initialization the positioner adapts itself optimally to the friction conditions and the signal pressure required by the control valve. The type and extent of auto tuning depends on the initialization mode selected:

– **Maximum range (MAX)** (standard range)

Initialization mode for simple start-up of valves with two clearly defined mechanical end positions, e.g. three-way valves (see section 7.6.1)

– **Nominal range (NOM)**

Initialization mode for all globe valves (see section 7.6.2)

– **Manually selected range (MAN)**

Initialization mode for globe valves with an unknown nominal range (see section 7.6.3)

– **Substitute calibration (SUb)**

This mode allows a positioner to be replaced while the plant is running, with the least amount of disruption to the plant (see section 7.6.4).

For normal operation, simply start initialization by pressing the INIT key after mounting the positioner on the valve and defining the fail-safe position and setting the volume restriction. The positioner only needs to work with its default settings. If necessary, perform a reset (see section 7.9).


**i Note**

An initialization procedure in progress can be canceled by pressing the rotary pushbutton. STOP is displayed for three seconds and the positioner changes to the fail-safe position (SAFE). Clear the fail-safe position again over Code 0 (see section 7.11.2).

The time required for the initialization procedure depends on the actuator transit time, which means that initialization can take a few minutes.

After a successful initialization, the positioner runs in closed-loop operation indicated by the  closed-loop operation icon.

A malfunction leads to the process being canceled. The initialization error is displayed according to how it has been classified by the condensed state. Refer to section 9.



Alternating readings  
Initialization in progress  
Icon depending on initialization mode selected



Bar graph display indicating the progress of the initialization



Initialization successfully completed. Positioner in automatic mode ()

**i Note**

When Code 48 - h0 = YES, the diagnostics automatically start to plot the reference graphs (drive signal steady-state d1 and hysteresis d2) after initialization has been completed. This is indicated by tESt and d1 or d2 appearing on the display in alternating sequence.

An error during the plotting of the reference graphs is indicated on the display over Code 48 - h1 and Code 81.

The reference graphs do not have any effect on closed-loop operation.

### Fail-safe action AIR TO CLOSE

If the slide switch is set to AIR TO CLOSE, the positioner automatically switches to the direction of action increasing/decreasing ( $\nearrow\searrow$ ) after initialization has been completed. This results in the assignment (left) between set point and valve position.

The tight-closing function is activated.

**Set Code 15 (set point cutoff increase) to 99 % for three-way valves.**

Fail-safe position	Direction of action	Set point Valve	
		CLOSED at	OPEN at
Actuator stem extends (FA) AIR TO OPEN	$\nearrow\searrow$	0 %	100 %
Actuator stem retracts (FE) AIR TO CLOSE	$\nearrow\searrow$	100 %	0 %

### 7.6.1 MAX – Initialization based on maximum range

The positioner determines travel/angle of rotation of the closing member from the CLOSED position to the opposite travel stop and adopts this travel/angle of rotation as the operating range from 0 to 100 %.

#### Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading:  $\Rightarrow$ ).



Enable configuration  
Default: No

#### Select the initialization mode:

1. Turn  until Code 6 appears.
2. Press , the code number 6 blinks.
3. Turn  until MAX appears.
4. Press  to confirm the MAX initialization mode.



Default: MAX

**Start initialization:**


- Press INIT key.

The rated travel/angle of rotation is indicated in % after initialization. Code 5 (nominal range) remains locked. The parameters for travel/angle range start (Code 8) and travel/angle range end (Code 9) can also only be displayed and modified in %.

For a reading in mm/°, enter the pin position (Code 4).

**Enter the pin position:**

1. Turn  until Code 4 appears.
2. Press , the code number 4 blinks.
3. Turn  to select pin position on lever (see relevant section on attachment).
4. Press  to confirm.



Pin position  
Default: No

The nominal range is displayed in mm/°.

## 7.6.2 NOM – Initialization based on nominal range

The calibrated sensor allows the effective valve travel to be set very accurately. During initialization, the positioner checks whether the control valve can move through the indicated nominal range (travel or angle) without collision. If this is the case, the indicated nominal range is adopted with the limits of travel/angle range start (Code 8) and travel/angle range end (Code 9) as the operating range.

 **Note**


*The maximum possible travel must always be greater than the rated travel entered. If this is not the case, initialization is automatically canceled (error message Code 52) because the rated travel could not be achieved.*

**Enable configuration:**

Configuration is locked again if no settings are entered within 120 s.

## Operating the positioner


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: .




Enable configuration  
Default: No

### Enter the pin position and nominal range:

1. Turn  until Code 4 appears.
2. Press , the code number 4 blinks.
3. Turn  to select pin position on lever (see relevant section on attachment).
4. Press  to confirm.
5. Turn  until Code 5 appears.
6. Press , the code number 5 blinks.
7. Turn  and set rated travel of the valve.
8. Press  to confirm.




Pin position  
Default: No



Nominal range  
(locked when Code 4 = No)

### Select the initialization mode:

1. Turn  until Code 6 appears.
2. Press , the code number 6 blinks.
3. Turn  until NOM appears.
4. Press  to confirm the NOM initialization mode.



Init mode  
Default: MAX

### Start initialization:

- Press INIT key.  
→ After the initialization has been successfully completed:  
Check the direction of action (Code 7) and, if necessary, change it.

### 7.6.3 MAN – Initialization based on a manually selected range

Before starting initialization, move the control valve manually to the OPEN position. Turn the rotary pushbutton (⊗) clockwise in small steps. The valve must be moved with a monotonically increasing signal pressure. The positioner calculates the differential travel/angle from the OPEN and CLOSED positions and adopts it as the operating range with limits of lower travel/angle range value (Code 8) and upper travel/angle range value (Code 9).

#### Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn (⊗) until Code 3 appears (reading: No).
2. Press (⊗), the code number 3 blinks.
3. Turn (⊗) until YES appears.
4. Press (⊗) to confirm (reading: ☐).



Enable configuration  
Default: No

#### Enter the pin position:

1. Turn (⊗) until Code 4 appears.
2. Press (⊗), the code number 4 blinks.
3. Turn (⊗) to select pin position on lever (see relevant section on attachment).
4. Press (⊗) to confirm.



Pin position  
Default: No

#### Select the initialization mode:

1. Turn (⊗) until Code 6 appears.
2. Press (⊗), the code number 6 blinks.
3. Turn (⊗) until MAN appears.
4. Press (⊗) to confirm the MAN initialization mode.




Init mode  
Default: MAX

## Operating the positioner

### Enter OPEN position:

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until MAN appears.
4. Press  to confirm.
5. Turn  until Code 1 appears.
6. Press , the code number 1 blinks.
7. Turn  until the valve reaches its OPEN position.
8. Press  to confirm the OPEN position.



Manual set point  
(current angle of rotation is indicated)

### Start initialization:

- Press INIT key.

## 7.6.4 SUb – Substitute calibration

A complete initialization procedure takes several minutes and requires the valve to move through its entire travel range several times. In the SUb initialization mode, the control parameters are estimated and not determined by an initialization procedure. As a result, a high level of accuracy cannot be expected. A different initialization mode should be selected if the plant allows it.

The substitute calibration is used to replace a positioner while the process is running. For this purpose, the control valve is usually fixed mechanically in a certain position or pneumatically by means of a pressure signal which is routed to the actuator externally. The blocking position ensures that the plant continues to operate with this valve position.

By entering the blocking position (Code 35), closing direction (Code 34), pin position (Code 4), nominal range (Code 5) and direction of action (Code 7), the positioner can calculate the positioner configuration.


### NOTICE

Perform a reset before re-initializing the positioner if the substitute positioner has already been initialized. Refer to section 7.9.

**Enable configuration:**

Configuration is locked again if no settings are entered within 120 s.

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ☐).



Enable configuration  
Default: No

**Enter the pin position and nominal range:**

1. Turn  until Code 4 appears.
2. Press , the code number 4 blinks.
3. Turn  to select pin position on lever (see relevant section on attachment).
4. Press  to confirm.
5. Turn  until Code 5 appears.
6. Press , the code number 5 blinks.
7. Turn  and set rated travel of the valve.
8. Press  to confirm.



Pin position  
Default: No



Nominal range  
(locked when Code 4 = No)

**Select the initialization mode:**

1. Turn  until Code 6 appears.
2. Press , the code number 6 blinks.
3. Turn  until SUb appears.
4. Press  to confirm the SUb initialization mode.




Init mode  
Default: MAX

## Operating the positioner

### Enter the direction of action:

1. Turn  until Code 7 appears.
2. Press , the code number 7 blinks.
3. Turn  to select the direction of action ( $\nearrow/\nwarrow$ ).
4. Press  to confirm.



Direction of action  
Default:  $\nearrow$

### Deactivate travel limit:

1. Turn  until Code 11 appears.
2. Press , the code number 11 blinks.
3. Turn  until No appears.
4. Press  to deactivate the travel limit function.



Travel limitation  
Default: No

### Change pressure limit and control parameters:

#### Note

*Do not change the pressure limit (Code 16). Only change the control parameters  $K_p$  (Code 17) and  $T_V$  (Code 18) if the settings of the replaced positioner are known.*

1. Turn  until the required Code 16/17/18 appears.
2. Press , the code number 16/17/18 blinks.
3. Turn  to set the control parameter selected.
4. Press  to confirm.



Pressure limit  
Default: No




$K_p$  level  
Default: 7



$T_V$  level  
Default: 2

### Enter closing direction and blocking position:

1. Turn  until Code 34 appears.
2. Press , the code number 34 blinks.
3. Turn  and set the closing direction (CCL = counterclockwise/CL = clockwise).
4. Press  to confirm.
5. Turn  until Code 35 appears.
6. Press , the code number 35 blinks.
7. Turn  to set the blocking position, e.g. 5 mm (read off at travel indicator scale of the blocked valve or measure with a ruler).
8. Set switch for fail-safe position AIR TO OPEN or AIR TO CLOSE according to section 7.1.
9. Adjust volume restriction as described in section 7.2.



Closing direction  
(direction of rotation causing the valve to move to the CLOSED position (view onto positioner display))  
Default: CCL  
(counterclockwise)



Blocking position  
Default: 0

## Operating the positioner

### Start initialization:

- Press INIT key.  
The positioner switches to MAN mode.  
The blocking position is indicated.

Since initialization has not been completed, the error code 76 (no emergency mode) and possibly also error code 57 (control loop) may appear on the display. These alarms do not influence the positioner's readiness for operation.

### Cancel the blocking position and change to automatic mode (AUTO):

For the positioner to follow its set point again, the blocking position must be canceled and the positioner must be set to automatic mode as follows:

1. Turn  until Code 1 appears.
2. Press , the code number 1 and  icon blink.
3. Turn  to build up pressure in the positioner to move the valve slightly past the blocking position.
4. Press  to cancel the mechanical blocking.
5. Turn  until Code 0 appears.
6. Press , the code number 0 blinks.
7. Turn  until AUtO appears.
8. Press  to confirm. The positioner switches to automatic mode. The current valve position is indicated in %.

- If the positioner shows a tendency to oscillate in automatic mode, the parameters  $K_p$  and  $T_v$  must be slightly corrected. Proceed as follows:
- Set  $T_v$  (Code 18) to 4.
  - If the positioner still oscillates, the gain  $K_p$  (Code 17) must be decreased until the positioner shows a stable behavior.

### Zero point calibration

- Finally, if process operations allow it, the zero point must be calibrated according to section 7.7.

## 7.7 Zero calibration

In case of inconsistencies in the closed position of the valve, e.g. with soft-seated plugs, it might be necessary to recalibrate zero.

### ⚠ WARNING

*Risk of injury due to the actuator stem extending or retracting.  
Do not touch or block the actuator stem.*

### ❗ NOTICE

*The process is disturbed by the movement of the actuator stem.  
Do not perform zero calibration while the process is running. First isolate the plant by closing the shut-off valves.*

The positioner must be connected to the supply air to perform the zero calibration.

#### Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration  
Default: No

#### Perform zero calibration:

1. Turn  until Code 6 appears.
  2. Press , the code number 6 blinks.
  3. Turn  until ZP appears.
- Press INIT key.  
Zero calibration starts. The positioner moves the valve to the CLOSED position and recalibrates the internal electrical zero point.



Init mode  
Default: MAX

### 7.8 Adjusting the inductive limit contact

The positioner version with an inductive limit contact has an adjustable tag (1) mounted on the axis of rotation, which operates the proximity switch (3).

For operation of the inductive limit contact, the corresponding switching amplifier (see section 5.16) must be connected to the output circuit.

When the tag (1) is located in the inductive field of the switch, the switch assumes a high resistance. When it moves outside the field, the switch assumes a low resistance.

Normally, the limit contact is adjusted in such a way that it will provide a signal in both end positions of the valve. The switch, however, can also be adjusted to indicate intermediate valve positions.

The required switching function, i.e. whether the output relay is to be picked up or released when the tag enters the field, must be selected at the switching amplifier, if required.

#### Adjusting the switching point

##### **i Note**

*During adjustment or testing, the switching point must always be approached from mid-position (50 %).*

To guarantee the switching under all ambient conditions, adjust the switching point approx. 5 % before the mechanical stop (OPEN – CLOSED).

##### For CLOSED position:

1. Initialize the positioner.
2. Move the valve to 5 % in the MAN mode (see display).
3. Adjust the tag at the yellow adjustment screw (2) until the tag enters or leaves the field and the switching amplifier responds.  
You can measure the switching voltage as an indicator.

##### Contact function:


- Tag leaving the field > contact is closed.
- Tag entering the field > contact is opened.

### For OPEN position:

1. Initialize the positioner.
2. Move the valve to 95 % in the MAN mode (see display).
3. Adjust the tag (1) at the yellow adjustment screw (2) until the tag enters or leaves the field of the proximity switch (3).  
You can measure the switching voltage as an indicator.

### Contact function:

- Tag leaving the field > contact is closed.
- Tag entering the field > contact is opened.



**Fig. 38:** Adjusting the limit contact


### 7.9 Reset to default settings

This function resets all start-up and setting parameters as well as the diagnosis to the factory default settings (see code list in section 11.8).

#### Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration  
Default: No

#### Reset start-up parameters:

1. Turn  until Code 36 appears (reading: ).
2. Press , the code number 36 blinks.
3. Turn  until Std appears.
4. Press  to confirm. All start-up parameters as well as the diagnosis are reset to their default values.



Reset  
Default: No

#### Note

Code 36 - diAG allows just the diagnosis data (EXPERTplus) to be reset. Refer to the Operating Instructions for EXPERTplus valve diagnostics ► EB 8389.

### 7.10 Enabling and selecting parameters

All codes and their meaning and default settings are listed in the code list in section 11.4.

Codes which are marked with an asterisk must be enabled with Code 3 before the associated parameters can be configured as described below.

Turn  until Code 3 appears (reading: No).

Press , the code number 3 blinks.

Change the setting in Code 3.

Turn  until YES appears.

Press , reading: 

Configuration is enabled.

You can now configure codes one after the other:

Turn  to select the required code.

Press  to activate the selected code. The code number starts to blink.

Turn  to select the setting.

Press  to confirm the selected setting.



Code 3  
Configuration not enabled



Configuration enabled

If no settings are entered within 120 seconds, the enabled configuration function becomes invalid and the display returns to Code 0.

#### Cancel the setting:

To cancel a value before it is confirmed (by pressing ) proceed as follows:

Turn  until ESC appears.

Press  to confirm.

The entered value is not adopted.



Canceling the reading

### 7.11 Operating modes

#### 7.11.1 Automatic and manual modes

After initialization has been completed successfully, the positioner is in  automatic mode (AUTO).



Automatic mode

#### Switching to manual mode (MAN):

1. Turn  until Code 0 appears.
2. Press , reading: AUTO, the code number 0 blinks.
3. Turn  until MAN appears.
4. Press . The positioner changes to the manual mode ().

The manual mode starts using the last set point of the automatic mode, ensuring a bumpless changeover. The current position is displayed in %.



Automatic mode



Manual mode

#### Adjusting the manual set point:

1. Turn  until Code 1 appears.
2. Press , the code number 1 blinks.
3. Turn  until sufficient pressure has been built up in the positioner and the control valve moves to the required position.



The positioner automatically returns to Code 0 if no settings are made within 120 seconds, but remains in the manual mode.

### Switch to automatic mode

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until AUtO appears.
4. Press . The positioner switches to automatic mode.

### 7.11.2 Fail-safe position (SAFE)

If you want to move the valve to the fail-safe position determined during start-up (see section 7.1), proceed as follows:

1. Turn  until Code 0 appears.
2. Press , reading: current operating mode (AUtO or MAN), the code number 0 blinks.
3. Turn  until SAFE appears.
4. Press , reading: S

The valve moves to the fail-safe position. If the positioner has been initialized, the current valve position in % is indicated on the display.



### Exiting the fail-safe position:

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  and select the required operating mode (AUtO or MAN).
4. Press  to confirm.
5. The positioner switches to the operating mode selected.



## 8 Servicing

### **i Note**

The positioner was checked by SAMSON before it left the factory.

- The product warranty becomes void if service or repair work not described in these instructions is performed without prior agreement by SAMSON's After-sales Service department.
- Only use original spare parts by SAMSON, which comply with the original specifications.

The positioner does not require any maintenance.

### Housing cover

Occasionally, the window in the cover may need to be cleaned.

### **! NOTICE**

Incorrect cleaning will damage the window. The window is made of Makrolon® (new design) and will be damaged when cleaned with abrasive cleaning agents or agents containing solvents.

- Do not rub the window dry.
- Do not use any cleaning agents containing chlorine or alcohol or abrasive cleaning agents.
- Use a non-abrasive, soft cloth for cleaning.

### Filters

There are filters with a 100 µm mesh size in the pneumatic connections for supply and output which can be removed and cleaned, if required.

### Supply air pressure reducing stations

The maintenance instructions of any upstream supply air pressure reducing stations must be observed.

## 8.1 Firmware update

Firmware updates on positioners currently in operation can be performed as described below. Only individuals with a written approval may perform updates. Approved individuals are named by SAMSON's Total Quality Management and assigned a test mark.

Laptops and computers connected to the power supply must only be interconnected with intrinsically safe equipment if the SAMSON isolated USB interface adapter (order no. 1400-9740) is connected in-between for software programming or test routines.

### Updates outside the hazardous area:

- Remove the positioner and perform the update outside the hazardous area.

### Updates on site:

- Updates on site are only permitted after the plant operator presented a signed hot work permit.

- After updating has been completed, add the current firmware to the nameplate (e.g. using a label).
- The individual approved by SAMSON confirms the update by attaching the assigned test mark (stamp).

## 8.2 Preparation for return shipment

Defective positioners can be returned to SAMSON for repair.

Proceed as follows to return devices to SAMSON:

1. Put the control valve out of operation.  
See associated valve documentation.
2. Remove the positioner (see section 10).
3. Send the positioner to your nearest SAMSON subsidiary. SAMSON subsidiaries are listed on our website at  
▶ [www.samsongroup.com](http://www.samsongroup.com) > About SAMSON > Sales offices.

## 9 Malfunctions

A status classification is assigned to all status and fault alarms in the positioner. The default settings of the status classification are listed in the code list.

### Note

The assignment of the status classification can be changed in TROVIS-VIEW and over the FOUNDATION™ fieldbus parameters. Refer to the Operating Instructions for the valve diagnostics ► EB 8389 and the Configuration Manual ► KH 8384-5 on the enclosed CD-ROM for more details.

To provide a better overview, the classified messages are summarized in a condensed state for the positioner according to the NAMUR Recommendation NE 107. The status messages are divided into the following categories:

- **Maintenance alarm**

The positioner cannot perform its control task due to a functional fault in the positioner itself or in one of its peripherals or an initialization has not yet been successfully completed.

- **Maintenance required**

The positioner still performs its control task (with restrictions). A maintenance demand or above average wear has been determined. The wear tolerance will soon be exhausted or is reducing at a faster rate than expected. Maintenance is necessary in the medium term.

- **Maintenance demanded**

The positioner still performs its control task (with restrictions). A maintenance demand or above average wear has been determined. The wear tolerance will soon be exhausted or is reducing at a faster rate than expected. Maintenance is necessary in the short term.

- **Out of specification**

The positioner is running outside the specified operating conditions.

- **Function check**

Test or calibration procedures are performed in the positioner. The positioner is temporarily unable to perform its control task as long as the procedure is taking place.

### Note


If an event is classified as "No message", this event does not have any affect on the condensed state.

The condensed state is displayed represented by the following icons:

Condensed state	Positioner display
Maintenance alarm	
Function check	Text e.g. tESTing, TunE or tEST
Maintenance required/maintenance demanded	
Out of specification	 blinking

If the positioner has not been initialized, the maintenance alarm icon () is displayed as the positioner cannot follow its set point.

If fault alarms exist, the possible source of error is displayed in Code 49 onwards. In this case, Err is displayed.



Example:  
Error caused by pin position

Refer to the code list (section 11.4) for possible causes and the recommended action.

## 9.1 Confirming error messages

### Enable configuration:

1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).

### Confirming error message:

1. Turn  until the the error code that you want appears.
2. Press  to confirm the error message.

## 9.2 Emergency action

Fail-safe action is triggered by the i/p converter or solenoid valve and upon supply air failure. The positioner fully discharges its pneumatic output to the atmosphere, causing the mounted actuator to be vented. As a result, the valve moves to the fail-safe position. The fail-safe position depends on how the springs are arranged in the pneumatic actuator (air-to-close or air-to-open).

When the supply air fails, the optional solenoid valve is triggered or after reaching the shutdown signal, all positioner functions, except open/closed loop control, remain active (including diagnostics as well as position and status feedback).



*Emergency action in the event of valve or actuator failure is described in the associated valve and actuator documentation.*

→ The plant operator is responsible for emergency action to be taken in the plant.

## 10 Decommissioning and removal

### ⚠ DANGER

#### **Risk of fatal injury due to ineffective explosion protection.**

The explosion protection becomes ineffective when the positioner cover is opened.  
The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1).

### ⚠ NOTICE

The process is disturbed by interrupting closed-loop control.

Do not mount or service the positioner while the process is running and only after isolating the plant by closing the shut-off valves.

### 10.1 Decommissioning

To decommission the positioner before removing it, proceed as follows:

1. Disconnect and lock the air supply and signal pressure.
2. Open the positioner cover and disconnect the wires for the control signal.

### 10.2 Removing the positioner

1. Disconnect the wires for the control signal from the positioner.
2. Disconnect the lines for supply air and signal pressure (not required for direct attachment using a connection block).

3. To remove the positioner, loosen the three fastening screws on the positioner.

### 10.3 Disposal



We are registered with the German national register for waste electric equipment (stiftung ear) as a producer of electrical and electronic equipment, WEEE reg. no.: DE 62194439

- Observe local, national and international refuse regulations.
- Do not dispose of components, lubricants and hazardous substances together with your other household waste.

### i Note

We can provide you with a recycling passport according to PAS 1049 on request. Simply e-mail us at [aftersaleservice@samsongroup.com](mailto:aftersaleservice@samsongroup.com) giving details of your company address.

### 💡 Tip

On request, we can appoint a service provider to dismantle and recycle the product.



## 11 Annex

### 11.1 After-sales service

Contact SAMSON's After-sales Service for support concerning service or repair work or when malfunctions or defects arise.

#### E-mail address

You can reach our after-sales service at [aftersalesservice@samsongroup.com](mailto:aftersalesservice@samsongroup.com).

#### Addresses of SAMSON AG and its subsidiaries

The addresses of SAMSON AG, its subsidiaries, representatives and service facilities worldwide can be found on our website ([www.samsongroup.com](http://www.samsongroup.com)) or in all SAMSON product catalogs.

#### Required specifications

Please submit the following details:

- Order number and position number in the order
- Type, serial number, firmware version, device version

### 11.2 Information on the UK sales region

The following information corresponds to the 2016 Regulations No. 1105 Pressure Equipment (Safety) Regulations 2016, STATUTORY INSTRUMENTS, 2016 No. 1105 (UKCA marking). It does not apply to Northern Ireland.

#### Importer

SAMSON Controls Ltd  
Perrywood Business Park  
Honeycrock Lane  
Redhill, Surrey RH1 5JQ  
Phone: +44 1737 766391  
E-mail: [sales-uk@samsongroup.com](mailto:sales-uk@samsongroup.com)  
Website: [uk.samsongroup.com](http://uk.samsongroup.com)

### 11.3 Certificates

The certificates valid at the time when these instructions were published are included on the next pages. The latest certificates can be found on our website ([www.samsongroup.com](http://www.samsongroup.com) > Product selector > Valve accessories > Type 3730-5 > Downloads > Certificates).

## 11.4 Code list

Code no.	Parameter – Readings/values [default setting]	Description																											
<b>Note:</b> Codes marked with an asterisk (*) must be enabled with Code 3 prior to configuration.																													
0	<b>Operating mode</b> [MAN] Manual mode AUtO Automatic mode SAFE Fail-safe position ESC Stop	Switchover from automatic to manual mode is bumpless. In fail-safe position, the S icon is displayed. In MAN and AUtO mode, the system deviation is represented by the bar graph elements. The reading indicates the valve position or angle of rotation in % when the positioner is initialized. If the positioner is not initialized, the position of the lever in relation to the longitudinal axis is displayed in degrees (°).																											
1	<b>Manual w</b> [0] to 100 % of the nominal range	Adjust the manual set point with the rotary pushbutton. The current travel/angle is displayed in % when the positioner is initialized. If the positioner is not initialized, the position of the lever in relation to the longitudinal axis is indicated in degrees (°). <p><b>i Note</b> It can only be selected when Code 0 = MAN</p>																											
2	<b>Reading direction</b> 1234, 1234, ESC	The reading direction of the display is turned by 180°.																											
3	<b>Enable configuration</b> [No], YES, ESC	Enables changing of data (automatically deactivated when the rotary pushbutton has not been operated for 120 s). FF blinks on the display when the on-site operation is locked. Codes marked with an asterisk (*) can only be read and not overwritten. Similarly, codes can only read over the SSP interface.																											
4*	<b>Pin position</b> [No], 17, 25, 35, 50, 70, 100, 200 mm, 90° with rotary actuators, ESC  <b>Note:</b> If you select a pin position in Code 4 that is too small, the positioner switches to SAFE mode for reasons of safety.	Follower pin must be mounted in the proper position depending on the valve travel/opening angle. Pin position must be entered for nominal (NOM) or substitute (SUB) initialization. <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Pin position Code 4</th> <th>Standard Code 5</th> <th>Adjustment range Code 5</th> </tr> </thead> <tbody> <tr> <td>17</td> <td>7.5</td> <td>3.6 to 17.7</td> </tr> <tr> <td>25</td> <td>7.5</td> <td>5.0 to 25.0</td> </tr> <tr> <td>35</td> <td>15.0</td> <td>7.0 to 35.4</td> </tr> <tr> <td>50</td> <td>30.0</td> <td>10.0 to 50.0</td> </tr> <tr> <td>70</td> <td>40.0</td> <td>14.0 to 70.7</td> </tr> <tr> <td>100</td> <td>60.0</td> <td>20.0 to 100.0</td> </tr> <tr> <td>200</td> <td>120.0</td> <td>40.0 to 200.0</td> </tr> <tr> <td>90°</td> <td>90.0</td> <td>24.0 to 100.0</td> </tr> </tbody> </table>	Pin position Code 4	Standard Code 5	Adjustment range Code 5	17	7.5	3.6 to 17.7	25	7.5	5.0 to 25.0	35	15.0	7.0 to 35.4	50	30.0	10.0 to 50.0	70	40.0	14.0 to 70.7	100	60.0	20.0 to 100.0	200	120.0	40.0 to 200.0	90°	90.0	24.0 to 100.0
Pin position Code 4	Standard Code 5	Adjustment range Code 5																											
17	7.5	3.6 to 17.7																											
25	7.5	5.0 to 25.0																											
35	15.0	7.0 to 35.4																											
50	30.0	10.0 to 50.0																											
70	40.0	14.0 to 70.7																											
100	60.0	20.0 to 100.0																											
200	120.0	40.0 to 200.0																											
90°	90.0	24.0 to 100.0																											

Code no.	Parameter – Readings/values [default setting]	Description
5*	<b>Nominal range</b> mm or angle °, ESC	Nominal valve travel or opening angle must be entered for nominal (NOM) or substitute (SUB) initialization. The possible adjustment range depends on the pin position from the table for Code 4. Code 5 is generally locked until Code 4 is set to No, i.e. after a pin position has been entered, Code 5 can be configured. Indicates maximum travel/angle reached during initialization after initialization has been successfully completed.
6*	<b>Init mode</b>  [MAX] Maximum range NOM Nominal range MAN Manual setting SUB Emergency mode ZP Zero calibration ESC Stop	Select the initialization mode MAX: Travel/angle of the closure member from the CLOSED position to the opposite stop in the actuator. NOM: Travel/angle of the closure member measured from the CLOSED position to the indicated OPEN position. MAN: Manually selected range SUB: Substitute calibration (without initialization)
7*	<b>w/x</b>  [↗↗] Increasing/increasing ↗↘ Increasing/decreasing ESC	Direction of action of the set point w in relation to the travel/angle x Automatic adaptation: AIR TO On completing initialization, the direction of action remains OPEN: increasing/increasing (↗↗). A globe valve opens as the set point increases. AIR TO On completing initialization, the direction of action changes CLOSE: to increasing/decreasing (↗↘). A globe valve closes as the set point increases.
8*	<b>Travel/angle range start (lower x-range value)</b> [0.0] to 80.0 % of the nominal range, ESC  <b>Note:</b> Specified in mm or angle ° provided Code 4 is activated.	Lower range value for travel/angle in nominal or operating range The <b>operating range</b> is the actual travel/angle of the valve and is limited by the lower travel/angle range value (Code 8) and the upper travel/angle range value (Code 9). Usually, the operating range and the nominal range are identical. The nominal range can be limited to the operating range by the lower and upper x-range values. The value is displayed or must be entered. The characteristic is adapted. See also the example in Code 9.

## Annex

Code no.	Parameter – Readings/values [default setting]	Description
9*	<b>Travel/angle range end (upper x-range value)</b> 20.0 to [100.0 %] of the nominal range, ESC  <b>Note:</b> Specified in mm or angle ° provided Code 4 is activated.	Upper range value for travel/angle in nominal or operating range The value is displayed or must be entered. The characteristic is adapted.  <b>Example:</b> The operating range is modified, for example to limit the range of a control valve which has been sized too large. For this function, the entire resolution range of the set point is converted to the new limits.  0 % on the display corresponds to the adjusted lower limit and 100 % to the adjusted upper limit.
10*	<b>Travel/angle lower limit (lower x-limit)</b> 0.0 to 49.9 % of the operating range, [No], ESC	Limits travel/opening angle to the entered value (lower limit). The characteristic is not adapted.  The characteristic is not adapted to the reduced range. See also example in Code 11.
11*	<b>Travel/angle upper limit (upper x-limit)</b> 50.0 to 120.0 %, [100 %] of the operating range, No, ESC	Limits travel/angle to the entered value (upper limit). The characteristic is not adapted.  <b>Example:</b> In some applications, it is better to limit the valve travel, e.g. if a certain minimum medium flow is required or a maximum flow must not be reached.  The lower limit must be adjusted with Code 10 and the upper limit with Code 11. If a tight-closing function has been set up, it has priority over the travel limitation. When set to No, the valve can be opened past the rated travel with a set point outside of the 0 to 100 % range.
14*	<b>Set point cutoff decrease</b> 0.0 to 49.9 %, [1.0 %] of the span adjusted in Code 12/13, No, ESC	If the set point w reaches up to the entered percentage at the final value that causes the valve to close, the actuator is immediately completely vented (with AIR TO OPEN) or filled with air (with AIR TO CLOSE). This action always lead to maximum tight-closing of the valve.  Codes 14/15 have priority over Codes 8/9/10/11. Codes 21/22 have priority over Codes 14/15.

Code no.	Parameter – Readings/values [default setting]	Description
15*	<b>Set point cutoff increase</b> 50.0 to 100.0 % of the span adjusted in Code 12/13, [No], ESC	<p>If the set point <math>w</math> reaches up to the entered percentage at the final value that causes the valve to open, the actuator is immediately filled with air (with AIR TO OPEN) or completely vented (with AIR TO CLOSE). This action always lead to the valve being completely opened. The signal pressure can be limited in Code 16.</p> <p>Codes 14/15 have priority over Codes 8/9/10/11.</p> <p>Codes 21/22 have priority over Codes 14/15.</p> <p><b>Example:</b> set the cutoff to 99 % for three-way valves.</p>
16*	<b>Pressure limit</b> 1.4, 2.4, 3.7 bar, [No], ESC	<p>The signal pressure to the actuator can be limited in stages.</p> <p>After changing a pressure limit already set, the actuator must be vented once (e.g. by selecting the fail-safe position (SAFE) over Code 0).</p> <p><b>! NOTICE</b></p> <p><i>Do not activate pressure limitation for double-acting actuators (with fail-safe position AIR TO OPEN).</i></p>
17*	<b>Proportional-action coefficient <math>K_p</math> (level)</b> 0 to 17, [7], ESC	<p>Read or change <math>K_p</math></p> <p><b>i Note</b></p> <p><b>Note concerning changing the <math>K_p</math> and <math>T_V</math> levels:</b> During positioner initialization, the values for <math>K_p</math> and <math>T_V</math> are optimally set. If the positioner tends to overshoot impermissibly due to other disturbances, the <math>K_p</math> and <math>T_V</math> levels can be adapted accordingly after initialization. Increment <math>T_V</math> level until desired behavior is reached or when the maximum value of 4 is reached, the <math>K_p</math> level can be decreased in increments.</p> <p><math>K_p</math> level changes affect the set point deviation.</p>
18*	<b>Derivative-action time <math>T_V</math> (level)</b> 1, [2], 3, 4, No, ESC	<p>Read or change <math>T_V</math> (see <math>K_p</math> level)</p> <p>A change of the <math>T_V</math> level has no effect on the system deviation.</p>
19*	<b>Tolerance band</b> 0.1 to 10.0 %, [5.0 %] of the operating range, ESC	<p>Used for error monitoring.</p> <p>Determination of the tolerance band in relation to the operating range.</p> <p>Associated lag time (30 s) is a reset criterion.</p> <p>If a transit time is determined during initialization which is six times longer than 30 s, the six-fold transit time is accepted as the lag time.</p>

Code no.	Parameter – Readings/values [default setting]	Description
20*	<b>Characteristic</b> [0] to 9, ESC	Select characteristic 0 Linear 1 Equal percentage 2 Reverse equal percentage 3 SAMSON butterfly valve, linear 4 SAMSON butterfly valve, equal percentage 5 VETEC rotary plug valve, linear 6 VETEC rotary plug valve, equal percentage 7 Segmented ball valve, linear 8 Segmented ball valve, equal percentage 9 User-defined (defined over operator software)
		<b>i Note</b> <i>The various characteristics are listed in the Appendix.</i>
21*	<b>Required transit time OPEN (w ramp open)</b> [0] to 240 s, ESC	Time required to move through the operating range when the valve opens. Limitation of the transit time (Code 21 and 22): For some applications it is recommendable to limit the transit time of the actuator to prevent it from engaging too fast in the running process. Code 21 has priority over Code 15. <b>! NOTICE</b> <i>The function is not activated when the fail-safe function or solenoid valve is triggered nor upon failure of the auxiliary power.</i>
22*	<b>Required transit time CLOSED (w ramp closed)</b> [0] to 240 s, ESC	Time required to move through the operating range when the valve closes. Code 22 has priority over Code 14. <b>! NOTICE</b> <i>The function is not activated when the fail-safe function or solenoid valve is triggered nor upon failure of the auxiliary power.</i>
23*	<b>Total valve travel</b> [0] to $99 \cdot 10^7$ , YES, ESC Exponential reading from 9999 travel cycles onwards	Totaled full valve travel cycle Can be reset to 0 by selecting ESC. <b>i Note</b> <i>The total valve travel is saved in a non-volatile memory after every 1000 full valve travel cycle.</i>

Code no.	Parameter – Readings/values [default setting]	Description
24*	<b>LV total valve travel</b> 1000 to 99 . 10 <sup>7</sup> [1.000000], ESC Exponential reading from 9999 travel cycles onwards	Limit value of total valve travel. If the limit is exceeded, the error message and the  icon corresponding to the condensed state appear.
34*	<b>Closing direction</b> CL, [CCL], ESC	CL: Clockwise CCL: Counterclockwise Direction of rotation to reach the valve's CLOSED position (view onto rotary switch with positioner cover open). Needs only be entered in SUb initialization mode (Code 6).
35*	<b>Blocking position</b> [0.0] mm/° /%, ESC	Enter the blocking position (distance to CLOSED position) Only necessary with SUb initialization mode.
36*	<b>Reset</b> [---], Std, diAG, ESC	Std: Resets all parameters and diagnosis data to their default settings. After a reset, the positioner must be re-initialized.  diAG: Resets diagnosis data only. Plotted reference graphs and logs remain saved. The positioner does not need to be re-initialized.
38*	<b>Inductive alarm</b> [No], YES, ESC	Indicates whether the inductive limit contact option is installed or not.
39	<b>Set point deviation e info</b> -99.9 to 99.9 %	Read only Indicates the deviation from the target position.
40	<b>Transit time Open info</b> [0] to 240 s	Read only Minimum opening time determined during initialization.
41	<b>Transit time Closed info</b> [0] to 240 s	Read only Minimum closing time determined during initialization.
42	<b>Auto-w/manual-w info</b> 0.0 to 100.0 % of the span	Read only Auto mode: Indicates the applied automatic set point. Man mode: Indicates the applied manual set point.
43	<b>Firmware info control</b>	Read only Indicates the positioner type and current firmware version in alternating sequence.

## Annex

Code no.	Parameter – Readings/values [default setting]	Description
44	<b>y info</b> [0] to 100 %, OP, MAX, – – –	Read only  Indicates the control signal y in % in relation to the travel range determined during initialization.  MAX: The positioner builds up its maximum output pressure, see description in Code 14 and 15. OP: The positioner vents completely, see description in Code 14 and 15. – – –: The positioner is not initialized.
45	<b>Solenoid valve info</b> YES, HIGH/LOW, No	Read only  Indicates whether a solenoid valve is installed or not. If a voltage supply is connected at the terminals of the installed solenoid valve, YES and HIGH appear on the display in alternating sequence. If a voltage supply is not connected (actuator vented, fail-safe position indicated on the display by the S icon), YES and LOW appear on the display in alternating sequence.
46*	<b>Bus address</b> 16 to 251, ESC	Bus address  16 to 247: Positioners with fixed bus address 248 to 251: Positioners without fixed bus address (new or decommissioned positioners)
47*	<b>Write protection FF</b> YES, [No], ESC	When write protection is active, device data can be read using FF communication but not overwritten.
48*	<b>Diagnostic parameters ► EB 8389</b>	
49*		

## 11.5 Error codes

### Initialization errors

Error codes – Recommended action		Condensed state message active, when prompted, <b>Err</b> appears. When fault alarms exist, they are displayed here.
50	<b>x &gt; permissible range</b>	<p>Value of measuring signal too high or too low; the lever operates near its mechanical stops.</p> <ul style="list-style-type: none"> <li>• Pin not mounted properly</li> <li>• Bracket slipped in case of NAMUR attachment or positioner is off center.</li> </ul> <p>Follower plate not mounted properly.</p>
	Status classification	[Maintenance required]
	Recommended action	Check attachment and pin position, set operating mode from SAFE to MAN and re-initialize the positioner.
51	<b><math>\Delta x &lt; \text{permissible range}</math></b>	<p>Insufficient measuring span of the lever.</p> <ul style="list-style-type: none"> <li>• Pin not mounted properly</li> <li>• Wrong lever</li> </ul> <p>An angle of rotation smaller than 16° at the positioner shaft only generates an alarm. An angle below 9° leads to the initialization being canceled.</p>
	Status classification	[Maintenance required]
	Recommended action	Check attachment and re-initialize the positioner.
52	<b>Attachment</b>	<ul style="list-style-type: none"> <li>• Invalid positioner attachment</li> <li>• Rated travel/angle (Code 5) could not be achieved during NOM initialization (no tolerance downwards permissible).</li> <li>• Mechanical or pneumatic fault, e.g. wrong lever selected or supply pressure too low to move to the required position.</li> </ul>
	Status classification	[Maintenance required]
	Recommended action	<p>Check attachment and supply pressure. Re-initialize the positioner. Under certain circumstances, it may be possible to check the maximum travel/angle by entering the actual pin position and then performing a MAX initialization.</p> <p>After initialization has been completed, the Code 5 indicates the maximum achieved travel or angle.</p>

## Annex

Error codes – Recommended action		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
53	<b>Initialization time exceeded (Init time &gt;)</b>	<p>Initialization takes too long. The positioner returns to the previous operating mode.</p> <ul style="list-style-type: none"> <li>• No pressure in supply line or pneumatic leakage</li> <li>• Supply air failure during initialization</li> </ul>
	Status classification	[Maintenance required]
	Recommended action	Check attachment and supply air line. Re-initialize the positioner.
54	<b>Initialization – solenoid valve</b>	<ol style="list-style-type: none"> <li>1) A solenoid valve is installed (Code 45 = YES) and has not been connected or not properly. As a result, actuator pressure cannot build up. The alarm is generated when you attempt to initialize the positioner.</li> <li>2) If you attempt to initialize the positioner from the fail-safe position (SAFE).</li> </ol>
	Status classification	[Maintenance required]
	Recommended action	<ol style="list-style-type: none"> <li>1) Check connection and supply voltage of the solenoid valve (Code 45 High/Low).</li> <li>2) Set the MAN mode in Code 0. Re-initialize the positioner.</li> </ol>
55	<b>Transit time too short (transit time &lt;)</b>	Actuator transit times detected during initialization are so short that optimal positioner tuning is impossible.
	Status classification	[Maintenance required]
	Recommended action	Check the volume restriction setting. Re-initialize the positioner.
56	<b>Pin position</b>	Initialization canceled because selected NOM and SUB initialization modes require the pin position to be entered.
	Status classification	[Maintenance required]
	Recommended action	Enter pin position over Code 4 and rated travel/angle over Code 5. Re-initialize the positioner.

## Operational errors

<b>Error codes – Recommended action</b>		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
57	<b>Control loop</b>	<p>Control loop error, the valve no longer follows the controlled variable within tolerable times (tolerance band alarm Code 19).</p> <ul style="list-style-type: none"> <li>• Actuator blocked</li> <li>• Positioner attachment shifted subsequently</li> <li>• Supply pressure no longer suffices.</li> </ul>
	Status classification	[Maintenance required]
	Recommended action	Check attachment.
58	<b>Zero point</b>	<p>Zero point incorrect Error can occur when the positioner's attachment position is shifted or when the valve trim is worn, particularly with soft-sealed plugs.</p>
	Status classification	[Maintenance required]
	Recommended action	<p>Check valve and attachment of the positioner. If OK, perform a zero calibration over Code 6. We recommend to re-initialize the positioner if zero deviates by more than 5 %.</p>
59	<b>Auto-correction</b>	Errors in the positioner's data section are detected by automatic monitoring and corrected automatically.
	Status classification	[No message]
	Recommended action	Automatic
60	<b>Fatal error</b>	<p>Error in safety-relevant data that cannot be corrected automatically. Possible cause: EMC disturbances. The valve is moved to fail-safe position.</p>
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Reset over Code 36. Re-initialize the positioner.

## Hardware errors

Error codes – Recommended action		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
<b>62</b>	<b>x signal</b>	<p>Actuator's measured value recording failed. The conductive plastic element is defective. The device continues functioning in emergency mode but it must be replaced as quickly as possible. The emergency mode on the display is indicated by a blinking closed-loop operation icon and 4 dashes instead of the position reading.</p> <p><b>i Note</b></p> <p><b>Note on the open-loop operation:</b> If the measuring system has failed, the positioner is still in a reliable state. The positioner switches to emergency mode where the position cannot be accurately controlled anymore. However, the positioner continues operation according to its set point so that the process remains in a safe state.</p>
	Status classification	[Maintenance demanded]
	Recommended action	Return positioner to SAMSON AG for repair.
<b>64</b>	<b>i/p converter (y)</b>	Current circuit of i/p converter interrupted.
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Cannot be remedied. Return positioner to SAMSON AG for repair.

## Error appendix

Error codes – Recommended action		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
<b>65</b>	<b>Hardware</b>	<p>Initialization key jammed (firmware version R 1.51 and higher) A hardware error has occurred. The positioner changes to the fail-safe position (SAFE).</p>
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Confirm error and return to automatic mode or perform a reset and re-initialize the positioner. If this is not successful, return positioner to SAMSON for repair.
<b>66</b>	<b>Data memory</b>	No more data can be written to the memory, e.g. because written data deviate from read data. The valve moves to the fail-safe position.
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Return positioner to SAMSON AG for repair.

<b>67</b>	<b>Check calculation</b>	Hardware controller monitored by test calculation.
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Confirm error. If this is not possible, return positioner to SAMSON for repair.

## Data errors

<b>Error codes – Recommended action</b>		Condensed state message active, when prompted, <i>Err</i> appears. When fault alarms exist, they are displayed here.
<b>68</b>	<b>Control parameters</b>	Error in control parameters.
	Status classification	[Maintenance required]
	Recommended action	Confirm error, perform a reset and re-initialize the positioner.
<b>69</b>	<b>Potentiometer parameters</b>	Error in digital potentiometer parameters
	Status classification	[Maintenance required]
	Recommended action	Confirm error, perform a reset and re-initialize the positioner.
<b>70</b>	<b>Calibration</b>	Error in data from production calibration. The positioner continues operation with cold start values.
	Status classification	[Maintenance required]
	Recommended action	Return positioner to SAMSON AG for repair.
<b>71</b>	<b>General parameters</b>	Error in parameters not critical to control operation.
	Status classification	[Maintenance required]
	Recommended action	Confirm error. Check and, if necessary, change the settings of the required parameters.
<b>73</b>	<b>Internal device error 1</b>	Internal device error
	Status classification	[Maintenance required]
	Recommended action	Return positioner to SAMSON AG for repair.
<b>74</b>	<b>FF parameters</b>	Error in parameters not critical to control operation.
	Status classification	[Maintenance required]
	Recommended action	Confirm error and perform a reset.

## Annex

<b>Error codes – Recommended action</b>		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
76	<b>No emergency mode</b>	<p>The travel measuring system of the positioner has a self-monitoring function (see Code 62).</p> <p>An emergency mode (open-loop control) is not available for certain actuators, such as double-acting actuators. In case of a travel sensing error, the positioner vents the output (Output 38) or A1 in double-acting actuators. During the initialization, the positioner automatically checks whether the actuator has such a function or not.</p>
	Status classification	[No message]
	Recommended action	Merely information, confirm, if necessary. No further action required.
77	<b>Software loading error</b>	<p>When the positioner starts operation for the first time after the FF signal has been applied, it carries out a self-test (<b>tESTinG</b> runs across the display).</p> <p>If the positioner loads the wrong software, the valve moves to the fail-safe position. It is not possible to make the valve leave this fail-safe position again.</p>
	Status classification	Maintenance alarm (cannot be classified)
	Recommended action	Interrupt fieldbus signal and restart the positioner. If not successful, return positioner to SAMSON for repair.
78	<b>Option parameters</b>	Error in option parameters.
	Status classification	[Maintenance required]
	Recommended action	Return positioner to SAMSON AG for repair.

## Diagnosis errors

<b>Error codes – Recommended action</b>		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
79	<b>Diagnostic messages</b>	Messages generated by the extended diagnostics
	Status classification	Maintenance required (cannot be classified)
80	<b>Diagnostic parameters</b>	Error in parameters not critical to control operation.
	Status classification	Maintenance required (cannot be classified)
	Recommended action	Confirm error. Check and, if necessary, perform a new reference test.

<b>Error codes – Recommended action</b>		Condensed state message active, when prompted, <b><i>Err</i></b> appears. When fault alarms exist, they are displayed here.
81	<b>Reference graphs</b>	<p>Error occurred during plotting the reference graphs for drive signal y steady-state or drive signal y hysteresis.</p> <ul style="list-style-type: none"> <li>• Reference test canceled</li> <li>• Reference line for drive signal y steady-state or drive signal y hysteresis was not adopted.</li> </ul>
	Status classification	[No message]
	Recommended action	Check and, if necessary, perform a new reference test.

## 11.6 Decimal values of the modes in the FOUNDATION™ fieldbus blocks (Code 48)

Mode	Decimal value
AUTO	8
AUTO/CAS	12
AUTO/RCAS	134
O/S	128
MAN	16

## 11.7 Decimal values of the states in the FOUNDATION™ fieldbus blocks (Code 48)

Status	Decimal value
Good (NC) – Non-specific	128
Good (NC) – Active block alarm	132
Good (NC) – Active advisory alarm	136
Good (NC) – Active critical alarm	140
Good (NC) – Unack block alarm	144
Good (NC) – Unack advisory alarm	148
Good (NC) – Unack critical alarm	152
Uncertain – Non-specific	64

## Annex

Status	Decimal value
Uncertain – Last usable value	68
Uncertain – Substitute/manual entry	72
Uncertain – Initial value	76
Uncertain – Sensor conversion not accurate	80
Uncertain – Engineering unit range violation	84
Uncertain – Sub-normal	88
Good (C) – Non-specific	192
Good (C) – Initialization acknowledge	196
Good (C) – Initialization request	200
Good (C) – Not invited	204
Good (C) – Not selected	208
Good (C) – Local override	216
Good (C) – Fault state active	220
Bad – Non-specific	0
Bad – Configuration error	4
Bad – Not connected	8
Bad – Device failure	12
Bad – Sensor failure	16
Bad – No comm., with last usable value	20
Bad – No comm., no last usable value	24
Bad – Out of service	28

## 11.8 Selecting the characteristic


The characteristics that can be selected in Code 20 are shown in the following in graph form.

### i Note

A characteristic can only be defined (user-defined characteristic) using a workstation/operating software (e.g. TROVIS-VIEW).


#### Linear (select characteristic: 0)

Travel/angle [%]




#### Equal percentage (select characteristic: 1)

Travel/angle [%]




#### Reverse equal percentage (select characteristic: 2)


Travel/angle [%]




**SAMSON butterfly valve linear** (select characteristic: 3)  
Travel/angle [%]




**SAMSON butterfly valve equal percentage**  
(select characteristic: 4)  
Travel/angle [%]




**VETEC rotary plug valve linear** (select characteristic: 5)  
Travel/angle [%]




**VETEC rotary plug valve equal percentage**  
(select characteristic: 6)  
Travel/angle [%]



**Segmented valve ball linear** (select characteristic: 7)  
Travel/angle [%]



**Segmented valve ball equal percentage** (select characteristic: 8)  
Travel/angle [%]





## VDE Prüf- und Zertifizierungsinstitut

VDE Prüf- und Zertifizierungsinstitut • Medienstraße 28 • D-33955 Osnabrück  
Samson AG  
Mess- und Regeltechnik  
Weismüllerstrasse 3  
60314 Frankfurt

Ihr Zeichen:  
Herr Op  
2005-11-08  
Ihr Schreiben:  
Offenbach, 2005-11-21  
Unser Zeichen: Bitte angeben  
479000-90-0001/67325  
FG33/bh-wah  
Ansprechpartner:  
Herr Biehl  
Tel (069) 83 06-249  
Fax (069) 83 06-716  
gerhard.biehl@vde.com

**Prüfbericht**  
*zur Information des Auftraggebers*  
**Test Report for the Information of the applicant**

### Schutzarprüfung an Gehäusen für Stellungsregler

Typ 3730, 3731

Dieser Prüfbericht enthält das Ergebnis einer einmaligen Untersuchung an dem zur Prüfung vorgelegten Erzeugnis. Ein Muster dieses Erzeugnisses wurde geprüft, um die Übereinstimmung mit den nachfolgend aufgeführten Normen bzw. Teilen von Normen festzustellen.  
This test report contains the result of a single investigation carried out on the product submitted. A sample of this product was tested to find the accordance with the thereafter listed standards resp. parts of standards.

Der Prüfbericht berechtigt nicht zur Benutzung eines Prüfzeichens des VDE und des Zeichens "GS=geprüfte Sicherheit" und erstreckt sich nicht auf alle für das geprüfte Erzeugnis geltenden VDE-Bestimmungen.  
The test report does not entitle to use a VDE Certification mark and the "GS" = geprüfte Sicherheit (tested safety) "and does not refer to all VDE specifications applicable for the tested product.

Dieser Prüfbericht darf Dritten nur im vollen Wortlaut einschließlich dieser Vorbemerkung und unter Angabe des Ausstellungsorts zum Kenntnis gegeben werden.  
This test report may only be passed to a third party in its complete wording including this preamble and the date of issue.

Jede Veröffentlichung oder Vervielfältigung bedarf der vorherigen, schriftlichen Genehmigung des VDE Prüf- und Zertifizierungsinstituts.  
Any publication or reproduction requires the prior written approval of the VDE Testing and Certification Institute.

VDE VERBAND DER ELEKTROTECHNIK  
ELEKTRONIK INFORMATSTECHNIK e.V.

Nach dem Gesetz und Produktionsleistungsgesetz (GPSG) eingesetzte Stelle für technische Aufsicht und Zertifizierungsinstitut  
Testing and Certification Institute  
Von der Zulassungsbehörde der Elektrischen  
Mittel, das Gütesiegel der Elektrischen  
Vor Zulassungsbehörde für elektronische  
Produkte für Bauanwendungen und  
Von Zulassungsbehörde für Verwendung  
an Werkstätten der Elektrotechnik  
Von Zulassungsbehörde für die Anwendung  
im Haushalt und für die Anwendung  
in der Freizeit - IEC/IEC/CEC und  
CENELEC - Europa - Kommission für elektrische Normung - CCA, HAR, ENIC, MEDA  
.../2

VDE-FIRM 11-01-2015




Seite 2 - 21.11.2005      Unser Zeichen: 479000-90-0001/67325  
FG33/bh-wah

### 1 Aufgabe

An den unter Punkt 2 bezeichneten Prüfmuster wurde eine Prüfung auf Einhaltung der Schutzart IP66 durchgeführt.

### 2 Prüfmuster

2.1 Stellungsregler Typ 3730      2.2 Stellungsregler Typ 3731



### 3 Beurteilungsgrundlage

DIN EN 60529 (VDE 0470 Teil 1):2000-09  
Schutzarten durch Gehäuse (IP-Code)  
Deutsche Fassung EN 60529:1991 + A1:2000

### 4 Durchführung der Prüfung

Die Staubprüfung erfolgte bereits am Stellungsregler Typ 3731 unter Az.: 479000-90-0001/32752 und am Stellungsregler Typ 3731 unter Az.: 479000-90-0001/58865 mit Absaugung gemäß Kategorie 1 an den Anschlussgehäusen der Stellungsregler und der Magnetventile. Der Unterdruck betrug 2 kPa; die Prüfzeit 8 Stunden.



VDE VERBAND DER ELEKTROTECHNIK  
ELEKTRONIK INFORMATSTECHNIK e.V.

Nach dem Gesetz und Produktionsleistungsgesetz (GPSG) eingesetzte Stelle für technische Aufsicht und Zertifizierungsinstitut  
Testing and Certification Institute  
Von der Zulassungsbehörde der Elektrischen  
Mittel, das Gütesiegel der Elektrischen  
Vor Zulassungsbehörde für elektronische  
Produkte für Bauanwendungen und  
Von Zulassungsbehörde für die Anwendung  
im Haushalt und für die Anwendung  
in der Freizeit - IEC/IEC/CEC und  
CENELEC - Europa - Kommission für elektrische Normung - CCA, HAR, ENIC, MEDA  
.../3

VDE-FIRM 11-01-2015

Seite 3 - 21.11.2005

Unser Zeichen: 479000-9010-0001/67325  
FG33/bhl-wah**5 Prüfergebnis**

Für die unter 2 beschriebenen Prüfmuster wurde folgendes Ergebnis erzielt:

- Schutz gegen den Zugang zu gefährlichen Teilen und gegen feste Fremdkörper nach DIN EN 60529 (VDE 0470 Teil 1):2000-09 erfüllt
- Schutz gegen das Eindringen von Wasser nach DIN EN 60529 (VDE 0470 Teil 1):2000-09 erfüllt

Die Gehäuse der Stellungsregler erfüllen in den vorgestellten Ausführungen die Anforderungen an die Schutzart IP66.

In die Anschlussgehäuse drang weder Staub noch Wasser ein.

VDE Prüf- und Zertifizierungsinstitut  
Fachgebiet FG33

i. A. *M. Breit*  
i. A. *A. Breit*



VDE VERBAND DER ELEKTROTECHNIK  
ELEKTRONIK INFORMATIONSTECHNIK e.V.

Nach dem Gerät- und Produktsicherheitsgesetz (GPSG) "Zugelassene Stelle" für technische Auszubildende und Verbraucherschutz  
Technische Prüfstelle für elektronische, Verteilgeschaltete EDV's von Geräten.  
Von Herstellern und Importeuren für Versorgungsgarantie Produkte für Basis-Elektronik,  
Von Akkuschreibern im DACH nach DIN ISO/IEC 7025, DIN EN IEC 17025 und IEC 60079 abgedichtet:  
Akkuschreiber durch: TÜV Rheinland, GS, TÜV Nord, TÜV SÜD, TÜV NORD, CCA, HAR, INEC, E-MEDIA,  
CERTEC, Eurofins, Bureau Veritas, TÜV SÜD, TÜV NORD, GS, GS-C, GS-C-CE, GS-C-EMEA.



Physikalisch-Technische Bundesanstalt  
Braunschweig und Berlin  
Nationales Metrologieinstitut



(1) **EU-TYPE-EXAMINATION CERTIFICATE**  
(Translation)

- (2) Equipment or Protective Systems Intended for Use in  
Potentially Explosive Atmospheres - **Directive 2014/34/EU**  
(3) EU-Type Examination Certificate Number:

**PTB 04 ATEX 2109**

**Issue: 1**

- (4) Product: Positioner, type 3730-41..., 3730-51..., 3730-45..., 3730-55...  
(5) Manufacturer: SAMSON AG Mess- und Regeltechnik  
(6) Address: Weismüllerstraße 3, 60314 Frankfurt, Germany  
(7) This product and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.  
(8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and of the Council, dated 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential Test Report PTB Ex 17-25139.

- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:  
**EN 60079-0:2012/A11:2013 EN 60079-11:2012 EN 60079-31:2014**  
(10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate.  
(11) This EU-Type Examination Certificate relates only to the design and construction of the specified product in accordance to the Directive 2014/34/EU. Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate.  
(12) The marking of the product shall include the following:

**Ex II 2 G Ex ia IIC T6...T4 Gb and II 2 D Ex ia IIIC T80 °C Db or  
II 2 D Ex tb IIIC T80 °C Db**

Konformitätsbewertungsstelle, Sektor Explosionsschutz  
On behalf of PTB:

Braunschweig, May 11, 2017

ZSEx001e c

Dr.-Ing. F. Lienest  
Regierungsdirektor



sheet 1/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



(13)

## SCHEDULE

(14) EU-Type Examination Certificate Number PTB 04 ATEX 2109, Issue: 1

(15) Description of Product

The positioners of types 3730-41..., 3730-51..., 3730-45... and 3730-55... are communication-capable, bus-powered field devices which are used to assign a valve position to a control signal.

The bus interface connection (bus-coupling) can be performed according to the FISCO-concept for both specifications, Profibus PA and Foundation<sup>TM</sup> Fieldbus.

They are mounted onto levitation and slewing actuators. Non-flammable media are used as pneumatic auxiliary power. The equipment is intended for the application inside the hazardous area.

### Thermal and electrical maximum values

#### Type 3730-41 and 3730-51:

For relationship between temperature class and permissible ranges of the ambient temperature, reference is made to the following table:

Gas- or dust group	Temperature class	Permissible ambient temperature range
IIC	T6	-55 °C ... 60 °C
	T5	-55 °C ... 70 °C
	T4	-55 °C ... 80 °C
IIIC	not applicable	-55 °C ... 80 °C

For relationship between temperature class, permissible ranges of the ambient temperature, maximum short-circuit currents and maximum power for analyzing units with limit contacts (terminals 41/42), reference is made to the following table:

sheet 2/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

Temperature class	Permissible ambient temperature range	$I_0 / P_0$
T6	-55 °C ... 45 °C	52 mA / 169 mW
T5	-55 °C ... 60 °C	
T4	-55 °C ... 75 °C	
T6	-55 °C ... 60 °C	25 mA / 64 mW
T5	-55 °C ... 80 °C	
T4	-55 °C ... 80 °C	

BUS-connection-signal circuit .....type of protection Intrinsic Safety Ex ia IIC / IIB / IIIC  
(terminals 11/12) only for connection to a certified intrinsically safe circuit

For relationship between type of protection and electrical data, reference is made to the following table:

Maximum values:

FISCO power supply	FIELDBUS power supply general	
Ex ia IIC / IIB / IIIC	Ex ia IIC / IIIC	Ex ia IIB / IIIC
$U_i = 17,5 \text{ V DC}$	$U_i = 24 \text{ V DC}$	$U_i = 24 \text{ V DC}$
$I_i = 380 \text{ mA}$	$I_i = 360 \text{ mA}$	$I_i = 380 \text{ mA}$
$P_i = 5,32 \text{ W}$	$P_i = 1,04 \text{ W}$	$P_i = 2,58 \text{ W}$

$$C_i = 5 \text{ nF}$$
$$L_i = 10 \mu\text{H}$$

Limit contact, inductive .....type of protection Intrinsic Safety Ex ia IIC / IIIC  
(terminals 41/42) only for connection to a certified intrinsically safe circuit

Maximum values:

$$U_i = 16 \text{ V}$$
$$I_i = 52 \text{ mA}$$
$$P_i = 169 \text{ mW}$$

$$C_i = 60 \text{ nF}$$
$$L_i = 100 \mu\text{H}$$

resp.

sheet 3/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

$U_i = 16 \text{ V}$   
 $I_i = 25 \text{ mA}$   
 $P_i = 64 \text{ mW}$   
 $C_i = 60 \text{ nF}$   
 $L_i = 100 \mu\text{H}$

Forced deaeration.....type of protection Intrinsic Safety Ex ia IIC / IIIC  
(terminals 81/82) only for connection to a certified intrinsically safe circuit

Maximum values:

$U_i = 28 \text{ V}$   
 $I_i = 115 \text{ mA}$   
 $C_i = 5.3 \text{ nF}$   
 $L_i$  negligibly low

Binary input 1.....type of protection Intrinsic Safety Ex ia IIC / IIIC  
(terminals 87/88) for connection to an active contact circuit

Maximum values:

$U_i = 30 \text{ V}$   
 $I_i = 100 \text{ mA}$   
 $C_i$  negligibly low  
 $L_i$  negligibly low

Binary input 2.....type of protection Intrinsic Safety Ex ia IIC / IIB / IIIC  
(terminals 85/86) only for connection to a passive floating contact circuit

Maximum values:

$U_o = 5.88 \text{ V}$   
 $I_o = 1 \text{ mA}$   
 $P_o = 7.2 \text{ mW}$

For relationship between explosion group and permissible external capacitances and inductances, reference is made to the following table:

Ex ia IIC / IIIC	Ex ia IIB / IIIC
$C_o = 2 \mu\text{F}$	$C_o = 16 \mu\text{F}$
$L_o = 10 \text{ mH}$	$L_o = 1 \text{ H}$

sheet 4/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

C<sub>i</sub> negligibly low  
L<sub>i</sub> negligibly low

Serial Interface .....type of protection Intrinsic Safety Ex ia IIC / IIB / IIIC  
(programming socket BU)

Maximum values:

U<sub>o</sub> = 8.61 V  
I<sub>o</sub> = 55 mA  
P<sub>o</sub> = 250 mW

For relationship between type of protection and permissible external capacitances and inductances, reference is made to the following table:

Ex ia IIC / IIIC	Ex ia IIB / IIIC
C <sub>o</sub> = 0.61 µF	C <sub>o</sub> = 4 µF
L <sub>o</sub> = 9 mH	L <sub>o</sub> = 9 mH

resp.

only for connection to a certified intrinsically safe circuit

Maximum values:

U<sub>i</sub> = 16 V  
I<sub>i</sub> = 25 mA  
P<sub>i</sub> = 64 mW

C<sub>i</sub> negligibly low  
L<sub>i</sub> negligibly low

External position sensor .....type of protection Intrinsic Safety Ex ia IIC / IIIC  
(analog circuit board, pins p9, p10, p11)

Maximum values:

U<sub>o</sub> = 8.61 V  
I<sub>o</sub> = 55 mA  
P<sub>o</sub> = 250 mW

For relationship between type of protection and permissible external capacitances and inductances, reference is made to the following table:



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

Ex ia IIC / IIIC	Ex ia IIB / IIIC
$C_o = 0.61 \mu F$	$C_o = 4 \mu F$
$L_o = 9 \text{ mH}$	$L_o = 9 \text{ mH}$

$$C_i = 730 \text{ nF}$$
$$L_i = 370 \text{ } \mu\text{H}$$

Type 3730-45... und 3730-55...:

The permissible range of the ambient temperature for dust groupe IIIC is -55 °C ... 80 °C.

BUS-connection signal circuit .....	Nominal signal: 24 V DC
(Terminals 11/12).....	Rated voltage: 28 V
Binary input 1.....	Nominal signal: 6 ... 30 V DC
(Terminals 87/88) .....	Rated voltage: 30 V
Binary input 2.....	only for connection to a passive floating contact circuit
(Terminals 85/86).....	
Limit contact, inductive .....	Nominal signal: 8 V DC, 8 mA
(Terminals 41/42) .....	Rated voltage: 16 V
Forced deaeration.....	Nominal signal: 6 ... 24 V DC
(Terminals 81/82) .....	Rated voltage: 28 V

Changes against previous issue:

The changes concern the update of the applied standards, the electrical data, the adding of another type notation for dust ignition protection by enclosure, the implementation of dust ignition protection by Intrinsic Safety, the application of alternative gasket material of the enclosure and alternative construction of the enclosure.

(16) Test Report PTB Ex17-25139

(17) Specific conditions of use

none

sheet 6/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



Physikalisch-Technische Bundesanstalt  
Braunschweig und Berlin  
Nationales Metrologieinstitut



## SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

### (18) Essential health and safety requirements

Met by compliance with the aforementioned standards.

According to Article 41 of Directive 2014/34/EU, EC-type examination certificates which have been issued according to Directive 94/9/EC prior to the date of coming into force of Directive 2014/34/EU (April 20, 2016) may be considered as if they were issued already in compliance with Directive 2014/34/EU. By permission of the European Commission supplements to such EC-type examination certificates and new issues of such certificates may continue to hold the original certificate number issued before April 20, 2016.

Konformitätsbewertungsstelle, Sektor Explosionsschutz  
On behalf of PTB:

Dr.-Ing. F. Lienesch

Regierungsdirektor



Braunschweig, May 11, 2017

sheet 7/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



Physikalisch-Technische Bundesanstalt  
Braunschweig und Berlin  
Nationales Metrologieinstitut



(1)

## CONFORMITY STATEMENT (Translation)

- (2) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres - **Directive 2014/34/EU**

- (3) Test Certificate Number:

**PTB 05 ATEX 2010 X**

**Issue: 1**

- (4) Product: Positioner type 3730-48... and 3730-58...  
(5) Manufacturer: SAMSON AG Mess- und Regeltechnik  
(6) Address: Weismüllerstraße 3, 60314 Frankfurt, Germany  
(7) This product and any acceptable variation thereto are specified in the schedule to this certificate and the documents therein referred to.  
(8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and of the Council, dated 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential test report PTB Ex 17-25140.

- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:  
**EN 60079-0:2012/A11:2013 EN 60079-15:2010 EN 60079-31:2014**

- (10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to special conditions for safe use specified in the schedule to this certificate.  
(11) This Conformity Statement relates only to the design and construction of the specified product in accordance with Directive 2014/34/EU. Further requirements of this Directive apply to the manufacture and supply of this product.  
(12) The marking of the product shall include the following:



**II 3 G Ex nA IIC T6 Gc bzw. II 3 D Ex tc IIIC T80 °C Dc**

Konformitätsbewertungsstelle, Sektor Explosionsschutz  
On behalf of PTB

Braunschweig, June 22, 2017

Dr.-Ing. F. Lieneck  
Regierungsdirektor

Sheet 1/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

(13)

## SCHEDULE

(14)

### CONFORMITY STATEMENT PTB 05 ATEX 2010 X, Ausgabe: 1

(15) Description of the product

The positioners of types 3730-48... and 3730-58... are communication-capable, bus-powered field devices which are used to assign a valve position to a control signal.

They are mounted onto levitation and slewing actuators. Non-flammable media are used as pneumatic auxiliary power. The equipment is intended for the application inside the hazardous area.

Thermal and electrical maximum values:

The permissible ambient temperature range for dust group IIIC is between -55 °C ... 80 °C.

For the relationship between temperature class and permissible ranges of the ambient temperature for gas group IIC reference is made to the following table:

Temperature class	permissible ambient temperature range
T6	-55 °C ... 60 °C
T5	-55 °C ... 70 °C
T4	-55 °C ... 80 °C

BUS-connection signal circuit ..... Nominal signal: 24 V DC  
(Terminals 11/12) Rated voltage: 28 V

Binary input 1..... Nominal signal: 6 ... 30 V DC  
(Terminals 87/88) Rated voltage: 30 V

Binary input 2..... only for connection to a passive floating contact circuit  
(Terminals 85/86)

Limit contact, inductive ..... Nominal signal: 8 V DC, 8 mA  
(Terminals 41/42) Rated voltage: 16 V

Forced deaeration..... Nominal signal: 6 ... 24 V DC  
(Terminals 81/82) Rated voltage: 28 V

Sheet 2/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 05 ATEX 2010 X, Issue: 1

Changes against previous issue:

The changes concern the update of the applied standards, the electrical data, the cancelation of type of protection "nL", the adding of dust ignition protection by enclosure, the application of alternative gasket material of the enclosure and alternative construction of the enclosure.

- (16) Test report PTB Ex 17-25139

- (17) Specific conditions of use

The program-interface intended for connection to the positioners of types 3730-48... and 3730-58... shall be installed outside of the hazardous area.

For type of protection "nA" applies:

If the program-interface adaptor is connected to a circuit of type of protection "nA" a fuse according to IEC 60127-2/II, 250 V F or according to IEC 60127-2/VI, 250 V T with a nominal fuse current of max.  $I_N \leq 40$  mA shall be connected in series to the Vcc-circuit. The fuse shall be arranged outside of the hazardous area.

- (18) Essential health and safety requirements

Met by compliance with the aforementioned harmonized standards.

According to Article 41 of Directive 2014/34/EU, Conformity Statements which have been issued according to Directive 94/9/EC prior to the date of coming into force of Directive 2014/34/EU (April 20, 2016) may be considered as if they were issued already in compliance with Directive 2014/34/EU. By permission of the European Commission supplements to such Conformity Statements and new issues of such certificates may continue to hold the original certificate number issued before April 20, 2016.

Konformitätsbewertungsstelle Sektor Explosionsschutz  
On behalf of PTB

Braunschweig, June 22, 2017

Dr.-Ing. F. Lieresch  
Regierungsdirektor



Sheet 3/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt.  
In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



Member of the FM Global Group

FM Approvals  
1151 Boston-Providence Turnpike  
P.O. Box 9102 Norwood, MA 02062 USA  
T: 781 762 4300 F: 781 762 9375 www.fmglobal.com

# CERTIFICATE OF COMPLIANCE

## HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT

This certificate is issued for the following equipment:

**3730-43-abcdef. Profibus PA Positioner**

**3730-53-abcdef. Foundation FF Positioner**

IS / I,II,III / 1 / ABCDEFG / T6 Ta = 60°C - Addendum to EB Addendum to EB 8384-5 EN, pages 7 to 12; Entity/FISCO; Type 4X

I / 0 / AEx ia IIC / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 7 to 12; Type 4X

NI / I / 2 / ABCD / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 10 to 12; Nonincendive Field Wiring/FNINCO; Type 4X; S / II,III / 2 / FG / T6 Ta = 60°C; Type 4X

I / 2 / Ex nA / nL IIC / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 10 to 12; Nonincendive Field Wiring/FNINCO; Type 4X

### Entity/FISCO Parameters:

*Foundation-Fieldbus Signal Terminals Group A/B (IIC)*

Vmax (Ui) = 24V, Imax (li) = 360mA, Pmax (Pi) = 1.04W, Ci = 5nF, Li = 10µH

*Profibus-Fieldbus Signal Terminals Group C, D (IIB)*

Vmax (Ui) = 24V, Imax (li) = 380mA, Pmax (Pi) = 2.58W, Ci = 5nF, Li = 10µH

*Profibus-Fieldbus Signal Circuit Terminals Group A/B (IIC)*

Vmax (Ui) = 17.5Vdc, Imax (li) = 380mA, Pmax (Pi) = 5.32W, Ci = 5nF, Li = 10µH

### Nonincendive Field Wiring/FNINCO Parameters:

*Foundation-Fieldbus Signal Terminals Group A/B (IIC)*

Vmax (Ui) = 30V or 32V, Imax (li) = 152mA or 130mA, Pmax (Pi) = 1.14W, Ci = 5nF, Li = 10µH

*Profibus-Fieldbus Signal Terminals Group C, D (IIB)*

Vmax (Ui) = 30V or 32V, Imax (li) = 379mA or 324mA, Pmax (Pi) = 3.85W or 2.77W, Ci = 5nF, Li = 10µH

### Inputs & Outputs:

*Limit Switches Terminals (Entity/FISCO):*

Vmax (Ui) = 16V, Imax (li) = 25mA, Pmax (Pi) = 64mW, Ci = 30nF, Li = 100µH

Vmax (Ui) = 16V, Imax (li) = 52mA, Pmax (Pi) = 169mW, Ci = 30nF, Li = 100µH

*Limit Switches Terminals (Nonincendive Field Wiring/ FNINCO):*

Vmax (Ui) = 20V, Imax (li) = 25mA, Pmax (Pi) = 64mW, Ci = 60nF, Li = 100µH

*Force Venting Function Terminals 81/82 (Entity/FISCO):*

Vmax (Ui) = 28V, Imax (li) = 115mA, Pmax (Pi) = 0.5W, Ci = 5.3nF, Li = 0



Member of the FM Global Group

*Force Venting Function Terminals 81/82 (Nonincendive Field Wiring/FNINCO):*  
Vmax (Ui) = 30V, I<sub>max</sub> (Ii) = 100mA, P<sub>max</sub> (Pi) = 0.75W, C<sub>i</sub> = 5.3nF, L<sub>i</sub> = 0

*Binary Inputs 1 & 2 Terminals (Entity/FISCO/Nonincendive Field Wiring/ FNINCO):*  
Vmax (Ui) = 30V, I<sub>max</sub> (Ii) = 100mA, P<sub>max</sub> (Pi) = 0.75W, C<sub>i</sub> = 0, L<sub>i</sub> = 0  
V<sub>oc</sub> (Ui) = 5.88V, I<sub>max</sub> (Ii) = 1mA, P<sub>max</sub> (Pi) = 7.2mW, C<sub>a</sub> = 2μF, L<sub>a</sub> = 10mH

*Serial Interface Active & Passive Plugs (Entity/FISCO/Nonincendive Field Wiring/ FNINCO):*  
V<sub>oc</sub> (Ui) = 8.61V, I<sub>sc</sub> (Ii) = 55mA, P<sub>max</sub> (Pi) = 250mW, C<sub>a</sub> = 0.61μF, L<sub>a</sub> = 9mH  
Vmax (Ui) = 16V, I<sub>sc</sub> (Ii) = 25mA, P<sub>max</sub> (Pi) = 64mW, C<sub>i</sub> = 0, L<sub>i</sub> = 0

a = Inductive proximity switches: 0 (without proximity switch) or 1 (with proximity switch).  
b = Force venting function (solenoid Valve): 0 (not provided) or 4 (provided).  
c = Vibration Sensor: 0 (not provided) or 2 (provided).  
d = Binary input: 0 (not provided) or 3 (provided).  
e = External position sensor: 0 (not provided) or 1 (provided).  
f = Connections: Pneumatic connections, electrical connections, 1+2 m 20 x1.5 (plastic) or  
1 + 5 = M 20 x 1.5 (metal).

#### Equipment Ratings:

evaluated as Intrinsically Safe electrical apparatus with Entity/FISCO parameters for use in Class I, II, III, Division 1, Groups A, B, C, D, E, F and G; alternatively for Class I, Zone 0, AEx ia Group IIC; Temperature Class T6 Ta = 60°C in accordance with control drawing Addendum to EB 8384-5 EN, pages 7 to 12; Nonincendive electrical apparatus with nonincendive field wiring/FNINCO for use in Class I, Division 2, Groups A, B, C and D; Suitable for Class II, III, Division 2, Groups F and G Temperature Class T6 Ta = 60°C; alternatively for Class I, Zone 2, Ex nA / nL Group IIC; Temperature Class T6 Ta = 60°C in accordance with control drawing Addendum to EB 8384-5 EN, pages 10 to 12; indoor/outdoor Type 4X hazardous (classified) Locations.

#### Approved for:

Samson AG  
Postfach 101901 D-60314 Frankfurt, Germany



This certifies that the equipment described has been found to comply with the following FM Approval Standards and other documents:

Class 3600	1998
Class 3610	1999
Class 3611	2004
Class 3810	2005
ANSI/NEMA 250	1991

Original Project ID: 3023605

FM Approval Granted: September 5, 2005

Subsequent Revision Reports / Date FM Approval Amended

Report Number	Date	Report Number	Date
3025274	October 26, 2005		

FM Global Technologies LLC

A handwritten signature of Timothy Adam over a solid horizontal line.

Timothy Adam  
Technical Team Manager  
FM Approvals

31<sup>st</sup> October, 2005  
Date



# Certificate of Compliance

**Certificate:** 1675804

**Master Contract:** 173246 (LR 54227)

**Project:** 70136714

**Date Issued:** 2017-05-23

**Issued to:** Samson AG  
Mess- Und Regeltechnik  
Weismuellerstrasse 3  
Frankfurt, 60314  
GERMANY

**Attention:** Tomislav Varga

*The products listed below are eligible to bear the CSA Mark shown*



**Issued by:**

A handwritten signature in black ink that reads 'R Papiah'.

R Papiah

## PRODUCTS

**CLASS 2258 04 - PROCESS CONTROL EQUIPMENT** - Intrinsically Safe Entity - For Hazardous Locations

**Ex ia IIC T6**

**Class I, Division 1, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Type 4 Enclosure**

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C; Intrinsically safe when installed per Samson AG installation drawing EB8384-5 EN.

**CLASS 2258 03 - PROCESS CONTROL EQUIPMENT** - Intrinsically Safe and Non-Ionic Systems - For Hazardous Locations

**Ex nL IIC T6**

**Class I, Division 2, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Class III; Type 4 Enclosure**

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C; Energy-limited (Non-ionic) when installed per Samson AG installation drawing EB8384-5 EN.



**Certificate:** 1675804 (LR 54227)  
**Project:** 70136714

**Master Contract:** 173246  
**Date Issued:** 2017-05-24

#### CLASS 2258 02 - PROCESS CONTROL EQUIPMENT - For Hazardous Locations

**Ex nA II T6**

**Class I, Division 2, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Class III; Type 4 Enclosure**

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C. Refer to installation EB 8384-5 EN for electrical ratings.

#### Condition of acceptability

The Model 3730-53 must be installed per SAMSON AG installation drawing EB8384-5 EN.

#### APPLICABLE REQUIREMENTS

- |                             |   |   |
|-----------------------------|---|---|
| CSA Std C22.2 No. 25-1966   | - | Enclosures for Use in Class II, Groups E, F and G Hazardous Locations                 |
| CAN/CSA-C22.2 No. 94-M91    | - | Special Purpose Enclosures  |
| CSA Std C22.2 No. 142-M1987 | - | Process Control Equipment   |
| CAN/CSA-C22.2 No.157-92     | - | Intrinsically Safe and Non-Incendive Equipment for Use in Hazardous Locations         |
| CSA Std C22.2 No. 213-M1987 | - | Non-Incendive Electrical Equipment for Use in Class I, Division 2 Hazardous Locations |
| CAN/CSA-E60079-0:02         | - | Electrical Apparatus for Explosive Atmospheres, Part 0 - General Requirements         |
| CAN/CSA-E60079-11:02        | - | Electrical Apparatus for Explosive Atmospheres, Part 11 - Intrinsic Safety "i"        |
| CAN/CSA-E60079-15:02        | - | Electrical Apparatus for Explosive Atmospheres, Part 15 – Type of Protection "n"      |



**Certificate:** 1675804 (LR 54227)

**Project:** 70136714

**Master Contract:** 173246

**Date Issued:** 2017-05-24

### **MARKINGS**

Marking nameplate shall bear the following information:

- CSA Monogram;
- Submitter Identification;
- Model number;
- Serial number or date code;
- Electrical Rating/Entity Parameters
- Hazardous Location Designation;
- Reference to installation drawing number.
- The caution: "Warning - Substitution of Components May Impair Intrinsic Safety";
- Temperature Code Rating
- Maximum ambient
- Year and Certificate Number followed by an indicator 'X'



## *Supplement to Certificate of Compliance*

**Certificate:** 1675804

**Master Contract:** 173246 (LR 54227)

*The products listed, including the latest revision described below,  
are eligible to be marked in accordance with the referenced Certificate.*

### **Product Certification History**

<b>Project</b>	<b>Date</b>	<b>Description</b>
70136714	2017-05-24	Addition of a new window construction
1675804	2006-06-01	Correction – originally issued January 30, 2006
1675804	2006-01-30	Original Certification.

**Installation Manual for apparatus certified by CSA for use in hazardous locations.**

Communication is optionally either according to the **FOUNDATION<sup>TM</sup>** Fieldbus Specification or according to **PROFIBUS PA** in compliance **FISCO-Concept**

The **FISCO Concept** allows interconnection of intrinsically safe apparatus to associated apparatus not specifically examined in such combination. The criteria for interconnection is that the voltage (**V<sub>max</sub>**) the current (**I<sub>max</sub>**) and the power (**P<sub>max</sub>**) which intrinsically safe apparatus can receive and remain intrinsically safe, considering faults, must be equal or greater than the voltage (**V<sub>oc</sub>**) the current (**I<sub>sc</sub>**) and the power (**P<sub>0</sub>**) levels which can be delivered by the associated apparatus, considering faults and applicable factors. In addition, the maximum unprotected capacitance (**C<sub>i</sub>**) and inductance (**L<sub>i</sub>**) of each apparatus (other than the termination) connected to the fieldbus must be less than or equal to **5 nF** and **10 µH** respectively.

In each segment only one active device, normally the associated apparatus, is allowed to provide the necessary energy for the fieldbus system. The allowed voltage (**V<sub>oc</sub>**) of the associated apparatus is limited to the range of

**14V DC. to 24V DC.** All other equipment connected to the bus cable has to be passive, meaning that they are not allowed to provide energy to the system, except to a leakage current of 50mA for each connected device. Separately powered equipment needs a galvanic isolation to assure that the intrinsically safe fieldbus circuit remains passive.

The cable used to interconnect the devices need to have the parameters in the following range:

Loop resistance R' :	15 ... 150 Ohm/km
Inductance per unit length L' :	0,4 ... 1 mH/km
Capacitance per unit length C' :	80 ... 200 nF/km
C' = C' line/line + 0,5 C' line/screen, if both lines are floating or, C' = C' line/line + C' line/screen, if the screen is connected to one line	
Length of spur cable:	≤ 30 m
Length of trunk cable:	≤ 1 km

At each end of the trunk cable an approved infallible line termination with the following parameters is suitable:

$$R = 90 \dots 100 \text{ Ohm} \quad C = 0 \dots 2,2 \mu\text{F}$$

One of the allowed terminations might already be integrated in the associated apparatus.

The number of passive devices connected to the bus segment is not limited due to I.S. reasons. If the above rules are respected, the inductance and capacitance of the cable will not impair the intrinsic safety of the installation.

**Notes:**

1. Approved associated apparatus must be installed in accordance with manufacturer instructions
2. Approved associated apparatus must meet the following requirements:  
 $V_{oc} \leq V_{max}$ ,  $I_{sc} \leq I_{max}$ ,  $P_0 \leq P_{max}$
3. The maximum non-hazardous area voltage must not exceed 250 V.
4. The installation must be in accordance with the Canadian Electrical code Part 1.
5. Each set of wires must be provided with grounded shield. The shield must extend as close to the terminal(s) as possible and it must be grounded shield at I. S. Barrier ground.
6. Caution: Use only supply wires suitable for 5 °C above surrounding.
7. Warning: Substitution of components may impair intrinsic safety. PE = I. S. Ground
8. The polarity for connecting 11 and 12 is of no importance due to an internal rectifier.
9. FISCO concept applies to fieldbus / circuit only.
10. Entity parameters apply to circuit 2, 3 and 4 and further required to meet the following conditions:  
 $C_o \geq C_i + C_{cable}$ ;  $L_o \geq L_i + L_{cable}$

Intrinsically safe if installed as specified in manufacturer's installation manual.


CSA- certified for hazardous locations

Ex ia IIC; Class I, Zone 0

Class I; Groups A, B, C, D

Class II, Groups E, F + G; Class III.

Type 4 Enclosure



**Revisions Control No. 0: March,2005**  
**Revisions Control No. 1: Nov. 2012**

**Addendum to EB 8384-4 EN**  
**and EB 8384-5 EN**

**Table 1: Maximum values**

	Fieldbus		Limit-switches inductive	Forced venting- function	Binary- input		Serial-Interface	
	Foundation	Profibus			1	2	active	passive
Circuit No.	1	1	2	3	4	5	6	6
Terminal No.	11 / 12	11 / 12	41 / 42	81 / 82	87 and 88	85 and 86	plug	
Groups	A, B IIC	C, D IIB	A, B, C, D IIC / IIB	#/#	#/#	#/#	#/#	#/#
V <sub>max</sub> [ V ]	24		17,5	16	28	30	V <sub>0C</sub> 5,88	V <sub>0C</sub> 8,61
I <sub>max</sub> [ mA ]	360	380	380	25	115	100	I <sub>SC</sub> 1	I <sub>SC</sub> 55
P <sub>max</sub> [ W ]	1,04	2,58	5,32	64 mW	##	##	7,2 mW	250 mW
C <sub>i</sub> [ nF ]	5			60	5,3	0	2µF	0,61µF
L <sub>i</sub> [ µH ]	10			100	0	0	10mH	9mH

**Binary- input 1:** For connection of an active signal circuit

**Binary- input 2:** For connection of an passive contact circuit directly on the control valve, e.g.  
passive pressure switch for leakage monitoring

**Notes:**

- Entity parameters must meet the following requirements:  
 $V_{0C} \leq V_{max}$ ,  $I_{SC} \leq I_{max}$ ,  $P_0 \leq P_{max}$   
 $C_0$  or  $C_a \geq C_i + C_{cable}$  and  $L_0$  or  $L_a \geq L_i + L_{cable}$
- Install in accordance with the Canadian Electrical Code Part I
- Cable entry M 20 x1,5 or metal conduit acc. to dwg. No. 1050-0540

**Table 2: CSA – certified barrier parameters of circuit 4**

Barrier	Supply barrier		Evaluation barrier	
	V <sub>0C</sub>	R <sub>min</sub>	V <sub>0C</sub>	R <sub>min</sub>
circuit 3	≤28V	≥245Ω	≤28V	Diode
circuit 4	≤30V	≥300Ω	≤30V	Diode

The correlation between temperature classification and permissible ambient temperature ranges is shown in the table 3 below:

Table 3:

Temperature class	Permissible ambient temperature range
T6	+60°C
T5	-40°C ≤ T <sub>a</sub> ≤ +70°C
T4	+80°C


Table 4:

	Foundation Fieldbus or Profibus PA (see PTB Certificate PTB 05 ATEX 2010 X)						Limit-switches (inductive)	Forced venting function	Binary- Input 1	Maximum values for serial-interface and binary input 2 see table 1
Terminal	11 / 12						41 / 42	81 / 82	87 / 88	
Groups	A, B and IIC			C, D and IIB			#/#	#/#	#/#	
V <sub>max</sub>	20V DC	24V DC	30V DC	20V DC	24V DC	30V DC	20V	30V	30V	
I <sub>max</sub>	464 mA	261 mA	152 mA	1,17 A	650 mA	379 mA	25mA	100mA	100mA	
P <sub>max</sub>	2,32	1,56	1,14	5,88	3,89	3,85	64mW	##	##	
C <sub>i</sub>	5nF						60	5,3	0	
L <sub>i</sub>	10μH						100	0	0	

CSA certified for hazardous locations:

Ex nA II; Ex nL IIC; Zone 2  
 Class II, Div. 2; Groups A, B, C, D  
 Class II, Div. 2 Groups E, F + G; Class III


Type 4 Enclosure



Revisions Control No. 0: March.2005  
 Revisions Control No. 1: Nov. 2012

Addendum to EB 8384-4 EN  
 and EB 8384-5 EN

**Installation drawing Control Relay KHA5-OTI/Ex2, KHA6-OTI/Ex1 or  
KHA6-OTI/Ex2 with Model SJ-b-N Proximity Sensors**



The total series inductance and shunt capacitance of shield wiring shall be restricted to the following maximum values

maximum capacitance of each inductive sensor 30nF  
maximum inductance of each inductive sensor 100 $\mu$ H

**System parameters**

Control Relay Terminal No.	Groups	L [mH]	C [ $\mu$ F]	V <sub>0C</sub> [V]	I <sub>SC</sub> [mA]	V <sub>max</sub> [V]	R <sub>min</sub> [ $\Omega$ ]
1-3; 2-3 4-6; 5-6	A + B	192	2,66	10,5	13	10,5	811
	C + E	671	7,9				
	D, F, G	1000	21,3				

Division 2 wiring method shall be in accordance to the Canadian Electrical Code Part 1.

**Revisions Control No. 0: March.2005  
Revisions Control No. 1: Nov. 2012**

Addendum to EB 8384-4 EN  
and EB 8384-5 EN

**Installation Manual for apparatus approved by FM for use in hazardous locations.**

Communication is optionally either according to the **FOUNDATION™** Fieldbus Specification or according to **PROFIBUS PA** in compliance **FISCO-Concept**

The **FISCO Concept** allows interconnection of intrinsically safe apparatus to associated apparatus not specifically examined in such combination. The criteria for interconnection is that the voltage ( $V_{max}/U_i$ ) the current ( $I_{max}/I_i$ ) and the power ( $P_i$ ) which intrinsically safe apparatus can receive and remain intrinsically safe, considering faults, must be equal or greater than the voltage ( $V_{0C}/U_0$ ) the current ( $I_{SC}/I_0$ ) and the power ( $P_0$ ) levels which can be delivered by the associated apparatus, considering faults and applicable factors. In addition, the maximum unprotected capacitance ( $C_i$ ) and inductance ( $L_i$ ) of each apparatus (other than the termination) connected to the fieldbus must be less than or equal to 5 nF and 10 µH respectively.

In each segment only one active device, normally the associated apparatus is allowed to provide the necessary energy for the fieldbus system. The allowed voltage ( $V_{0C}/U_0$ ) of the associated apparatus is limited to the range of 14V DC. to 24V DC. All other equipment connected to the bus cable has to be passive, meaning that they are not allowed to provide energy to the system, except to a leakage current of 50mA for each connected device. Separately powered equipment needs a galvanic isolation to assure that the intrinsically safe fieldbus circuit remains passive.

The cable used to interconnect the devices need to have the parameters in the following range:

Loop resistance $R'$ :	15 ... 150 Ohm/km
Inductance per unit length $L'$ :	0,4 ... 1 mH/km
Capacitance per unit length $C'$ :	80 ... 200 nF/km
$C' = C'$ line/line + 0,5 $C'$ line/screen, if both lines are floating or, $C' = C'$ line/line + $C'$ line/screen, if the screen is connected to one line	
Length of spur cable:	≤ 30 m
Length of trunk cable:	≤ 1 km

At each end of the trunk cable an approved infallible line termination with the following parameters is suitable:

$$R = 90 \dots 100 \text{ Ohm} \quad C = 0 \dots 2,2 \mu\text{F}$$

One of the allowed terminations might already be integrated in the associated apparatus.

The number of passive devices connected to the bus segment is not limited due to I.S. reasons. If the above rules are respected, the inductance and capacitance of the cable will not impair the intrinsic safety of the installation.

**Notes:**

1. Approved associated apparatus must be installed in accordance with manufacturer instructions
2. Approved associated apparatus must meet the following requirements:  
**U<sub>o</sub> or V<sub>oc</sub> ≤ U<sub>i</sub> or V<sub>max</sub>, I<sub>o</sub> or I<sub>sc</sub> ≤ I<sub>i</sub> or I<sub>max</sub>, P<sub>o</sub> ≤ P<sub>i</sub> or P<sub>max</sub>**
3. The maximum non-hazardous area voltage must not exceed 250 V.
4. The installation must be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.06.01
5. Each set of wires must be provided with grounded shield. The shield must extend as close to the terminal(s) as possible and it must be grounded shield at I. S. Barrier ground.
6. Caution: Use only supply wires suitable for 5 °C above surrounding.
7. Warning: Substitution of components may impair intrinsic safety. PE = I. S. Ground
8. The polarity for connecting 11 and 12 is of no importance due to an internal rectifier.
9. FISCO concept applies to fieldbus / circuit only.
10. Entity parameters apply to circuit 2, 3 and 4 and further required to meet the following conditions:  
**C<sub>0</sub> ≥ C<sub>i</sub> + C<sub>cable</sub>; L<sub>0</sub> ≥ L<sub>i</sub> + L<sub>cable</sub>**


Intrinsically safe if installed as specified in manufacturer's installation manual.

FM- approved for hazardous locations

Class I, Zone 0 AEx ia IIC T6:

Class I, II, III Div. 1, Groups A, B, C, D, E, F + G.

Field enclosure NEMA 4X



Revisions Control No. 0: March.2005

Addendum to EB 8384-5 EN

**Table 1: Maximum values**

	Fieldbus			Limit-switches inductive	Forced venting- function	Binary- input		Serial-Interface	
	Foundation		Profibus			1	2	active	passive
Circuit No.	1		1	2	3	4	5	6	6
Terminal No.	11 / 12		11 / 12	41 / 42	81 / 82	87 / 88	85 / 86	plug	
Groups	A, B IIC	C, D IIB	A, B, C, D IIC / IIB	#/#	#/#	#/#	#/#	#/#	#/#
Ui or V <sub>max</sub> [ V ]	24		17,5	16	28	30	V <sub>0C</sub> 5,88	V <sub>0C</sub> 8,61	V <sub>max</sub> 16
Ii or I <sub>max</sub> [ mA ]	360	380	380	25	115	100	I <sub>SC</sub> 1	I <sub>SC</sub> 55	I <sub>max</sub> 25
Pi or P <sub>max</sub> [ W ]	1,04	2,58	5,32	64 mW	##	##	7,2 mW	250 mW	64 mW
C <sub>i</sub> [ nF ]	5			60	5,3	0	2μF	0,61μF	0
L <sub>i</sub> [ μH ]	10			100	0	0	10mH	9mH	0

**Binary- input 1:** For connection of an active signal circuit

**Binary- input 2:** For connection of an passive contact circuit directly on the control valve, e.g.  
passive pressure switch for leakage monitoring

**Notes:**

1. Entity parameters must meet the following requirements:  
 $U_0 \leq U_i \text{ or } V_{max}$ ,  $I_0 \leq I_i \text{ or } I_{max}$ ,  $P_0 \leq P_i \text{ or } P_{max}$ ;  $C_0 \text{ or } C_a \geq C_{cable}$  and  $L_0 \text{ or } L_a \geq L_{i} + L_{cable}$
2. The installation must be in accordance with the National Electrical Code  
ANSI/NFPA 70 and ANSI/ISA RP 12.06.01
3. Cable entry M 20 x1,5 or metal conduit acc. to dwg. No. 1050-0540

**Table 2: FM – approved barrier parameters of circuit 4**

Barrier	Supply barrier				Evaluation barrier	
	V <sub>0C</sub>	R <sub>min</sub>	I <sub>0C</sub>	P <sub>max</sub>	V <sub>0C</sub>	R <sub>min</sub>
circuit 3	≤28V	≥245Ω	≤115mA	##	≤28V	Diode
circuit 4	≤30V	≥300Ω	≤100mA	##	≤30V	Diode

The correlation between temperature classification and permissible ambient temperature ranges is shown in the table 3 below:

Table 3:


Temperature class	Permissible ambient temperature range
T6	+60°C
T5	-40°C ≤ T <sub>a</sub> ≤ +70°C
T4	+80°C

Table 4:


	Foundation Fieldbus or Profibus PA (Non incendive Field wiring)								Limit-switches (inductive)	Forced venting function	Binary- Input 1	Maximum values for serial-interface and binary input 2 see table 1
Terminal	11 / 12								41 / 42	81 / 82	87 / 88	
Groups	A, B and IIC				C, D and IIB				#/#	#/#	#/#	
Ui or V <sub>max</sub> [VDC]	20V	24V	30V	32V	20V	24V	30V	32V	20V	30V	30V	
Ii or I <sub>max</sub> [mA]	464	261	152	130	1,117 A	650	379	324	25mA	100mA	100mA	
Pi or P <sub>max</sub> [W]	2,32	1,56	1,14	1,14	5,88	3,89	3,85	2,77	64mW	##	##	
Ci	5nF								60	5,3	0	
Li	10µH								100	0	0	

Ex nA II T6; Ex nL IIC T6 Zone 2.  
Class I, II, Div. 2 Groups A, B, C, D, E+F.

## Field enclosure NEMA 4X



**Installation drawing Control Relay KHA5-OTI/Ex2, KHA6-OTI/Ex1 or  
KHA6-OTI/Ex2 with Model SJ-b-N Proximity Sensors**



maximum capacitance of each inductive sensor 30nF  
maximum inductance of each inductive sensor 100 $\mu$ H

**Model designation code Type Khab – cExde**

a= Supply Voltage type A or D  
a=AC, d=DC  
b= Supply Level  
2=24V DC $\pm$ 15%; 5=120V AC +10%–15%;  
6=230V AC+10%–15%;  
c= Output type RTA/; RW1/; SS1/; SS2/; RS1/;  
SR/; ST-or SOT  
d= Number of channels 1 or 2  
e= Power rail designation, P, 2S.P or GS.P  
(includes Model KHD2-EB-PB Power Feed  
Module) or Blank

Each pair of I.S. wires must be protected by a shield that is grounded at the I.S. Ground. The shield must be extend as close to the terminals as possible installation shall be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.06.01.

The total series inductance and shunt capacitance of shield wiring shall be restricted to the following maximum values

**System parameters**

Control Relay Terminal No.	Groups	L [mH]	C [ $\mu$ F]	V <sub>0C</sub> [V]	I <sub>SC</sub> [mA]	V <sub>max</sub> [V]	R <sub>min</sub> [ $\Omega$ ]
1-3; 2-3 4-6; 5-6	A + B	192	2,66	10,5	13	10,5	811
	C + E	671	7,9				
	D, F, G	1000	21,3				

SMART IN FLOW CONTROL.



## EU Konformitätserklärung/EU Declaration of Conformity/ Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/  
This declaration of conformity is issued under the sole responsibility of the manufacturer/  
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.  
Für das folgende Produkt / For the following product / Nous certifions que le produit

**Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation /  
Electropneumatic Positioner with FOUNDATION FIELDBUS communication /  
Positionneur électropneumatique avec communication FOUNDATION FIELDBUS  
Typ/Type/Type 3730-5...**

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /  
the conformity with the relevant Union harmonisation legislation is declared with/  
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

EMC 2014/30/EU

EN 61000-6-2:2005, EN 61000-6-3:2007  
+A1:2011, EN 61326-1:2013

RoHS 2011/65/EU

EN 50581:2012

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT  
Weismüllerstraße 3  
D-60314 Frankfurt am Main  
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

A handwritten signature in black ink, appearing to read "i.v. H. Zager".

Hanno Zager  
Leiter Qualitätssicherung/Head of Quality Management/  
Responsable de l'assurance de la qualité

A handwritten signature in black ink, appearing to read "i.V. Dirk Hoffmann".

Dirk Hoffmann  
Zentralabteilungsleiter/Head of Department/Chef du département  
Entwicklungsorganisation/Development Organization



## EU Konformitätserklärung / EU Declaration of Conformity / Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/  
This declaration of conformity is issued under the sole responsibility of the manufacturer/  
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.  
Für das folgende Produkt / For the following product / Nous certifions que le produit

**Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation /**  
**Electropneumatic Positioner with FOUNDATION FIELDBUS communication /**  
**Positionneur électropneumatique avec communication FOUNDATION FIELDBUS**  
**Typ/Type/Type 3730-51..**

entsprechend der EU-Baumusterprüfung PTB 04 ATEX 2109 ausgestellt von der/  
according to the EU Type Examination PTB 04 ATEX 2109 issued by/  
établi selon le certificat CE d'essais sur échantillons PTB 04 ATEX 2109 émis par:

Physikalisch Technische Bundesanstalt  
 Bundesallee 100  
 D-38116 Braunschweig  
 Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt/  
the conformity with the relevant Union harmonisation legislation is declared with/  
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

EMC 2014/30/EU	EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013
Explosion Protection 94/9/EC (bis/to 2016-04-19) Explosion Protection 2014/34/EU (ab/from 2016-04-20)	EN 60079-0:2012/A11:2013, EN 60079-11:2012, EN 60079-31:2014
RoHS 2011/65/EU	EN 50581:2012

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT  
 Weismüllerstraße 3  
 D-60314 Frankfurt am Main  
 Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

Hanno Zager  
 Leiter Qualitätssicherung/Head of Quality Management/  
 Responsable de l'assurance de la qualité

Dirk Hoffmann  
 Zentralabteilungsleiter/Head of Department/Chef du département  
 Entwicklungsorganisation/Development Organization



## EU Konformitätserklärung/EU Declaration of Conformity/ Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/  
This declaration of conformity is issued under the sole responsibility of the manufacturer/  
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.  
Für das folgende Produkt / For the following product / Nous certifions que le produit

**Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation /  
Electropneumatic Positioner with FOUNDATION FIELDBUS communication /  
Positionneur électropneumatique avec communication FOUNDATION FIELDBUS  
Typ/Type/Type 3730-55..**

entsprechend der EU-Baumusterprüfung PTB 04 ATEX 2109 ausgestellt von der/  
according to the EU Type Examination PTB 04 ATEX 2109 issued by/  
établi selon le certificat CE d'essais sur échantillons PTB 04 ATEX 2109 émis par:

Physikalisch Technische Bundesanstalt  
Bundesallee 100  
D-38116 Braunschweig  
Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /  
the conformity with the relevant Union harmonisation legislation is declared with/  
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

EMC 2014/30/EU	EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013
Explosion Protection 94/9/EC (bis/to 2016-04-19) Explosion Protection 2014/34/EU (ab/from 2016-04-20)	EN 60079-0:2012/A11:2013, EN 60079-11:2012, EN 60079-31:2014
RoHS 2011/65/EU	EN 50581:2012

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT  
Weismüllerstraße 3  
D-60314 Frankfurt am Main  
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

Hanno Zager  
Leiter Qualitätssicherung/Head of Quality Management/  
Responsable de l'assurance de la qualité

Dirk Hoffmann  
Zentralabteilungsleiter/Head of Department/Chef du département  
Entwicklungsorganisation/Development Organization



## EU Konformitätserklärung / EU Declaration of Conformity / Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/  
This declaration of conformity is issued under the sole responsibility of the manufacturer/  
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.  
Für das folgende Produkt / For the following product / Nous certifions que le produit

**Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation /**  
**Electropneumatic Positioner with FOUNDATION FIELDBUS communication /**  
**Positionneur électropneumatique avec communication FOUNDATION FIELDBUS**  
**Typ/Type/Type 3730-58..**

entsprechend der EU-Baumusterprüfung PTB 05 ATEX 2010 X ausgestellt von der/  
according to the EU Type Examination PTB 05 ATEX 2010 X issued by/  
établi selon le certificat CE d'essais sur échantillons PTB 05 ATEX 2010 X émis par:

Physikalisch Technische Bundesanstalt  
 Bundesallee 100  
 D-38116 Braunschweig  
 Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt/  
the conformity with the relevant Union harmonisation legislation is declared with/  
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

EMC 2014/30/EU	EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013
Explosion Protection 94/9/EC (bis/to 2016-04-19) Explosion Protection 2014/34/EU (ab/from 2016-04-20)	EN 60079-15:2010, EN 60079-31:2009
RoHS 2011/65/EU	EN 50581:2012

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT  
 Weismüllerstraße 3  
 D-60314 Frankfurt am Main  
 Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

Hanno Zager  
 Leiter Qualitätssicherung/Head of Quality Management/  
 Responsable de l'assurance de la qualité

Dirk Hoffmann  
 Zentralabteilungsleiter/Head of Department/Chef du département  
 Entwicklungsorganisation/Development Organization

# ЕВРАЗИЙСКИЙ ЭКОНОМИЧЕСКИЙ СОЮЗ



## СЕРТИФИКАТ СООТВЕТСТВИЯ

№ ЕАЭС RU C-DE.ЭА11.В.00045/19

Серия RU № 0197354

**ОРГАН ПО СЕРТИФИКАЦИИ** Общество с ограниченной ответственностью «ТМС РУС». Место нахождения (адрес юридического лица): Российская Федерация, 127083, город Москва, улица Верхняя Масловка, дом 20, строение 2; адрес места осуществления деятельности: Российская Федерация, 127083, город Москва, улица Верхняя Масловка, дом 20, строение 2, помещения № 18, 28. Аттестат аккредитации № РОСС RU.0001.11ЭА11 от 02.07.2015. Номер телефона: +7 (495) 221-18-04; адрес электронной почты: info@tms-cs.ru.

**ЗАЯВИТЕЛЬ** Общество с ограниченной ответственностью «Самсон Контролс».

Место нахождения (адрес юридического лица) и адрес места осуществления деятельности: Российская Федерация, 109544, город Москва, бульвар Энтузиастов, дом 2, этаж 5, комната 11. ОГРН 1037700041026. Номер телефона: +7 (495) 777-45-45; адрес электронной почты: samson@samson.ru.

**ИЗГОТОВИТЕЛЬ** «SAMSON AG Mess- und Regeltechnik».

Место нахождения (адрес юридического лица) и адрес места осуществления деятельности по изготовлению продукции: Weismullerstrasse 3, D-60314 Frankfurt am Main, Германия.

**ПРОДУКЦИЯ** Позиционеры, типы 3724, 3725, 3730-0, 3730-1, 3730-2, 3730-3, 3730-4, 3730-5, 3730-6, 3731-3, 3731-5, 4763, 4765. Изготовление в соответствии со стандартами, указанными в приложении к сертификату соответствия на бланке № 0676628.

Серийный выпуск.

**КОД ТН ВЭД ЕАЭС** 9032 81 000 0

**СООТВЕТСТВУЕТ ТРЕБОВАНИЯМ** технического регламента Таможенного союза «Электромагнитная совместимость технических средств» (ТР ТС 020/2011)

**СЕРТИФИКАТ СООТВЕТСТВИЯ ВЫДАН НА ОСНОВАНИИ** протокола сертификационных испытаний № 190919-013-016-02/ИР от 22.10.2019, выданного испытательной лабораторией Общества с ограниченной ответственностью «Инновационные решения», аттестат аккредитации РОСС RU.0001.21AB90; акта о результатах анализа состояния производства № 00062-А от 04.07.2019 органа по сертификации Общества с ограниченной ответственностью «ТМС РУС»; руководств по эксплуатации 4218-3725-3724-2018.РЭ, 4218-3730-4763-2018.РЭ, 4218-3731-2018.РЭ.

Схема сертификации – 1с.

**ДОПОЛНИТЕЛЬНАЯ ИНФОРМАЦИЯ** Стандарт, в результате применения которого на добровольной основе обеспечивается соблюдение требований технического регламента: подразделы 6.2 и 7.2 ГОСТ Р 51522.1-2011 (МЭК 61326-1:2005) «Электрическое оборудование для измерения, управления и лабораторного применения. Часть 1. Общие требования и методы испытаний». Назначенный срок службы – 15 лет. Назначенный срок хранения – 2 года. Условия хранения указаны в руководствах по эксплуатации 4218-3725-3724-2018.РЭ, 4218-3730-4763-2018.РЭ, 4218-3731-2018.РЭ.

**СРОК ДЕЙСТВИЯ С** 05.11.2019 **ПО** 04.11.2024  
**ВКЛЮЧИТЕЛЬНО**

Руководитель (уполномоченное лицо) органа по сертификации

Эксперт (эксперт-аудитор)  
(эксперты (эксперты-аудиторы))



Назарова Лилия Юрьевна

(Ф.И.О.)

Ходоров Владимир Игоревич

(Ф.И.О.)

АО «Опцион», Москва, 2019 г., -б-. Лицензия № 05-05-09/003 ФНС РФ, Т3 № 369, Тел.: (495) 726-47-42, www.option.ru

# ЕВРАЗИЙСКИЙ ЭКОНОМИЧЕСКИЙ СОЮЗ

## ПРИЛОЖЕНИЕ

К СЕРТИФИКАТУ СООТВЕТСТВИЯ № ЕАЭС RU C-DE.ЭА11.B.00045/19

Серия RU № 0676628 Лист 1 из 1

Стандарты, в соответствии с которыми изготавливается продукция

Обозначение стандарта	Наименование стандарта
IEC 61000-6-2:2016	Electromagnetic compatibility (EMC). Part 6-2: Generic standards. Immunity for industrial environments
EN 61000-6-3:2007	Electromagnetic compatibility (EMC). Part 6-3: Generic standards. Emission standard for residential, commercial and light-industrial environments
EN 61326-1:2013	Electrical equipment for measurement, control and laboratory use. EMC requirements. Part 1: General requirements

Руководитель (уполномоченное лицо) органа по сертификации

Над  
(подпись)

Назарова Лилия Юрьевна

(Ф.И.О.)



Эксперт (эксперт-аудитор)  
(эксперты (эксперты-аудиторы))

Ходоров Владимир Игоревич  
(подпись)

Ходоров Владимир Игоревич

(Ф.И.О.)

АО «Опцион», Москва, 2019 г., «б», Лицензия № 05-05-09/003 ФНС РФ, ТЗ № 369, Тел.: (495) 726-47-42, www.opcion.ru

**UK  
CA**

**UK DECLARATION OF CONFORMITY**  
**ORIGINAL**



This declaration of conformity is issued under the sole responsibility of the manufacturer.

For the following product:

**Electropneumatic Positioner with FOUNDATION™ fieldbus communication**  
**Type 3730-5**

the conformity with the following relevant UK regulatory requirements is declared with:

**UK Regulation / Statutory Instrument**

SI 2016 No. 1091  
The Electromagnetic Compatibility Regulations 2016

SI 2012 No. 3032  
The Restriction of the Use of Certain Hazardous Substances  
in Electrical and Electronic Equipment Regulations 2012

**Designated Standard**

EN 61000-6-2:2005  
EN 61000-6-3:2007+A1:2011  
EN 61326-1:2013

EN IEC 63000:2018

Manufacturer:

SAMSON AKTIENGESELLSCHAFT  
Weismuellerstrasse 3  
60314 Frankfurt am Main  
Germany

Frankfurt am Main, 2022-12-14

Signed for and behalf of the manufacturer:

A handwritten signature in black ink, appearing to read "ppa. R.R." followed by a long horizontal line.

Fabio Roma  
Vice President Smart Products & Components

A handwritten signature in blue ink, appearing to read "i.v. J. Bieger" followed by a horizontal line.

Jens Bieger  
Director Development Electronics

Revision 00

Classification: Public · SAMSON AKTIENGESELLSCHAFT · Weismuellerstrasse 3 · 60314 Frankfurt am Main, Germany

Page 1 of 1

**UK  
CA**    **UK DECLARATION OF CONFORMITY**  
ORIGINAL



This declaration of conformity is issued under the sole responsibility of the manufacturer.

For the following product:

**Electropneumatic Positioner with FOUNDATION™ fieldbus communication**

**Type 3730-51 / -55**

according to the UK-Type Examination Certificate FM21UKEX0202X issued by:

FM Approvals Limited  
Voyager Place  
Maidenhead, Berkshire  
SL6 2PJ  
United Kingdom  
Approved Body No. 1725

the conformity with the following relevant UK regulatory requirements is declared with:

**UK Regulation / Statutory Instrument**

SI 2016 No. 1091  
The Electromagnetic Compatibility Regulations 2016

**Designated Standard**

EN 61000-6-2:2005  
EN 61000-6-3:2007+A1:2011  
EN 61326-1:2013

SI 2016 No. 1107  
The Equipment and Protective Systems Intended for  
Use in Potentially Explosive Atmospheres Regulations 2016

EN IEC 60079-0:2018  
EN 60079-11:2012  
EN 60079-31:2014

SI 2012 No. 3032  
The Restriction of the Use of Certain Hazardous Substances  
in Electrical and Electronic Equipment Regulations 2012

EN IEC 63000:2018

Manufacturer:

SAMSON AKTIENGESELLSCHAFT  
Weismuellerstrasse 3  
60314 Frankfurt am Main  
Germany

Frankfurt am Main, 2022-12-14

Signed for and behalf of the manufacturer:

A handwritten signature in black ink, appearing to read "ppa. R.R."  
\_\_\_\_\_  
Fabio Roma  
Vice President Smart Products & Components

A handwritten signature in blue ink, appearing to read "i.v. J. Bieger".  
\_\_\_\_\_  
Jens Bieger  
Director Development Electronics

Revision 00

Classification: Public · SAMSON AKTIENGESELLSCHAFT · Weismuellerstrasse 3 · 60314 Frankfurt am Main, Germany

Page 1 of 1

**UK  
CA** UK DECLARATION OF CONFORMITY  
ORIGINAL



This declaration of conformity is issued under the sole responsibility of the manufacturer.

For the following product:

**Electropneumatic Positioner with FOUNDATION™ fieldbus communication**  
**Type 3730-58**

according to the UK-Type Examination Certificate FM21UKEX0203X issued by:

FM Approvals Limited  
Voyager Place  
Maidenhead, Berkshire  
SL6 2PJ  
United Kingdom  
Approved Body No. 1725

the conformity with the following relevant UK regulatory requirements is declared with:

**UK Regulation / Statutory Instrument**

SI 2016 No. 1091  
The Electromagnetic Compatibility Regulations 2016

SI 2016 No. 1107  
The Equipment and Protective Systems Intended for  
Use in Potentially Explosive Atmospheres Regulations 2016

SI 2012 No. 3032  
The Restriction of the Use of Certain Hazardous Substances  
in Electrical and Electronic Equipment Regulations 2012

**Designated Standard**

EN 61000-6-2:2005  
EN 61000-6-3:2007+A1:2011  
EN 61326-1:2013

EN IEC 60079-0:2018  
EN IEC 60079-7:2015/A1:2018  
EN 60079-31:2014

EN IEC 63000:2018

Manufacturer:

SAMSON AKTIENGESELLSCHAFT  
Weismuellerstrasse 3  
60314 Frankfurt am Main  
Germany

Frankfurt am Main, 2022-12-14

Signed for and behalf of the manufacturer:

A handwritten signature in black ink, appearing to read "ppa. R." followed by a stylized surname.

Fabio Roma  
Vice President Smart Products & Components

A handwritten signature in blue ink, appearing to read "i.v. J. Breyer".

Jens Breyer  
Director Development Electronics

Revision 00

Classification: Public · SAMSON AKTIENGESELLSCHAFT · Weismuellerstrasse 3 · 60314 Frankfurt am Main, Germany

Page 1 of 1





SAMSON AKTIENGESELLSCHAFT  
Weismüllerstraße 3 · 60314 Frankfurt am Main, Germany  
Phone: +49 69 4009-0 · Fax: +49 69 4009-1507  
[samson@samsongroup.com](mailto:samson@samsongroup.com) · [www.samsongroup.com](http://www.samsongroup.com)