



EB 8389-2S EN

Translation of original instructions

Name		Value	Unit	Comment
Diagnosis				Maintenance required
Friction change (open pos.)			No	
Friction change (mid-pos.)			No	
Friction change (closed pos.)			No	
Valve sign. failed			No	
No supply press.			No	
Low supply pressure			No	
Supply pressure > 10 bar			No	
PST				No message
PST: cancellation criteria met			No	
PST: start criteria not met			No	
FST				No message
FST: canc. crit. met			No	
FST: start criteria not met			No	
Pneumatic module A (P3799 A)				No message
P3799: failure			No	
P3799: movement impaired			No	
P3799: maintenance required			No	
P3799: initialization error			No	
Pneumatic module B (P3799 B)				No message
P3799: failure			No	
P3799: movement impaired			No	
P3799: maintenance required			No	
P3799: initialization error			No	
AMR signal outside range			No	
Hardware error			No	
Limit for total valve travel exceeded			No	
Lower end position shifted			No	

EXPERTplus Valve Diagnostics

TROVIS SAFE 3793 Electropneumatic Positioner

Firmware version 1.00.xxx

TROVIS SAFE

Edition March 2017

Note on these mounting and operating instructions

These mounting and operating instructions assist you in mounting and operating the device safely. The instructions are binding for handling SAMSON devices.

- For the safe and proper use of these instructions, read them carefully and keep them for later reference.
- If you have any questions about these instructions, contact SAMSON's After-sales Service Department (aftersaleservice@samson.de).



The mounting and operating instructions for the devices are included in the scope of delivery. The latest documentation is available on our website at www.samson.de > **Service & Support** > **Downloads** > **Documentation**.

Definition of signal words

DANGER

Hazardous situations which, if not avoided, will result in death or serious injury

WARNING

Hazardous situations which, if not avoided, could result in death or serious injury

NOTICE

Property damage message or malfunction

Note

Additional information

Tip

Recommended action

1	Safety instructions and measures	5
1.1	Notes on possible property damage	7
2	Operation	7
2.1	On-site operation	7
2.2	Operation using TROVIS-VIEW	8
3	Start-up	9
4	Device state.....	10
4.1	Information parameters and limits	10
4.1.1	Reset	12
4.2	Status classification	12
4.2.1	Reset	13
4.3	Status messages	13
4.3.1	Group and condensed states	14
4.4	Logging.....	14
4.4.1	Reset	14
4.5	Temperature	14
4.5.1	Reset	16
5	Statistical information	16
5.1	On/off	16
5.1.1	On/off diagnosis	16
5.1.2	Reset	17
5.2	Histograms	17
5.2.1	Reset	20
5.2.2	Valve position	20
5.2.3	Set point deviation	22
5.2.4	Load cycle	23
5.3	Course of end position	25
5.3.1	Course of lower end position	25
5.3.1.1	Reset	27
5.3.2	Course of upper end position	27
5.3.2.1	Reset	28
6	Tests	28
6.1	Step response test (PST)	28
6.1.1	Test cancellation criteria.....	30

Contents

6.1.2	Test start	32
6.1.2.1	Manual start	32
6.1.2.2	Automatic start after 'Test interval' has elapsed	32
6.1.2.3	Start triggered by the binary input	33
6.1.3	Analysis and monitoring	33
6.1.4	Reset	35
6.2	Step response test (FST)	36
6.2.1	Test cancellation criteria	36
6.2.2	Test start	37
6.2.2.1	Manual start	37
6.2.2.2	Start triggered by the binary input	38
6.2.3	Analysis and monitoring	38
6.2.4	Reset	40
7	Error messages and recommended corrective action	41

1 Safety instructions and measures

Intended use

EXPERTplus is a diagnostic firmware integrated into the positioner which allows the predictive, status-oriented maintenance of valves with pneumatic actuators.

EXPERTplus records the valve condition while the process is running (in automatic mode) and generates messages on the required maintenance work. In addition, numerous tests can be performed in manual mode to pinpoint emerging faults.

The diagnostic functions of EXPERTplus are completely integrated into the positioner. Diagnostic data are compiled, saved and analyzed in the positioner itself. Classified status messages on the state of the valve are generated from the analysis.

Reasonably foreseeable misuse

While the tests are being performed, the valve does not follow the set point. Instead, it is moved according to the test specifications. Therefore, the tests can only be started when the conditions in the plant allow it.

Qualifications of operating personnel

The devices are to be configured and set by trained and experienced personnel only. According to these operating instructions, trained personnel refers to individuals who are able to judge the work they are assigned to and recognize possible hazards due to their specialized training, their knowledge and experience as well as their knowledge of the applicable standards.

Personal protective equipment

No personal protective equipment is required.

Revisions and other modifications

Revisions or other modifications to the product are not authorized by SAMSON. They are performed at the user's own risk and may lead to safety hazards, for example. Furthermore, the product may no longer meet the requirements for its intended use.

Safety features

The software in offline mode has no influence on the connected device.

Safety instructions and measures

Warning against residual hazards

The software in online mode has a direct influence on the connected device, and, as a result, on the valve. To avoid personal injury or property damage, plant operators and operating personnel must prevent hazards that could be caused in the control valve by the process medium, the operating pressure, the signal pressure or by moving parts by taking appropriate precautions. They must observe all hazard statements, warning and caution notes in the referenced documents.

Responsibilities of the operator

The operator is responsible for proper operation and compliance with the safety regulations. The operator is obliged to provide these operating instructions as well as the referenced documents to the operating personnel and to instruct them in proper operation. Furthermore, the operator must ensure that operating personnel or third persons are not exposed to any danger.

Responsibilities of operating personnel

Operating personnel must read and understand these operating instructions as well as the referenced documents and observe the hazard statements, warning and caution notes specified in them. Furthermore, the operating personnel must be familiar with the applicable health, safety and accident prevention regulations and comply with them.

Referenced standards and regulations

None

Referenced documentation

The following documents apply in addition to these operating instructions:

- Mounting and operating instructions (EB), safety manual (SH), and configuration manual (KH) for mounted device:
 - ▶ EB 8493S, ▶ SH 8493S, and ▶ KH 8384-3
- Mounting and operating instructions for the associated control valve (actuator, valve, and other valve accessories)

1.1 Notes on possible property damage

! NOTICE

Valve malfunction due to a configuration that does not meet the requirements of the application.

Settings for the EXPERTplus valve diagnostics can be made in the TROVIS-VIEW software. In online mode of this software, the configuration and parameter settings take effect immediately in the connected positioner and affect the control valve as a result.

- Only activate the online mode when configurations, parameter settings, and measured values are to be transferred from or to the device.

2 Operation

Operation using TROVIS-VIEW/DD/DTM/eDD

EXPERTplus allows the parameters to be viewed or changed using the TROVIS-VIEW software or DD/DTM/eDD.

- **TROVIS-VIEW** · SAMSON operator interface used to configure various SAMSON devices
- **DTM** · Device type manager to describe the device and communication properties
- **DD/eDD** · Device description/enhanced device description

i Note

All parameter settings and configurations must also be downloaded onto the positioner to allow them to become effective.

2.1 On-site operation

Some parameters can be changed at the positioner as well as over the operator interface. Refer to the mounting and operating instructions of the TROVIS SAFE 3793 Positioner (▶ EB 8493S) for a list of all parameters that can be changed at the positioner.

2.2 Operation using TROVIS-VIEW


Operation using TROVIS-VIEW is described in these operating instructions. The following applies in this case:

- The default settings of parameters are written in square brackets [].
- Operation applies to the "Diagnosis" user level.

i Note

The installation and operation of the TROVIS-VIEW software is explained in detail in the Operating Instructions ► EB 6661. These instructions are available on the Internet and in the [?] menu in TROVIS-VIEW.

💡 Tip

The [Find...] function in the menu bar can be used to look for parameters: 

3 Start-up

The positioner must be initialized to use the full scope of the valve diagnostics. During initialization the positioner adapts itself optimally to the friction conditions and the signal pressure required by the control valve. The positioner can be initialized using one of the following initialization modes: MAX, NOM or MAN. All functions of EXPERTplus cannot be used when a positioner has been initialized in the SUB mode.

1. Connect the positioner with the configuration and operating software.
 - ➔ The TROVIS-VIEW software on a computer can be connected to the positioner using an isolated USB interface adapter (order no. 1400-9740).
2. Put the positioner into operation as described in the Mounting and Operating Instructions ► EB 8493S.


































































Tip

We recommend initialization with valve signature when the positioner is fitted with pressure sensors.

When initialization fails, the positioner generates a status message with the assigned status classification. See section 4.

If a status message is generated during initialization, the group status 'Start-up' and 'Initialization' are also generated with the assigned status classification. See section 4.

> Diagnosis/maintenance > Device state > Status classification

- Start-up:      [highest classification]
- Initialization:      [highest classification]
- Init: incorrect operating mode:     
- Init: travel too small:     
- Init: rated travel not achieved:     
- Init: pin position:     
- Init: no movement:     
- Init: canceled (control accuracy):      [highest classification]
- Init: low control accuracy:      [highest classification]
- Positioner not initialized:     
- Init: canceled externally:     
- Init: angle limitation:      [highest classification]
- Init: time-out:      [highest classification]

> Diagnosis/maintenance > Device state > Status messages

- Start-up
- Initialization
- Init: incorrect operating mode
- Init: travel too small
- Init: rated travel not achieved
- Init: pin position
- Init: no movement
- Init: canceled (control accuracy)
- Init: low control accuracy
- Positioner not initialized

Device state

- Init: canceled externally
- Init: angle limitation
- Init: time-out

3. Read out positioner data.

- ➔ In TROVIS-VIEW: select menu [Device > Read].



- 'Time stamp for min. supply pressure'
Time at which the pressure displayed in 'Min. supply pressure' occurred
- 'Max. supply pressure':
highest supply pressure
- 'Time stamp for max. supply pressure'
Time at which the pressure displayed in 'Max. supply pressure' occurred
- 'Lower press. limit'
The 'Low supply pressure' status message is generated with the assigned status classification when the supply pressure falls below the lower pressure limit.

> Diagnosis/maintenance > Device state

- Pressure sensors exist: Yes, [No]
- Lower press. limit: 0.01 to 10.00 bar, [2.50 bar]*

* The 'Lower press. limit' parameter is automatically recalculated on creating the valve signature.

4 Device state

4.1 Information parameters and limits

The [Device state] folder contains information parameters on the positioner state and the limits used to generate status messages.

Pressure sensors

Information parameters only displayed when the positioner is fitted with the optional pressure sensors:

- 'OUTPUT 138: pressure':
current pressure at output 138
- 'OUTPUT 238: pressure':
current pressure at output 238
- 'Supply pressure':
current supply pressure
- 'Min. supply pressure':
lowest supply pressure

Stress factor

The stress factor range is directly linked to the load cycle histogram. See section 5.2.4.

Total valve travel

- 'Total valve travel':
Totalled full valve travel cycle
- 'Total valve travel limit':
The 'Total valve travel' status message is generated when the total valve travel exceeds the limit.

> Diagnosis/maintenance > Device state

- Total valve travel:
1000 to 90,000,000, [1,000,000]

The screenshot displays the 'Device state' window in the SAMSON TROVIS-VIEW 4 software. The window title is 'TROVIS 3793, Version 1.00.00'. The navigation path is 'Diagnosis / maintenance > Device state'. The main content is a table with the following columns: Name, Value, Unit, and Comment. The data is grouped into several sections, each with a small icon and a title bar.

Name	Value	Unit	Comment
Pressure sensors			
Pressure sensors exist	Yes		
OUTPUT 138: pressure	0.11	bar	
OUTPUT 238: pressure	0.11	bar	
Supply pressure	3.00	bar	
Min. supply press.	3.00	bar	
Time stamp for min. supply pressure	5.06:33:10	d.hh:mm:ss	
Max. supply press.	3.00	bar	
Time stamp for max. supply pressure	5.06:33:09	d.hh:mm:ss	
Lower press. limit	2.50	bar	
Stress factor			
Dynamic stress factor	0	%	
Stem seal	Not selected		
Max. cycle count	1000000		
Limit of adjustable packing	800000		
Limit of self-adjusting packing	2000000		
Limit of bellows seal	8473930		
Total valve travel			
Total valve travel	0		
Total valve travel limit	1000	*1000	
Set point deviation			
Lag time for set point deviation	30	s	
Tolerance band for set point deviatio... [Max.CDw]	5.0	%	
Temperature at the last initialization			
Temperature			
Time			
Operating hours counter	5.07:11:38	d.hh:mm:ss	
Device switched on since last initialization	00:27:46	d.hh:mm:ss	
Device in closed-loop operation	00:00:00	d.hh:mm:ss	
Device in closed-loop operation since last initiali...	00:00:00	d.hh:mm:ss	
Counter			
Number of initializations	1		

Fig. 1: > Diagnosis/maintenance > Device state

Device state

Set point deviation

- 'Lag time for set point deviation':
The lag time is determined during initialization. It is the reset criterion for the 'Set point deviation' status message.
A transit time of less than 180 s determined during initialization causes the 'Lag time of set point deviation' to be set to 30 s.
A transit time of 180 s or more determined during initialization causes the 'Lag time of set point deviation' to be set to six times the transit time.
- 'Tolerance band for set point deviation +/-':
A set point deviation is recognized as a system deviation when the valve position deviates from the set point by the value adjusted in this parameter.

> Diagnosis/maintenance > Device state

- Tolerance band for set point deviation +/-: 0.1 to 10.0 %, [5.0 %]

Temperature

- See section 4.5 for [Temperature] folder.

Time

- 'Operating hours counter'
- 'Device switched on since last initialization'
- 'Device in closed-loop operation'
- 'Device in closed-loop operation since last initialization'

Counter

- 'Number of initializations'

- 'Number of zero calibrations'

Save

- 'Diagnostic data'
The diagnostic data are saved in a non-volatile memory (EEPROM).

4.1.1 Reset



	Initialization	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset information parameters without operating hours counter	YES	NO	YES	YES
Reset operating hours counter	NO	NO	NO	NO
Reset limits	1)	YES	YES	YES




- 1) Reset depending on limit

4.2 Status classification

A status classification is assigned to the status messages of the EXPERTplus valve diagnostics. This assigned status appears when a status message is generated.

The following classifications are possible:

- Priority ↓
-  **No message**
If an event is classified as "No message", this event does not have any affect on the condensed state.
 -  **Maintenance required**
The positioner still performs its control task (with restrictions). A maintenance demand has been determined. The wear tolerance will soon be ex-

- hausted or is reducing at a faster rate than expected. Maintenance is necessary in the medium term.
-  **Out of specification**
The positioner is running outside the specified operating conditions or has not yet been initialized.
 -  **Function check**
Test or calibration procedures are performed in the positioner. The positioner is temporarily unable to perform its control task as long as the procedure is taking place.
 -  **Failure**
The positioner cannot perform its control task due to a functional fault in the positioner itself or in one of its peripherals.
 - **Highest classification**
Status classification of a group status (see section 4.3.1). The group status depends on the status classification assigned to the status messages: the status message with the highest classification determines the group status.

i Note

In the "On-site" user levels, the active status messages are visible. In some cases, only the active group status is visible without the assigned status messages.

The status classification is predetermined in the [> Diagnosis/maintenance > Device state > Status classification] folder. All status messages are assigned to a status by default.

i Note

The 'Out of specification' status is assigned to a positioner that has not yet been initialized.


4.2.1 Reset

	Initialization	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset status classification	NO	NO	NO	YES

4.3 Status messages

The valve diagnostics integrated into the positioner generates classified status messages. All status messages with their assigned status are listed in the [> Diagnosis/maintenance > Device state > Status classification] folder.

i Note

The " No message" status is generated when:

- The conditions to generate a status message are not fulfilled.
- The conditions to generate a status message are fulfilled, but the status message is assigned the "No message" status.

➔ We recommend following the instructions listed in the Appendix when a status message occurs.

4.3.1 Group and condensed states

To provide a better overview on the individual status messages, various status messages are summarized in a **group status**. If a status message assigned to a group is active, the group status is generated according to the predefined status classification.

The **condensed state** is summary of all status messages. To provide a better overview on the condition of the valve, all status messages are summarized in a condensed state which is made up from a summary of all classified messages in the positioner. The status message with the highest priority determines which condensed state is set. The status message with the highest priority determines the condensed state.



The condensed state is indicated on the right-hand corner of the status bar in TRO-VIS-VIEW.

- The positioner was successfully initialized.
- EXPERTplus generates a status message.
- A generated status message has been canceled.
- A test was successfully completed.



Use [Find...] function to find a certain event:

4.4.1 Reset

	Initialization	'Reset logging'	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset logging	NO	YES	NO	YES	YES

4.4 Logging

EXPERTplus can log up to 400 events. They are listed in the [> Diagnosis/maintenance > Device state > Logging] folder together with additional information on the event and the time it occurred.

Logging starts automatically. It does not need to be activated by the user.

The following events are logged:

- The positioner was started up.

4.5 Temperature

The temperature inside the device is displayed:

- 'Temperature inside device': current temperature inside the device
- 'Min. temperature inside device': the lowest temperature inside the device while in service

ID	Event Index	Type Index	Time stamp	Delta time stamp
001	Device start	Action started	5.06:43:29	00:31:20
002	Operating mode not AUTO	NAMUR message canceled	5.06:40:52	00:33:57
003	Function check in progress	NAMUR message canceled	5.06:40:52	00:33:57
004	Valve signature	Action successful	5.06:40:52	00:33:57
005	Valve signature	Action started	5.06:40:00	00:34:49
006	Operating mode not AUTO	NAMUR message generated	5.06:40:00	00:34:49
007	Function check in progress	NAMUR message generated	5.06:40:00	00:34:49
008	Operating mode not AUTO	NAMUR message canceled	5.06:40:00	00:34:49
009	Function check in progress	NAMUR message canceled	5.06:40:00	00:34:49
010	Positioner initialized	NAMUR message canceled	5.06:40:00	00:34:49
011	Initialization	Action successful	5.06:39:58	00:34:51
012	Initialization	Action started	5.06:38:07	00:36:42
013	Function check in progress	NAMUR message generated	5.06:38:07	00:36:42
014	Positioner initialized	NAMUR message generated	5.06:37:49	00:37:00
015	Operating mode not AUTO	NAMUR message generated	5.06:37:49	00:37:00
016	Analog feedback module (Z3799 Module [T])	Option module active	5.06:37:49	00:37:00
017	Binary input/output (Z3799 Module [U])	Option module active	5.06:37:49	00:37:00
018	Device start	Action started	5.06:37:49	00:37:00
019	Forced venting switch incorrect	NAMUR message canceled	5.06:35:12	00:39:37
020	Analog feedback module (Z3799 Module [T])	Option module detected	5.06:35:12	00:39:37
021	Binary input/output (Z3799 Module [U])	Option module detected	5.06:34:39	00:40:10
022	Positioner initialized	NAMUR message generated	5.06:33:08	00:41:41
023	Operating mode not AUTO	NAMUR message generated	5.06:33:08	00:41:41
024	Forced venting switch incorrect	NAMUR message generated	5.06:33:08	00:41:41
025	Deactivation module (Z3799 Module [V])	Option module active	5.06:33:08	00:41:41

Messages per page 50 Find...

Online Reading successful.

Fig. 2: > Diagnosis/maintenance > Device state > Logging

Statistical information

- 'Max. temperature inside device': the highest temperature inside the device while in service
- 'Minimum temperature limit': The 'Temperature inside device below min. limit' status message is generated with the assigned status classification when the temperature inside the device falls below the limit. The status message is canceled as soon as the temperature rises above the limit again.
- 'Maximum temperature limit': The 'Temperature inside device above max. limit' status message is generated with the assigned status classification when the temperature inside the device exceeds the limit. The status message is canceled as soon as the temperature falls below the limit again.

i Note

The 'Minimum temperature' and 'Maximum temperature limit' parameters are set to $-60\text{ }^{\circ}\text{C}$ and $80\text{ }^{\circ}\text{C}$ respectively by default. These settings can only be changed in the "Customer expert" user level.

4.5.1 Reset

	Initialization	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset temperature values	YES	NO	NO	YES

5 Statistical information

The Statistical information compiles data while the process is running without disrupting the process. The data are saved and analyzed in the positioner, i.e. the positioner follows the set point to position the valve. A classified status message is generated when the positioner detects an event.

5.1 On/off

The travel range of open/close (on/off) is defined by the fail-safe position and the operating point.

The discrete analysis of the set point is performed in automatic mode (see Fig. 3). Depending on the set point change, the valve performs a step response test (PST). See Fig. 4.

5.1.1 On/off diagnosis

Every time a demand for the valve to move occurs, the on/off diagnosis records the following measuring data separately for the direction from open to closed and from closed to open:

- 'Start value': current valve position when a demand for the valve to move from open to closed or from closed to open is detected
- 'Breakaway time': the time taken after the demand for the valve to move is detected until the 'Breakaway threshold' is exceeded
- 'Transit time': the time it takes to detect both limits

- » Demand to move the valve from open to closed: 'Limit to detect open position' and 'Limit to detect closed position'
- » Demand to move the valve from closed to open: 'Limit to detect closed position' and 'Limit to detect open position'
- 'End value of transit time measurement': current valve position at the end of the movement "Open to closed" or "Closed to open"
- 'Reason for movement': trigger for demand to switch
 - » Set point: the set point has changed (see Fig. 3).
 - » Fail-safe position: the fail-safe position has been activated.
 - » Binary input: the 'Fixed value over binary input' (only with positioners with option module [T] or [V])

Every demand to switch causes the status of the last measurement to be saved and displayed.

> Diagnosis/maintenance > Statistical information > On/off

- Breakaway threshold: [2.0 %]
- Limit to detect open position: [98.0 %]
- Limit to detect closed position: [2.0 %]
- Time stamp (not write-enabled)
- Start value (not write-enabled)
- Dead time (not write-enabled)
- Transit time (not write-enabled)
- End value of transit time measurement (not write-enabled)

- Reason for movement (not write-enabled)
- Status of last measurement (not write-enabled)

i Note

The 'Breakaway threshold', 'Limit to detect open position', and 'Limit to detect closed position' parameters can only be changed in the "Customer expert" user level.

5.1.2 Reset

	Initialization	'Reset histograms'	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset measured data	YES	YES	YES	YES	YES

5.2 Histograms

Histograms are statistical analysis which are performed by the positioner in the AUTO and SAFE modes. For this purpose, data are logged every second and saved in a non-volatile memory every 24 hours.


Data logging and analysis do **not** need to be activated.

EXPERTplus has histograms on the following topics:

- Valve position (see section 5.2.2)
- Set point deviation (see section 5.2.3)
- Load cycle (see section 5.2.4)


On/off valve with ATO setting

If the set point (w , $---$) is below 75 % when the automatic mode starts, the valve (x , $—$) closes. If the set point rises and exceeds 75 %, the valve fully opens. If the set point continues to drop under 12.5 %, the valve closes.




On/off valve with ATC setting

If the set point (w , $---$) is above 12.5 % when the automatic mode starts, the valve (x , $—$) fully opens. If the set point drops below 12.5 %, the valve closes. If the set point continues to rise and exceeds 75 %, the valve fully opens.



If the set point (w , $---$) is above 75 % when the automatic mode starts, the valve (x , $—$) fully opens. If the set point continues to drop under 12.5 %, the valve closes.



If the set point (w , $---$) is below 12.5 % when the automatic mode starts, the valve (x , $—$) closes. If the set point continues to rise and exceeds 75 %, the valve fully opens.




Fig. 3: Discrete set point analysis

On/off valve with ATO setting

Triggering the step response test


A step response test (PST) is started when the set point (w , \cdots) moves into the range between 25 and 50 % of the travel (x , —) and remains there for longer than six seconds. See section 6.1.

The test is not started when the operating point (100 %) is outside the range: 'Start value' \pm 'Start value of tolerance band +/-'.

After the step response test (PST) is completed, the valve moves back to its previous position (open or closed).

Canceling the step response test (PST)

The step response test is canceled whenever the set point (w , \cdots) leaves the range between 25 and 50 %. After the step response test is canceled, the valve (x , —) moves back to its previous position (open or closed).



On/off valve with ATC setting

Triggering the step response test (PST)

A step response test (PST) is started when the set point (w , \cdots) moves into the range between 25 and 50 % of the travel (x , —) and remains there for longer than six seconds. See section 6.1.

The test is not started when the operating point (0 %) is outside the range: 'Start value' \pm 'Start value of tolerance band +/-'.

After the step response test is completed, the valve moves back to its previous position (open or closed).

Canceling the step response test

The step response test is canceled whenever the set point (w , \cdots) leaves the range between 25 and 50 %. After the step response test is canceled, the valve (x , —) moves back to its previous position (open or closed).




Fig. 4: Step response test (PST)

Statistical information

The histograms can be displayed for different monitoring periods. The monitoring periods are defined using the 'Archive type' parameter.

> **Diagnosis/maintenance > Statistical information > Histograms > Valve position**
> **Diagnosis/maintenance > Statistical information > Histograms > Set point deviation**
> **Diagnosis/maintenance > Statistical information > Histograms > Load cycle**

– Archive type: [Service life], Days, Weeks, Months, Years

With 'Archive type' setting = Days:

– Day: [Today], Yesterday, Day before yesterday, Three days ago, ..., Six days ago

With 'Archive type' setting = Weeks:

– Weeks: [This week], Last week, Week before last, Three weeks ago

With 'Archive type' setting = Months:

– Months: [This month], Last month, Month before last, Three months ago, ..., Eleven weeks ago

With 'Archive type' setting = Years:

– Years: [This year], Last year, Year before last, Three years ago, ..., Five years ago

5.2.1 Reset

The valve position, set point deviation, and load cycle histograms are all reset. It is not possible to reset single histograms.

	Initialization	'Reset histograms'	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset measured data	YES	YES	YES	YES	YES
Reset archived data	YES	YES	YES	YES	YES

5.2.2 Valve position

The valve position histogram provides information about the range in which valve mainly works during its service life and whether the operating range is possibly shifting.

The positioner records the valve position every second and assigns the data into predefined valve position classes. The distribution showing how often the sound level occurred within a valve position class is shown in a bar graph.

Analysis and monitoring

The first and last class indicate how often the 'End position $w \leq$ ' and 'End position $w \geq$ ' functions have been triggered.

- The 'End position $w \leq$ ' function causes the valve to move to the closed position

when the valve position reaches an adjustable set point.

- The 'End position $w \geq$ ' function causes the valve to move to the open position when the valve position reaches an adjustable set point.

The functions can be adjusted in the [> Configuration > Set point processing] folder.

A valve position that is mainly located close to the closed or open position pinpoint to a valve that is too large or too small.

- We recommend checking the valve sizing.




Fig. 5: > Diagnosis/maintenance > Statistical information > Histograms > Valve position

5.2.3 Set point deviation

The set point deviation histogram provides information on to which extent a set point deviation has occurred and whether faults may occur due to a restricted working range.

The positioner records the set point deviation every second and assigns the data into pre-defined classes. The distribution showing how often the set point deviation remained within a class is shown in a bar graph.

Analysis and monitoring

Ideally, the set point deviation should be as close to 0 % as possible.

Set point deviations greater than 1 % following in quick succession pinpoint to a limitation of the upper working range.

→ We recommend checking the attachment. Set point deviations smaller than 1 % following in quick succession pinpoint to a limitation of the lower working range or to seat leakage.

→ We recommend checking the attachment as well as the seat and plug for wear.

If almost all set point deviations during the short-term monitoring are greater than 1 % or smaller than -1 %, this may indicate that the actuator or valve stem is jammed.

→ We recommend checking the plug stem for external influences that could be blocking it.




Fig. 6: > Diagnosis/maintenance > Statistical information > Histograms > Set point deviation

5.2.4 Load cycle


The load cycle histogram provides a statistical analysis of the cycles that the valve has moved through. As a result, the cycle counter also provides information on the dynamic stress of a bellows seal and/or packing.

The positioner records the height of the cycles that the valve has moved through taking the selected stem seal into account.

The cycles are assigned to classes. The distribution showing how often the cycle occurred within a class is shown in a bar graph.

i Note

A valve cycle span starts at the point where the valve stroke changes direction until the point where it changes direction again.



> Diagnosis/maintenance > Device state

- Stem seal: [Not selected], Self-adjusting, Adjustable, Bellows, Other
- Max. cycle count: 1 to 1000000000, [1000000]

! NOTICE

No analysis of 'Dynamic stress factor' with 'Stem seal' = "Not selected" (= default setting).




Fig. 7: > Diagnosis/maintenance > Statistical information > Histograms > Load cycle

Operation

Set 'Stem seal' parameter to allow an analysis of the load cycle histogram to be performed.

Analysis and monitoring

The load on the bellows and/or packing can be read from the 'Dynamic stress factor' parameter. The value is determined from the cycle spans or cycle heights and takes into account the type of packing used in the valve.

A 'Dynamic stress factor exceeded' status message is generated with the assigned status classification whenever:

- The number of measured cycle spans exceeds 2,000,000 when 'Self-adjusting' is selected as the stem seal.
- The number of measured cycle spans exceeds 800,000 when 'Adjustable' is selected as the stem seal.
- The number of measured cycle spans exceeds 90 % of the 'Max. cycle count' when 'Other' is selected as the stem seal.
- The number of measured cycle heights exceeds 8,473,930 when 'Bellows' is selected as the stem seal.



Tip


The level of stress that the packing is exposed to depends on other factors besides load cycles, e.g. on the process medium and the operating conditions. Therefore, in the "Customer expert" user level, it is possible to adapt the limits to trigger the 'Dynamic stress factor exceeded' status message as required.

> Diagnosis/maintenance > Device state

– Dynamic stress factor

> Diagnosis/maintenance > Device state > Status classification

– Dynamic stress factor exceeded:



> Diagnosis/maintenance > Device state > Status messages

– Dynamic stress factor exceeded

- We recommend checking the condition of the packing when the status message is generated to prevent external leakage.

5.3 Course of end position

Data are recorded in the background regardless of the operating mode selected when the conditions for logging data are fulfilled (see sections 5.3.1 and 5.3.2). Data logging does not need to be activated.

The course of end position function records the measured data when the valve moves to the end position:

- Valve position
- Temperature
- Time stamp of operating hours counter

The new recorded end position is compared to the last saved end position. If the valve position deviates by 0.3 % from the last value, the data of the new end position are saved.

A graph of the recorded end positions is plotted over time.

The positioner saves the valve positions in a circular buffer, which holds 30 measured values at one time.

Analysis and monitoring

The 'Course of lower end position' and 'Course of upper end position' status messages are generated with the assigned status classification whenever a new recorded end position deviates from the reference value by the 'Threshold for end position shift'. The reference value is determined during initialization (see sections 5.3.1 and 5.3.2). It is shown as a straight line in the graph.

> Diagnosis/maintenance > Statistical information > Course of end position

– Threshold for end position shift:
0.3 to 100.0 %, [5.0 %]

i Note

When temperature fluctuations occur and with valves with a long insulating section, the 'Course of lower end position' and 'Course of upper end position' status messages may be generated at an early stage.

5.3.1 Course of lower end position

To record data for the course of lower end position (behavior during tight closing), the following conditions must exist:

- The positioner was initialized in the MAX or NOM mode.
- The tight-closing function is active ('Lower end position' parameter = "Active").

> Configuration > Set point processing

– Lower end position: [Active]

i Note

When the end position function is active, the valve shuts off tightly as soon as the set point is lower or equal to the value entered in 'End position w <='.

The reference value for the course of the lower end position is reference zero. This is de-




Fig. 8: > Diagnosis/maintenance > Statistical information > Course of lower end position





Fig. 9: > Diagnosis/maintenance > Statistical information > Course of upper end position

terminated during a MAX or NOM initialization and during a zero calibration.

> Diagnosis/maintenance > Device state > Status classification

– Lower end position shifted:



> Diagnosis/maintenance > Device state > Status messages

– Lower end position shifted

The generation of the 'Lower end position shifted' status message in combination with a shift of the course of the end position downward pinpoints to signs of wear between seat and plug in metal-seated valves.

➔ We recommend checking the seat and plug for wear.

i Note

The 'Lower end position shifted' status message is generated briefly after the initialization of soft-seated valves for design reasons. The soft seal settles after a few load cycles

causing zero to be shifted. In these valves, a repeated generation of the status message after a long time service first indicates signs of wear.

The generation of the 'Lower end position shifted' status message in combination with a shift of the course of the end position upward pinpoints to a blockage of the plug stem, e.g. due to dirt particles.

➔ We recommend checking the plug stem for mechanical blockage.

5.3.1.1 Reset

Refer to Table 1

5.3.2 Course of upper end position

The positioner must be initialized in the MAX mode to allow course of end position data to be recorded.

Table 1: *Reset the course of end position*

		Initialization	Zero calibration	'Reset course of end position'	'Reset diagnosis'	'Reset (standard)'	'Reset (advanced)'
Reset reference value	Lower end position	YES	YES	NO	NO	NO	NO
	Upper end position	YES	NO	NO	NO	NO	NO
Reset measured data	Lower end position	NO	NO	YES	YES	YES	YES
	Upper end position	NO	NO	YES	YES	YES	YES
Reset status message	Lower end position	YES	YES	NO	YES	YES	YES
	Upper end position	YES	NO	NO	YES	YES	YES


The reference value for the course of the top zero point is the travel at the open valve position. It is determined only in the MAX initialization mode.

Analysis and monitoring

If the analysis of course of the upper end position pinpoints a fault, the positioner generates the 'Upper end position shifted' status message with the assigned status classification.

> Diagnosis/maintenance > Device state > Status classification

– Upper end position shifted:



> Diagnosis/maintenance > Device state > Status messages

– Upper end position shifted

→ We recommend checking the plug stem for mechanical blockage when the status message is generated.

5.3.2.1 Reset

Refer to Table 1

6 Tests

Similar to the statistical information, data are compiled, saved, and analyzed in the positioner for the tests. **However, in this case, the valve position is not determined by the set point, but by the active test.** The tests can only be started when the conditions in the plant allow it (e.g. plant shutdown or service work in the workshop). For reasons of safety, these tests, except for step response test (PST), can only be performed in the MAN mode.

i Note

An active test is stopped and the positioner changes to the fail-safe position when the electrical signal falls below a certain level or when the forced venting function is triggered.

6.1 Step response test (PST)

The step response test (PST) is particularly suitable for the status-oriented detection of malfunctions in pneumatic shut-off valves. As a result, the probability of failure on demand (PFD) can be reduced and it may be possible to extend maintenance intervals. A shut-off valve normally in its end position can be prevented from seizing up or getting jammed. The initial breakaway torque must first be overcome after the valve starts to move from its end position. The initial breakaway torque depends on the plug/seat seal, deposits on the plug, the process medium and friction at the valve trim. After the initial

breakaway torque has been overcome, it can be assumed that the valve is able to close completely. The recording of the test results additionally allows an analysis of the dynamic control response.

During the step response test, the valve moves from its current operating point by the defined change in travel and back to the initial position again. The change in travel is calculated from the 'Start value' and 'Step height'.


The change in travel can be performed either in steps or in a ramp function (Fig. 10). The test is performed with the ramp function when the ramp times ('Ramp 1' and 'Ramp 2') are set to $\neq 0$ s.

The test starts after reaching the 'Start value' and the 'Waiting time' has elapsed. Starting from the 'Start position', the valve moves through the 'Step height' in the 'Test direc-

tion'. The valve remains in this position for the time defined in 'Waiting time' before performing a second step change in the opposite direction to the operating point. The 'Sampling time' defines the time interval between which the measured values are recorded during the test.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Start value: -20 to 120 %, [100 %]
- Step height: 2 to 100 %, [10 %]
- Test direction: [Minus], Plus
- Ramp 1: 0 to 9999 s, [60 s]
- Ramp 2: 0 to 9999 s, [6 s]
- Sampling rate (not write-enabled)



6.1.1 Test cancellation criteria

Various test cancellation conditions provide additional protection against the valve slamming shut or moving further than step height. The positioner cancels the step response test when one of the following cancellation conditions is fulfilled:

Time

- 'Canceled: max. test duration': the test is canceled when the maximum permissible test duration is reached.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Canceled: max. test duration (not write-enabled)

- 'Canceled: max. test duration': the test is canceled when the adjusted 'Waiting time' has elapsed without the valve having moved by the value 'Dead time limit determined'.

This cancellation criterion only takes effect when 'Dead time limit determined' is set to $\neq 0\%$.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Canceled: max. dead time (not write-enabled)
 - Dead time limit determined: 1 to 10 %, [2 %]

Tolerance bands

- 'Start value of tolerance band +/-': the test is not started when the operating

point is outside the range: 'Start value' \pm 'Start value of tolerance band +/-'.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Start value of tolerance band +/-:
 1 to 100 %, [3 %]

- 'Canceled: tolerance band (ramp) +/-', 'Canceled: tolerance band (step) +/-':
 The test is canceled as soon as the deviation of the valve position (in relation to the theoretical step end value, calculated from the 'Start position' and 'Step height') exceeds the adjusted value.

This cancellation criterion only takes effect when 'Canceled: tolerance band (ramp) +/-' or 'Canceled: tolerance band (step) +/-' is set to $\neq 0\%$.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Canceled: tolerance band (step) +/-:
 can only be selected in the "Customer expert" user level
 - Canceled: tolerance band (ramp) +/-:
 1 to 100 %, [5 %]

Valve position

- 'Canceled: x monitoring': the test is canceled when 'Minus' is selected as the 'Test direction' as soon as the valve position falls below the adjusted value. The test is canceled when 'Plus' is selected as the 'Test direction' as soon as the valve position exceeds the adjusted value.

This cancellation criterion only takes effect when 'Canceled: x monitoring' is set to $\neq 0$ %.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Canceled: x monitoring: -20 to 120 %, [ATO: 85 %; ATC: 15 %]

Pressure criteria

Analysis of the pressure only possible when the positioner is fitted with the optional pressure sensors.

- 'Canceled (press. limit)': the test is canceled through venting when the valve moves to the test end value after the pressure is below this limit. The test is canceled through supplying air when the valve moves to the test end value after the pressure exceeds this limit.

This cancellation criterion only takes effect when the 'Activate pressure monitoring' is set to "Active".

 **Tip**

The minimum or maximum pressure of the reference test can be used as a guide for the limit defined in 'Canceled (press. limit)'. See section 6.1.3.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Activate pressure monitoring: **Active**
- Canceled (press. limit): [0.00] to 1.00 bar

 **Notes on cancellation criteria**

- *The step response test must only be performed with the cancellation conditions (time or valve position) for valves with double-acting actuator and pneumatic booster as well as for valves that have been initialized using the SUB mode.*
- *Excessive overshooting may occur in valves fitted with volume boosters. In this case, the test cancellation criteria 'Canceled: x monitoring' and 'Canceled: tolerance band (ramp) +/-' or 'Canceled: tolerance band (step) +/-' must be increased accordingly.*

The reason why the test was canceled can be read in the 'Results of last test' parameter. Besides cancellation due to the adjusted test cancellation criteria, further events lead to the test being canceled, for example:

- The internal forced venting function is triggered.
- The current is lower than 3.8 mA.
- The test is manually canceled:
 - ➔ On site by pressing the rotary push-button
 - ➔ By software with the 'Stop test' parameter
- The positioner switches to the SAFE mode.
- At the start of the step response test over the binary input, the edge control changes again to the state which starts the step response test.
- In AUTO mode, the edge control changes to the state in which the valve moves

to a fixed value which is out the range:
'Start value' ± 'Start value of tolerance
band +/-'.

6.1.2 Test start

Table 2: Start conditions of step response test (PST)


Operating mode	See section 6.1.2.1 for manual start (on site or using software)	Automatic start after 'Test interval' has elapsed (see section 6.1.2.2)	Start triggered by the binary input (see section 6.1.2.3)
AUTO	YES	YES	YES
MAN	YES	NO	YES

6.1.2.1 Manual start

On-site operation

Step respons... | 10.2.2.1

Start test

- ➔ Use the rotary pushbutton to go to the 'Step response test (PST)' command (menu item: [10 Diagnosis/maintenance > Tests]). See ▶ EB 8493S.
- ➔ Press  to start test.

i Note

A test can be canceled manually by pressing the rotary pushbutton again.

Software command via TROVIS-VIEW/ integration

> Diagnosis/maintenance > Tests > Step response test (PST)

! Start test

i Note

The test can be manually canceled by selecting the 'Stop test' command.

6.1.2.2 Automatic start after 'Test interval' has elapsed

The step response test (PST) is started in AUTO mode regularly after the time entered in 'Test interval' has elapsed when the function is activated. The 'Delay time interval' parameter allows the test to be postponed once.

i Note

The time until the next regular test can be adapted in the 'Time until next test' information parameter.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Test interval: 1 to 365 d, [7 d]
- Activate test interval: [Not active], Active
- Delay test interval: [0] to 2160 h

> Diagnosis/maintenance > Tests > Step response test (PST)

– Time until next test (not write-enabled)

6.1.2.3 Start triggered by the binary input

Function only possible when positioners has option module [T] or [V].

> Configuration > Slot options > Slot C option

– Action upon active binary input: **start PST**

– Edge control:

[Active = switch closed], Active = switch open

6.1.3 Analysis and monitoring

The analysis of the last fifty step response test (PST) are saved with a time stamp in the [> Diagnosis/maintenance > Tests > Step response test (PST) > Reports and diagrams] folder. The last seven graphs at the maximum are shown.

The result of the last test can be read in the [> Diagnosis/maintenance > Tests > Step response test (PST) folder.

i Note

In total, seven step response tests (PST plus FST) with report and diagram can be displayed.

Test completed successfully

The following analysis parameters are shown during a completed step response test (PST).

Two test reports can be shown at one time for comparison. The comparison test can be selected as required.

> Diagnosis/maintenance > Tests > Step response test (PST) > Reports and diagrams

– Time stamp (not write-enabled)

– Dead time (not write-enabled)

– T86 (not write-enabled)

– Overshooting (not write-enabled)

– Pressure (only with pressure sensors) (not write-enabled)

– Test status (not write-enabled)

The results of the first step response test performed with the current configuration are used as a reference test and are write-protected. All other step response tests can be write-protected manually:

➔ Check   box.

Test not completed

If the test is canceled and no results are produced which activate the fail-safe position, the positioner changes to the 'Target operating mode'.

The fail-safe position can be activated, for example, when the forced venting is triggered and when the current is lower than 3.8 mA.

A test cancellation causes the 'PST: cancellation criteria met' status message to be generated with the assigned status classification.

If the test cannot be started, the 'PST: start criteria not met' status message with the assigned status classification is generated.

Table 3: Recommended action when the status message is generated

	Test result	We recommend:
Test canceled	Current	→ Check input signal
	Internal error	→ Restart test
	Timeout	→ Check seat and plug for deposits or foreign particles
	No movement possible	
Start criterion	Start criteria	→ Check test configuration
	Function active	→ Wait for the active test to finish and restart test.
	Incorrect operating mode	→ Set operating mode corresponding to Table 2 and restart test.

> Diagnosis/maintenance > Tests > Step response test (PST)

- Number of successful tests (not write-enabled)
- Number of canceled tests (not write-enabled)
- Number of failed start criteria (not write-enabled)

6.1.4 Reset

Refer to Table 4

Statistical analysis

Every time a step response test is started, one of the following counters counts this event depending on the test status.

Table 4: Reset step response test (PST)

	Initialization	'Reset diagnosis'	'Reset PST configuration'	'Clear reports'	'Reset (standard)'	'Reset (advanced)'
Reset configuration	YES	YES	YES	NO	YES	YES
Reset reports	YES	YES	YES	YES	YES	YES
Reset histograms	YES	YES	YES	YES	YES	YES
Reset reference test	YES	YES	YES	NO	YES	YES
Reset status messages	YES	YES	YES	NO	YES	YES

6.2 Step response test (FST)

The dynamic valve performance can be evaluated by performing the test. During the step response test (FST), the valve moves through its entire working range.

The valve can move through the working range either in steps or with a ramp function (Fig. 14). The test is performed with the ramp function when the ramp time ('Ramp') is set to $\neq 0$ s.

The test starts after the 'Waiting time' has elapsed. This ensures that the valve has reached the open position.

Starting from the open position, the valve moves to the closed position. The valve remains in this position for the time defined by the 'Waiting time' before performing a second step change in the opposite direction from the closed position to the open position. The 'Sampling time' defines the time interval

between which the measured values are recorded during the test.

> Diagnosis/maintenance > Tests > Step response test (PST) > Configuration

- Ramp 1: 0 to 9999 s, [60 s]
- Waiting time: 0 to 240 s, [2 s]

6.2.1 Test cancellation criteria


The positioner cancels the step response test (FST) when one of the following cancellation conditions is fulfilled:

Time

- 'Canceled: max. test duration': the test is canceled when the maximum permissible test duration is reached.

> Diagnosis/maintenance > Tests > Step response test (FST) > Configuration

- Canceled: max. test duration (not write-enabled)



Tolerance bands

- 'Start value of tolerance band +/-': the test is not started when the operating point is outside the range: open position
- 'Start value of tolerance band'

> Diagnosis/maintenance > Tests > Step response test (FST) > Configuration

- Start value of tolerance band +/-: 1 to 100 %, [3 %]

- 'End value of tolerance band +/-': the test is not started when the valve position after the first step does not reach the range: closed position + 'End value of tolerance band +/-'.

> Diagnosis/maintenance > Tests > Step response test (FST) > Configuration

- End value of tolerance band +/-: 1 to 100 %, [3 %]

Additionally, the step response test (FST) is canceled when one of the following events arises:

- The internal forced venting function is triggered.
- The current is lower than 3.8 mA.
- The test is manually canceled:
 - ➔ On site by pressing the rotary push-button
 - ➔ By software with the 'Stop test' parameter
- The positioner switches to the SAFE mode.
- At the start of the step response test over the binary input, the edge control chang-

es again to the state which starts the step response test (FST).

6.2.2 Test start

Table 5: Start conditions of step response test (FST)


Operating mode	See section 6.2.2.1 for manual start (on site or using software)	Start triggered by the binary input (see section 6.2.2.2)
AUTO	NO ¹⁾	NO ¹⁾
MAN	YES	YES


¹⁾ Default setting
By activating the 'Allow start in AUTO mode' parameter in the "Customer expert" user level, the test can also be started in AUTO mode.

6.2.2.1 Manual start

On-site operation

Step respons... | 10.2.2.1



- ➔ Use the rotary pushbutton to go to the 'Step response test (FST)' command (menu item: [10 Diagnosis/maintenance > Tests]). See ► EB 8493S.
- ➔ Press  to start test.

i Note

A test can be canceled manually by pressing the rotary pushbutton again.

Software command via TROVIS-VIEW/ integration

> **Diagnosis/maintenance > Tests > Step response test (FST)**

! Start test

i Note

The test can be manually canceled by selecting the 'Stop test' command.

6.2.2.2 Start triggered by the binary input

Function only possible when positioners has option module [T] or [V].

> **Configuration > Slot options > Slot C option**

- Action upon active binary input: **start FST**
- Edge control:
[Active = switch closed], Active = switch open

6.2.3 Analysis and monitoring

The analysis of the last six step response test (FST) at the maximum and graphs are saved with a time stamp in the [> Diagnosis/maintenance > Tests > Step response test (FST) > Reports and diagrams] folder.

The result of the last test can be read in the [> Diagnosis/maintenance > Tests > Step response test (FST) folder.

i Note

In total, seven step response tests (PST plus FST) with report and diagram can be displayed.

Test completed successfully

The following analysis parameters are shown during a completed step response test (FST).

Two test reports can be shown at one time for comparison. The comparison test can be selected as required.

> **Diagnosis/maintenance > Tests > Step response test (FST) > Reports and diagrams**

- Time stamp (not write-enabled)
- Dead time (rising) (not write-enabled)
- Dead time (falling) (not write-enabled)
- T86 (rising) (not write-enabled)
- T86 (falling) (not write-enabled)
- T98 (rising) (not write-enabled)
- T98 (falling) (not write-enabled)
- Test status (not write-enabled)

The results of the first step response test (FST) performed with the current configuration are used as a reference test and are write-protected. All other step response tests can be write-protected manually:

→ Check   box.

Test not completed

If the test is canceled and no results are produced which activate the fail-safe position, the positioner changes to the 'Target operating mode'.

The fail-safe position is activated when the forced venting is triggered and when the current is lower than 3.8 mA.

A test cancellation causes the 'FST: cancellation criteria met' status message to be generated with the assigned status classification.


If the test cannot be started, the 'FST: start criteria not met' status message with the assigned status classification is generated.

Note

No graph is plotted when a test cannot be started.

> Diagnosis/maintenance > Device state > Status classification

- FST: cancellation criteria met:



- FST: start criteria not met:





Fig. 13: > Diagnosis/maintenance > Tests > Step response test (FST) > Reports and diagrams

> **Diagnosis/maintenance > Device state > Status messages**

- FST: cancellation criteria met
- FST: start criteria not met

Statistical analysis

Every time a step response test is started, one of the following counters counts this event depending on the test status.

> **Diagnosis/maintenance > Tests > Step response test (FST)**

- Number of successful tests (not write-enabled)
- Number of canceled tests (not write-enabled)
- Number of failed start criteria (not write-enabled)

Table 6: Recommended action when the status message is generated

	Test result	We recommend:
Test canceled	Current	→ Check input signal
	Internal error	→ Restart test
	Timeout	→ Check seat and plug for deposits or foreign particles
No movement possible		
Start criterion	Start criteria	→ Check test configuration
	Function active	→ Wait for the active test to finish and restart test.
	Incorrect operating mode	→ Set operating mode corresponding to Table 5 and restart test.

6.2.4 Reset

Refer to Table 7









Table 7: Reset step response test (FST)

	Initialization	'Reset diagnosis'	'Reset FST configuration'	'Clear reports'	'Reset (standard)'	'Reset (advanced)'
Reset configuration	YES	YES	YES	NO	YES	YES
Reset reports	YES	YES	YES	YES	YES	YES
Reset histograms	YES	YES	YES	YES	NO	NO
Reset reference test	YES	YES	YES	NO	NO	NO
Reset status messages	YES	NO	YES	NO	NO	NO

7 Error messages and recommended corrective action

Message	Recommended action	Status classification
> Diagnosis/maintenance > Device state > Status classification		
No supply pressure	<ul style="list-style-type: none"> → Check air supply. → Check air lines/connections. 	YES [⚠]
Low supply pressure	<ul style="list-style-type: none"> → Check air supply. → Check supply pressure regulator. → Check air lines/connections. 	YES [⚠]
Supply pressure > 10 bar	<ul style="list-style-type: none"> → Check air supply. → Check supply pressure regulator. 	YES [⚠]
PST: cancellation criteria met	See section 6.1.	YES [⚠]
PST: start criteria not met	See section 6.1.	YES [✔]
FST: cancellation criteria met	See section 6.2.	YES [⚠]
FST: start criteria not met	See section 6.2.	YES [✔]
P3799: failure	<ul style="list-style-type: none"> → Check air quality. → Contact SAMSON's After-sales Service department. 	YES [highest classification]
P3799: movement impaired	<ul style="list-style-type: none"> → Check air supply. → Contact SAMSON's After-sales Service department. 	YES [highest classification]
P3799: maintenance required	<ul style="list-style-type: none"> → Check air supply. 	YES [highest classification]
P3799: initialization error	<ul style="list-style-type: none"> → Contact SAMSON's After-sales Service department. 	YES [highest classification]
AMR signal outside range	<ul style="list-style-type: none"> → Check attachment. 	YES [⚠]
Hardware error	<ul style="list-style-type: none"> → Confirm error and select AUTO operating mode. → Re-initialize positioner. 	YES [highest classification]
Limit for total valve travel exceeded	<ul style="list-style-type: none"> → Check valve and attachment for signs of wear. 	YES [⚠]
Lower end position shifted	See section 5.3.	YES [⚠]
Upper end position shifted	See section 5.3.	YES [⚠]
Dynamic stress factor exceeded	See section 5.2.4.	YES [⚠]

Error messages and recommended corrective action

Message	Recommended action	Status classification
Set point deviation		YES [
Brownout	→ Check input signal.	YES [
Current too low	→ Check input signal.	YES [
IP shutdown	→ Check input signal.	YES [
Current too high	→ Check input signal.	YES [
Angle limitation	→ Check attachment.	YES [highest classification]
Temperature inside device below min. limit	→ Check operating conditions.	YES [
Temperature inside device above max. limit	→ Check operating conditions.	YES [
Logging suspended	The positioner is not impaired. The message no longer appears as soon as the positioner starts logging again.	YES [

EB 8389-2S EN



SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3 · 60314 Frankfurt am Main, Germany
Phone: +49 69 4009-0 · Fax: +49 69 4009-1507
samson@samson.de · www.samson.de